RUSTOWN PDPX8074

RUSTOWN Farmhouse Bathroom Wall Cabinet Instruction Manual

Model: PDPX8074

Introduction

Thank you for purchasing the RUSTOWN Farmhouse Bathroom Wall Cabinet. This manual provides detailed instructions for assembly, installation, operation, and maintenance to ensure safe and efficient use of your new cabinet. Please read this manual thoroughly before beginning assembly or use.
For assistance, please refer to the contact information in the Support section.

Safety Information

Important: Follow all instructions carefully to avoid injury or damage to the product. Keep this manual for future reference.

- Ensure all parts are present and undamaged before assembly.
- Do not overtighten screws during assembly.
- Mount the cabinet securely to a wall stud or use appropriate drywall anchors for stability.
- Do not exceed the weight capacity of the shelves.
- Keep small parts away from children during assembly.

Package Contents

Verify that all components are included before starting assembly.

- Cabinet panels (engineered wood)
- Sliding barn doors
- Adjustable shelves
- Black metal hardware (knobs, hooks, sliding mechanism)
- Towel bar
- Assembly hardware (screws, dowels, wall mounting cleat, anchors)

- Instruction manual

Specifications

Brand	RUSTOWN
Model Name	PDPX8074
Color	Navy Blue
Material	Engineered Wood
Product Dimensions (D x W x H)	7.9" x 31.5" x 30.7" (20cm x 80cm x 78cm)
Item Weight	33.9 pounds (15.4 kg)
Mounting Type	Wall Mount
Number of Shelves	6 (including fixed and adjustable)
Special Features	Adjustable Shelves, Sliding Barn Doors, Towel Bar, 5 Removable Hooks




Image: Detailed dimensions of the RUSTOWN Farmhouse Bathroom Wall Cabinet, showing width, height, and depth measurements, along with internal shelf dimensions.

Setup and Assembly

Assembly is required for this product. Please follow the included comprehensive installation instructions carefully. Some panels may have specific front and back sides; refer to the step-by-step guide provided with your purchase.

Recommended Tools (Not Included):

- Phillips head screwdriver
- Hammer
- Level
- Drill (for wall mounting)
- Stud finder (for wall mounting)

Wall Mounting Instructions:

1. **Step 1: Secure Mounting Panel.** Identify the location on the wall where the cabinet will be mounted. Use a level to ensure the mounting panel is straight. Fix the mounting panel securely to the wall using appropriate screws, preferably into wall studs. If studs are not available, use suitable drywall anchors (not always included, may need to be purchased separately).
2. **Step 2: Align & Engage.** With assistance, lift the assembled cabinet and align the back of the cabinet with the secured mounting panel.
3. **Step 3: Hang & Lock.** Carefully slot the cabinet onto the mounting panel, ensuring it engages securely. Verify the cabinet is stable and level before placing items inside.



Image: Visual guide demonstrating the 3-step quick mount installation process for the RUSTOWN wall cabinet, showing securing the mounting panel, aligning the cabinet, and hanging it securely.

Operating Instructions

Adjustable Shelves:

The cabinet features 3-position adjustable shelves on both sides. To adjust a shelf, carefully remove any items, lift the shelf, and reposition the shelf supports into the desired holes. Ensure the shelf is level and securely seated before placing items back.

Sliding Barn Doors:

The two barn doors slide smoothly along the top track, allowing you to conceal or reveal different sections of the cabinet. Gently slide the doors using the handles. The bottom grooves help guide the doors and protect the frame.



Image: A detailed view highlighting the slideable door panel and handcrafted metal handle of the RUSTOWN cabinet, illustrating the sliding mechanism.

Towel Bar and Hooks:

The integrated towel bar and five S-shaped hooks at the bottom provide additional storage for towels, washcloths, or other hanging items. Ensure items hung do not exceed the weight capacity of the bar and hooks.

Maintenance and Care

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Dusting:** Regularly dust the cabinet with a dry, soft cloth.
- **Hardware:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Moisture:** While suitable for bathrooms, avoid prolonged exposure to excessive moisture. Wipe up spills immediately.

Troubleshooting

Problem	Possible Cause	Solution
Cabinet feels unstable after mounting.	Insufficient wall support; screws not fully tightened; improper anchor use.	Ensure mounting panel is secured to wall studs. If not possible, use heavy-duty drywall anchors. Check and tighten all mounting screws. Re-level if necessary.
Sliding doors are stiff or do not move smoothly.	Track obstruction; misaligned doors; dirt or debris in the track.	Inspect the top track and bottom grooves for any obstructions. Clean the track with a soft cloth. Ensure doors are properly seated in the grooves.
Shelves are not level or fall out.	Shelf supports not fully inserted; shelf not seated correctly.	Ensure all four shelf supports are fully inserted into the designated holes. Verify the shelf is resting evenly on all supports.

Warranty Information

RUSTOWN offers a limited warranty on this product against manufacturing defects. For specific warranty terms and conditions, please refer to the documentation included with your purchase or contact RUSTOWN customer service. Keep your proof of purchase for warranty claims.
Protection plans are available for purchase separately through Amazon. These plans offer extended coverage beyond the manufacturer's warranty.

- 2-Year Protection Plan (ASIN: B0CG6RYDXY)
- 3-Year Protection Plan (ASIN: B0CG6QPQD6)
- Complete Protect (ASIN: B07RZ3LSHM)

Customer Support

If you have any questions, concerns, or require assistance with your RUSTOWN Farmhouse Bathroom Wall Cabinet, please contact our customer service team.

- **Online Support:** Visit the RUSTOWN Store on Amazon.
- **Email:** Refer to your product packaging or included documentation for direct email contact.

Our professional customer service team is available to assist you.

© 2025 RUSTOWN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question