



Manuals.plus /

› Goyappin /

› Goyappin Handheld Steam Cleaner TC-SC-008 User Manual

Goyappin TC-SC-008

Goyappin Handheld Steam Cleaner User Manual

Model: TC-SC-008 | Brand: Goyappin

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the Goyappin Handheld Steam Cleaner. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Electrical Safety:** Always ensure the power outlet matches the voltage specified on the appliance. Do not operate with a damaged cord or plug.
- **High Temperature Steam:** The steam cleaner produces high-temperature steam (up to 212°F / 100°C). Avoid direct contact with skin or eyes. Always wear the provided heat-resistant gloves during operation.
- **Water Tank:** Only use clean tap water. Do not add detergents, chemicals, or aromatic oils to the water tank, as this can damage the appliance or create hazardous fumes.
- **Children and Pets:** Keep the appliance out of reach of children and pets. Do not leave the steam cleaner unattended while in operation.
- **Storage:** Always unplug the appliance and allow it to cool completely before storing. Store in a dry, safe place.

2. PRODUCT OVERVIEW

The Goyappin Handheld Steam Cleaner is a powerful and versatile cleaning tool designed for various surfaces. It features a 2500W heating element for rapid heat-up and a 1600ML water tank for extended cleaning sessions.

2.1 Included Components

The package includes the following items:

- 1 x Steam Cleaner Unit
- 1 x Cleaning Towel
- 1 x Extension Nozzle
- 1 x High-Pressure Nozzle
- 1 pair of Heat-Resistant Gloves
- Nylon Brush
- Brass Brush
- Scrapers

- Extension Pole
- Glass Clean Tool
- Spray Nozzle
- Bent Nozzle
- 2 x Rubber Rings
- Extended Power Cord
- Fabric Clean Tool
- Storage Bags

ALL-in-One Steam Cleaner



Image: All-in-One Steam Cleaner with various attachments and accessories.

2.2 Key Features

- **High Pressure Steam:** Delivers powerful steam at 3 Bar pressure.
- **Rapid Heat-Up:** Heats up in approximately 15 seconds.
- **Large Capacity Tank:** 1.69 Quarts (1600 Milliliters) water tank for extended use.
- **3 Steam Levels:** Adjustable steam control (Gear 1-3) for different cleaning needs.
- **Portable Design:** Handheld form factor with a long power cable (79 inches) and steam hose (59 inches) for easy maneuverability.
- **Chemical-Free Cleaning:** Uses only water for deep cleaning and sanitization.

3. SETUP

Follow these steps to prepare your steam cleaner for first use:

1. **Install Batteries:** Open the battery compartment on the spray gun handle and insert two AAA batteries.
2. **Fill Water Tank:** Open the dust cover on the main unit and fill the 1600ML tank with clean water. Do not overfill.
3. **Attach Accessories:** Securely install the desired brush head or nozzle onto the spray gun handle. Ensure the rubber ring is correctly placed at the connection point to prevent water leakage.
4. **Connect Power:** Plug the power cord into a suitable electrical outlet. The screen on the unit will display "0".



Image: Illustration of attaching brush heads directly or with an extension rod.



Image: Visual steps for battery installation, water filling, accessory attachment, and power connection.

4. OPERATION

Once set up, you can begin using your Goyappin Handheld Steam Cleaner:

1. **Power On:** Long-press the button on the spray gun handle for 2-3 seconds to power on. The screen will display "1". Allow 15 seconds for preheating.
2. **Adjust Steam Pressure:** Short-press the button on the handle to cycle through Gear 1, 2, and 3 steam control levels.
3. **Begin Cleaning:** Direct the steam nozzle towards the surface to be cleaned. Move the nozzle slowly over the area, allowing the steam to loosen dirt and grime.
4. **Power Off:** After use, long-press the button on the spray gun handle for 2-3 seconds to power off.



Image: Illustration of the spray gun handle with power and steam control buttons.

4.1 Usage Examples

- **Kitchen:** Clean stovetops, ovens, microwaves, and countertops.
- **Bathroom:** Sanitize tiles, grout, showers, and toilets.
- **Furniture & Fabrics:** Refresh couches, mattresses, and curtains.
- **Car Detailing:** Clean car seats, interior surfaces, and wheels.
- **Windows & Glass:** Use the glass clean tool for streak-free windows.



Image: Demonstrating steam cleaning on various household items.

Spray gun handle can control the switch and steam pressure.

Long press for 2-3s : Power on/off

Short press: Gear1-3 steam control



Image: Applications of the steam cleaner for car detailing and tough grime.

Perfect Results for Multi-Purpose



Image: Examples of multipurpose use showing before and after cleaning results.

4.2 Official Product Video

Your browser does not support the video tag.

Video: A demonstration of the Goyappin Handheld Steam Cleaner in action, showcasing its effectiveness on various surfaces.

5. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your steam cleaner.

- **Empty Water Tank:** After each use, remove the bottom drain plug to empty any remaining water from the tank.
- **Clean Accessories:** Wash all removable accessories with water and mild soap. Allow them to dry completely before storing.
- **Wipe Down Unit:** Wipe the main unit with a damp cloth. Do not immerse the unit in water.
- **Descaling (Periodically):** If you notice reduced steam output or mineral buildup, descale the unit by running a solution of equal parts white vinegar and water through it. Follow with several cycles of clean water.
- **Storage:** Store the steam cleaner and its accessories in the provided storage bags in a cool, dry place.



Image: Visual step for removing the bottom drain plug to empty water.

6. TROUBLESHOOTING

If you encounter issues with your steam cleaner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No steam output	Unit not powered on; Water tank empty; Insufficient preheating time; Blocked nozzle.	Ensure unit is powered on and preheated; Refill water tank; Allow 15 seconds for preheating; Clean or unblock nozzle.
Low steam pressure	Low water level; Mineral buildup; Steam level set too low.	Refill water tank; Perform descaling procedure; Adjust steam level to a higher setting (Gear 2 or 3).
Water leakage	Accessories not securely attached; Missing or damaged rubber ring.	Ensure all attachments are firmly connected; Check and replace rubber rings if necessary.
Unit not heating	Power cord not properly connected; Electrical outlet issue.	Check power cord connection; Try a different electrical outlet.

7. SPECIFICATIONS

- **Brand:** Goyappin
- **Model Number:** TC-SC-008
- **Wattage:** 2500 watts
- **Voltage:** 110 Volts
- **Heat Time:** 15 Seconds
- **Maximum Temperature:** 212 Degrees Fahrenheit (100 Degrees Celsius)
- **Tank Volume:** 1.69 Quarts (1600 Milliliters)
- **Item Weight:** 5.6 Pounds
- **Item Dimensions (D x W x H):** 5"D x 9"W x 7"H
- **Special Features:** High Pressure, Large Capacity Tank, Portable, Rapid Heat Up, Steam Control
- **Surface Recommendation:** All Surfaces

8. WARRANTY AND SUPPORT

For warranty information, product registration, or technical support, please refer to the documentation included with your product packaging or visit the official Goyappin website. Keep your purchase receipt as proof of purchase.