

[Manuals.plus](#) /

› [Aokrean](#) /

› Aokrean Halo Grow Light BL-B10E User Manual

Aokrean BL-B10E

Aokrean Halo Grow Light BL-B10E User Manual

Brand: Aokrean | Model: BL-B10E

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Aokrean Halo Grow Light BL-B10E. Designed for indoor plant growth, this full-spectrum light offers adjustable height, multiple color modes, and convenient timer functions to support your plants' health and development.

KEY FEATURES

- **Dual Installation Options:** Easily insert the stake directly into soil or use the detachable base for stability.
- **3 Spectrum Modes:** Choose from full-spectrum, warm, or cool light to match your plant's growth stage.
- **Auto Timer & 10 Brightness Levels:** Program 3/9/12-hour cycles and fine-tune intensity across 10 dimmable levels.
- **Adjustable Height (6.5–26 inches):** Flexibly raise or lower the LED panel to accommodate plants of various sizes.
- **Stylish Design:** The halo-inspired design blends seamlessly with modern home decor.

PACKAGE CONTENTS

- Aokrean Halo Grow Light x 1
- Power Adapter x 1
- Pole x 1
- ABS Base x 1
- User Manual x 1



Figure 1: Package contents for the Aokrean Halo Grow Light.

SETUP INSTRUCTIONS

The Aokrean Halo Grow Light offers versatile installation to suit your indoor gardening needs.

Method 1: Direct Soil Insertion

1. Attach the halo light head to the adjustable pole by screwing it securely.
2. Gently insert the pointed end of the pole directly into the soil of your potted plant. Ensure it is stable and

upright.

3. Adjust the height of the light to the desired level, typically 2-4 inches above the plant canopy.

Method 2: Using the Detachable Base

1. Attach the halo light head to the adjustable pole by screwing it securely.
2. Insert the pole into the provided ABS base.
3. Place the assembled light and base next to your plant. For added stability, place the plant pot directly on top of the base.
4. Adjust the height of the light to the desired level, typically 2-4 inches above the plant canopy.

DUAL-USE DESIGN

1 Detachable Base



1 Insert to base



2 Potted plants on base



3 Adjust height

2 Insert Soil



1 Insert to soil



2 Adjust height



3 Adjust angle

Figure 2: Dual installation options for the grow light.

Your browser does not support the video tag.

Video 1: Demonstration of Aokrean grow light installation using the base, showing height and position adjustments.

Your browser does not support the video tag.

Video 2: Showcase of the Aokrean wood grain grow light, demonstrating its adjustable features and aesthetic integration.

OPERATING INSTRUCTIONS

Your Aokrean Halo Grow Light is equipped with an inline controller for easy management of its settings.

Power On/Off

- Press the **Power Button** () on the inline controller to turn the light on or off.

Timer Settings

The grow light features an automatic timer to ensure your plants receive consistent light exposure without manual intervention.

- Press the **Timer Button** () to cycle through the available timer options: 3 hours (blue indicator), 9 hours (green indicator), and 12 hours (red indicator).
- Once a timer is set, the light will automatically turn on for the selected duration each day and then turn off.

Brightness Adjustment

Customize the light intensity to suit your plants' specific needs.

- Use the **Plus (+)** and **Minus (-)** buttons () to adjust between 10 dimmable brightness levels.

Spectrum Mode Selection

Choose the appropriate light spectrum for different plant growth stages.

- Press the **Spectrum Button** () to switch between 3 color modes:
 - **White Light:** Ideal for general plant growth.
 - **Warm White & Red Light:** Promotes flowering and fruiting.
 - **All Light On (Full Spectrum):** Suitable for all growth stages, mimicking natural sunlight.



3 Optional Spectrum



White Light



Warm White & Red



All Light on

Figure 3: Inline controller for brightness, spectrum, and timer settings.

Your browser does not support the video tag.

Video 3: Demonstration of the compact size and ease of use of Aokrean small grow lights for indoor plants.

Your browser does not support the video tag.

Video 4: Demonstration of the automatic timer function, showing how to set 6, 9, or 12-hour cycles for plant grow lights.

MAINTENANCE

To ensure optimal performance and longevity of your Aokrean Halo Grow Light, follow these simple maintenance guidelines:

- **Cleaning:** Regularly wipe the LED panel and pole with a soft, dry cloth to remove dust and debris. Do not use abrasive cleaners or immerse the light in water.
- **Placement:** Ensure the light is positioned at the recommended distance from your plants (typically 2-4 inches) to provide adequate light without causing heat stress.

- **Cable Care:** Avoid bending or crimping the power cable excessively. Keep it away from water and heat sources.
- **Storage:** If storing the grow light, ensure it is clean, dry, and disassembled if necessary, then store in a cool, dry place.

TROUBLESHOOTING

If you encounter any issues with your Aokrean Halo Grow Light, refer to the following common troubleshooting steps:

- **Light Not Turning On:**
 - Check if the power adapter is securely plugged into both the light and a working power outlet.
 - Ensure the power button on the inline controller is pressed.
 - Verify that the power outlet is functional by plugging in another device.
- **Timer Not Working:**
 - Confirm that the timer button has been pressed and the correct duration (3H, 9H, or 12H) is indicated by the colored LED.
 - Note that the timer function may reset after a power outage. Re-set the timer if necessary.
- **Inconsistent Brightness/Color:**
 - Ensure the brightness and spectrum buttons are pressed firmly to select the desired setting.
 - If the issue persists, try unplugging and re-plugging the light to reset it.

If these steps do not resolve the issue, please contact customer support for further assistance.

SPECIFICATIONS

Feature	Detail
Model Name	Halo grow light
Item Model Number	BL-B10E
Brand	Aokrean
Light Source Type	LED (48 Multi-Color Temperature LEDs)
Light Size	3.4 inches (Halo Diameter)
Height Adjustable	6.5 - 26 inches
Lighting Modes	3 (White, Warm White & Red, All Light On)

Brightness Levels	10 Dimmable Levels
Timer Options	3 / 9 / 12 hours (Auto On/Off)
Installation Methods	2 (Insert into soil, Use ABS Base)
Material	Acrylonitrile Butadiene Styrene, Aluminum
Power Source	Corded Electric
Indoor/Outdoor Usage	Indoor
Item Weight	1.19 pounds

WARRANTY AND SUPPORT

Aokrean stands behind the quality of its products. Your Halo Grow Light BL-B10E is covered by a standard manufacturer's warranty against defects in materials and workmanship.

- **Warranty Period:** Please refer to the product packaging or our official website for specific warranty duration.
- **Customer Support:** For technical assistance, troubleshooting, or warranty claims, please contact Aokrean customer service through the retailer where you purchased the product or visit our official website for contact information.