



Manuals.plus /

› **LOBKIN** /

› LOBKIN AFC-80 3-in-1 Wireless Charging Station User Manual

## LOBKIN AFC-80

# LOBKIN AFC-80 3-in-1 Wireless Charging Station User Manual

Model: **AFC-80** | Brand: **LOBKIN**

## 1. INTRODUCTION

---

Thank you for choosing the LOBKIN AFC-80 3-in-1 Wireless Charging Station. This device is designed to provide a convenient and efficient charging solution for your iPhone, Apple Watch, and AirPods simultaneously. Please read this manual carefully to ensure proper use and to maximize the product's lifespan.

### What's in the Box:

- LOBKIN AFC-80 3-in-1 Wireless Charging Station
- USB Type-C Charging Cable
- User Manual

# AI-POWERED 15W FAST CHARGING



Image 1.1: LOBKIN AFC-80 Charging Station with USB-C cable and user manual.

## 2. PRODUCT FEATURES

- **15W Wireless Fast Charging:** Delivers up to 15W fast wireless charging for compatible phones. Features smart power distribution and built-in protection against overheating, overcurrent, and short circuits for safe and efficient charging.
- **3-in-1 Charging Capability:** Charges your iPhone, Apple Watch, and AirPods simultaneously, reducing cable clutter and organizing your space.
- **Magnetic Alignment & Adjustable Stand:** Ensures precise magnetic alignment for secure and stable phone charging. The phone stand supports angle adjustment up to 60°, allowing for easy switching between portrait and landscape modes.
- **Touch Sensitive & Portable Design:** Features touch-sensitive controls for activating charging areas. Its slim, foldable structure makes it easy to carry and store, ideal for home, office, or travel.
- **Stable Base & Durable Build:** Equipped with a weighted base and anti-slip pads for stability. Constructed with premium materials for enhanced durability and efficient heat dissipation.

# STRONG MAGNETIC GRIP

Secure Charging



Image 2.1: Magnetic phone charging area with strong grip.

# ULTIMATE SAFETY PROTECTION



Image 2.2: Safety features including flash charge, smart cooling, and overload defense.

## 3. SETUP GUIDE

1. **Unpack the Charger:** Carefully remove the charging station and USB Type-C cable from the packaging.
2. **Connect Power:** Insert one end of the provided USB Type-C cable into the charging port on the back of the LOBKIN AFC-80 station. Connect the other end to a compatible power adapter (not included) with a minimum output of 15W for optimal performance.
3. **Place on a Stable Surface:** Position the charging station on a flat, stable surface away from direct sunlight or heat sources.



Image 3.1: Connecting the USB Type-C cable to the charging station.

## 4. OPERATING INSTRUCTIONS

---

### Activating Charging Areas:

The LOBKIN AFC-80 features touch-sensitive buttons to deploy its charging pads. Gently press the designated touch areas on the front of the station to extend the charging surfaces for your Apple Watch and AirPods.

# FLEXIBLE TOUCH CONTROL



Image 4.1: Touch-sensitive activation of charging pads.

## Charging Your Devices:

1. **For iPhone:** Place your iPhone directly onto the magnetic charging pad at the top of the station. Ensure it aligns correctly for optimal charging. The stand can be adjusted up to 60 degrees for comfortable viewing.
2. **For Apple Watch:** Gently press the touch button on the right side to extend the Apple Watch charging module. Place your Apple Watch onto the module.
3. **For AirPods:** Gently press the touch button on the left side to extend the AirPods charging module. Place your AirPods charging case onto the module.

An indicator light will confirm that your devices are charging. When not in use, you can press the touch buttons again to retract the charging pads, making the station compact for storage or travel.

Your browser does not support the video tag.

Video 4.2: Demonstration of the LOBKIN AFC-80's pop-up charging pads and device placement.

## 5. COMPATIBILITY

The LOBKIN AFC-80 Wireless Charging Station is compatible with a wide range of devices:

- **iPhones:** iPhone 16 Pro Max, iPhone 16 Pro, iPhone 16 Plus, iPhone 15 Pro Max, iPhone 15 Pro, iPhone 15 Plus, iPhone 15, iPhone 14 Pro Max, iPhone 14 Pro, iPhone 14 Plus, iPhone 14, iPhone 13 Pro Max, iPhone 13 Pro, iPhone 13, iPhone 13 mini, iPhone 12 Pro Max, iPhone 12 Pro, iPhone 12, iPhone 12 mini, iPhone SE (2nd Gen), iPhone SE (3rd Gen).
- **Apple Watch:** All Apple Watch Series (SE, Ultra, Series 1-9, etc.)
- **AirPods:** AirPods 2, AirPods 3, AirPods Pro, and other wireless charging earphones.
- **Other Qi-Enabled Devices:** Compatible with various Qi-enabled smartphones and devices, including Samsung Series, Motorola Mobility Series, Google Pixel Series, and more.



Image 5.1: Visual representation of compatible devices.

## 6. SAFETY INFORMATION

---

To ensure safe operation and prevent damage to the device or personal injury, please observe the following safety guidelines:

- Do not disassemble, modify, or repair the device yourself.
- Keep the device away from water, moisture, and high temperatures.
- Avoid dropping or subjecting the device to strong impacts.
- Use only the provided USB Type-C cable and a compatible power adapter.
- Do not place metal objects or magnetic cards on the charging pads, as this may interfere with charging or damage the device.
- Ensure proper ventilation around the charging station during use.

## 7. MAINTENANCE

---

Proper maintenance will help extend the life of your charging station:

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry cloth to wipe the surface of the charging station. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use for extended periods, store the charging station in a cool, dry place. Its foldable design allows for compact storage.

## 8. TROUBLESHOOTING

---

If you encounter issues with your LOBKIN AFC-80, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device not charging	Incorrect placement, incompatible device, insufficient power adapter, thick phone case, foreign object.	Ensure device is centered on the charging pad. Verify device compatibility. Use a power adapter with at least 15W output. Remove thick phone cases. Remove any metal objects.
Slow charging	Low power adapter output, background apps, device overheating.	Use a higher wattage power adapter. Close unnecessary background applications. Allow device to cool down.
Charging indicator not lighting up	No power, faulty cable/adaptor, device not detected.	Check power connection. Try a different USB-C cable or power adapter. Re-position the device.
Charging pads not extending/retracting	Power issue, mechanical obstruction.	Ensure the station is powered on. Check for any obstructions. Gently press the touch button again.

If the problem persists after trying these solutions, please contact LOBKIN customer support for assistance.

## 9. SPECIFICATIONS

---

- **Model Number:** AFC-80
- **Brand:** LOBKIN
- **Input Voltage:** 12 Volts
- **Amperage:** 1.7 Amps
- **Wattage:** 15 Watts
- **Connector Type:** USB Type C
- **Item Weight:** 1.06 pounds
- **Package Dimensions:** 6.54 x 3.78 x 2.83 inches

## 10. WARRANTY AND SUPPORT

---

LOBKIN is committed to providing high-quality products and excellent customer service. If you encounter any issues with your AFC-80 Wireless Charging Station, please do not hesitate to contact our customer support team. We aim to assist you within 12 hours to ensure a worry-free experience.

For warranty information and support, please refer to the contact details provided on the product packaging or visit the official LOBKIN website.