

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [CLIMADIFF](#) /

› [CLIMADIFF CEPAGE52DZF 52-Bottle Dual Zone Wine Cooler Instruction Manual](#)

## CLIMADIFF CEPAGE52DZF

# CLIMADIFF CEPAGE52DZF 52-Bottle Dual Zone Wine Cooler Instruction Manual

## INTRODUCTION

This manual provides essential information for the safe and efficient operation of your CLIMADIFF CEPAGE52DZF 52-Bottle Dual Zone Wine Cooler. Please read these instructions carefully before installation and use, and retain them for future reference.

The CLIMADIFF CEPAGE52DZF is designed to store up to 52 bottles of wine, featuring two independent temperature zones (5-20°C) for optimal preservation of both red and white wines. Its modern design, quiet operation, and advanced features ensure your wine collection is perfectly maintained.

## SAFETY INFORMATION

### Important Safety Instructions:

- Ensure the appliance is properly grounded.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Keep ventilation openings clear of obstruction.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerant circuit.
- This appliance is intended for household use only.
- Unplug the appliance before cleaning or performing maintenance.
- Do not allow children to play with or inside the appliance.

## PACKAGE CONTENTS

- CLIMADIFF CEPAGE52DZF Wine Cooler Unit
- 4 x Sliding Beech Wood Shelves
- Instruction Manual (this document)

## SETUP AND INSTALLATION

## Placement

The CLIMADIFF CEPAGE52DZF is designed for free-standing installation only. Ensure adequate space around the unit for proper ventilation. Avoid placing the cooler in direct sunlight or near heat sources.

- **Dimensions:** 49.5 cm (width) x 59.6 cm (depth) x 83.5 cm (height).
- Ensure the floor is level and strong enough to support the fully loaded unit.
- Maintain a minimum clearance of 10 cm at the back and sides for air circulation.

## Power Connection

Connect the appliance to a dedicated, grounded electrical outlet. The unit operates on 240 Volts.

## Initial Use

Before loading bottles, allow the wine cooler to stand upright for at least 2 hours after transport. Clean the interior with a damp cloth. Plug in the unit and allow it to reach the desired temperature settings for several hours before placing wine bottles inside.



Image: Front view of the CLIMADIFF CEPAGE52DZF wine cooler, showcasing its sleek black design and glass door, filled with various wine bottles on wooden shelves.

## OPERATING INSTRUCTIONS

### Temperature Control (Dual Zone)

The CEPAGE52DZF features two independent temperature zones, allowing you to store red and white wines at their ideal serving or aging temperatures. The upper zone typically holds 21 bottles, and the lower

zone holds 31 bottles.

- **Temperature Range:** Both zones can be set between 5°C and 20°C.
- **Digital Control Panel:** Use the external digital control panel to adjust the temperature for each zone. Press the 'SET' button to select the zone (upper/lower) and use the '+' and '-' buttons to set the desired temperature.
- The display will show the current temperature of each zone.

## LED Lighting

The interior is illuminated with cold white LED lighting. This lighting highlights your wine collection without emitting heat or harmful UV rays, protecting your wines from degradation.

## Sliding Beech Wood Shelves

The wine cooler is equipped with four sliding beech wood shelves. These shelves are designed to be elegant, practical, and provide anti-vibration support to preserve your bottles.

## Vinotag Application Integration

This appliance is compatible with the Vinotag application, allowing you to manage your virtual wine cellar directly from your smartphone. Refer to the Vinotag app documentation for detailed instructions on pairing and usage.




Image: Interior view of the CLIMADIFF CEPAGE52DZF wine cooler, displaying multiple rows of wine bottles neatly arranged on the sliding beech wood shelves. The digital control panel is visible at the top.

## MAINTENANCE

### Cleaning the Interior

- Always unplug the unit before cleaning.
- Clean the interior with a mild detergent and warm water. Avoid abrasive cleaners or solvents.
- Wipe dry thoroughly with a soft cloth.
- The shelves can be removed for easier cleaning.

### Exterior and Door Care

- Clean the exterior with a soft, damp cloth. For stubborn marks, use a mild, non-abrasive cleaner.
- The triple-glazed glass door with Low-e filter helps limit thermal exchange and protects your wines from UV light. Clean the glass with a glass cleaner and a soft cloth.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not operate	Not plugged in; Power outage; Circuit breaker tripped.	Ensure plug is secure; Check power supply; Reset circuit breaker.
Temperature is not cold enough	Door not closed properly; Excessive door openings; Warm environment; Ventilation blocked; Temperature setting too high.	Check door seal; Reduce door openings; Ensure proper ventilation; Adjust temperature setting.
Vibrations	Appliance not level.	Adjust leveling feet.
Excessive noise	Normal operation sounds; Appliance not level; Loose components.	Refer to normal operating sounds; Level the appliance; Check for loose parts.

## SPECIFICATIONS

Feature	Detail
Brand	CLIMADIFF
Model Number	CEPAGE52DZF
Capacity	52 Bottles (21 upper, 31 lower)
Volume	127 Liters
Dimensions (L x W x H)	60 x 50 x 84 cm
Weight	38 kg
Temperature Zones	Dual Zone (5-20°C)
Installation Type	Free-standing
Color	Black

Feature	Detail
Voltage	240 Volts
Wattage	85 Watts
Shelves	4 x Sliding Beech Wood
Door Finish	Triple Glazed, Low-e Filter
Noise Level	37 dB
Annual Energy Consumption	105 kWh/year
Energy Efficiency Class	F





Image: Energy label for the CLIMADIFF CEPAGE52DZF wine cooler, indicating an energy efficiency class F, annual consumption of 105 kWh, capacity of 52 bottles, and a noise level of 37 dB.

For more details, visit the [EPREL database](#).

## WARRANTY AND SUPPORT

CLIMADIFF offers a 10-year availability for spare parts for the CEPAGE52DZF wine cooler. For technical support, warranty claims, or further assistance, please contact CLIMADIFF customer service or visit the official [CLIMADIFF Brand Store](#).

	<p><a href="#"><b>Climadiff CLS130-CLS160 Wine Cellar User Manual</b></a></p> <p>Comprehensive user manual for Climadiff CLS130 and CLS160 wine cellars, detailing installation, operation, safety, maintenance, and technical specifications for optimal wine storage.</p>
	<p><a href="#"><b>Offre Black Friday Climadiff : Jusqu'à 200€ remboursés sur les caves à vin éligibles</b></a></p> <p>Détails de la promotion Black Friday Climadiff offrant jusqu'à 200€ de remboursement sur l'achat de caves à vin éligibles entre le 14 novembre et le 1er décembre 2025. Découvrez comment participer et obtenir votre remboursement.</p>
	<p><a href="#"><b>Offre Climadiff : Carte Cadeau CAVAVIN Jusqu'à 200€ pour l'Achat de Caves à Vin</b></a></p> <p>Découvrez l'offre spéciale Climadiff 'Foire aux vins' : recevez jusqu'à 200€ en carte cadeau CAVAVIN pour l'achat d'une cave à vin éligible entre le 18 août et le 19 octobre 2025. Instructions de participation, modèles concernés et conditions détaillées.</p>
	<p><a href="#"><b>CLIMADIFF GARDE200D Energy Efficiency Label</b></a></p> <p>Energy efficiency details for the CLIMADIFF GARDE200D, including its energy consumption, bottle capacity, and noise level, presented on an EU energy label.</p>