

[Manuals.plus](#) /

› [AKORD](#) /

› AKORD K-100 Chest of Drawers User Manual

AKORD K-100

AKORD K-100 Chest of Drawers User Manual

INTRODUCTION

The AKORD K-100 chest of drawers combines a sleek design with functional storage. Featuring three drawers and two doors, it offers a well-designed solution for organizing everyday items. Its clean lines and compact size make it an ideal addition to modern living or sleeping spaces, integrating harmoniously with various interior styles.



Image: The AKORD K-100 chest of drawers, showcasing its design with three top drawers and two lower cabinet doors, in an oak artisan finish.

Safety Information

Important Safety Warning: Assemble with caution and securely mount the unit to the wall to prevent any risk of tipping. Wear protective gloves during assembly to avoid injuries caused by tools or sharp edges.

- Always follow the assembly instructions carefully.
- Ensure all fasteners are tightened securely.
- Do not allow children to climb on the furniture.
- Place heavier items in lower drawers to improve stability.

SETUP AND ASSEMBLY

This product requires assembly. Please read all instructions thoroughly before beginning. It is recommended to sort all components and hardware before starting to ensure all parts are present and to familiarize yourself with them.

1. **Unpack and Verify:** Carefully unpack all components and check against the parts list provided in the packaging.
2. **Prepare Workspace:** Assemble the unit on a clean, soft surface (e.g., a carpet) to prevent scratches.
3. **Identify Components:** Although parts may not be individually numbered, refer to the diagrams in the included manual to identify each piece.
4. **Assemble Frame:** Follow the step-by-step diagrams to construct the main frame of the chest of drawers.
5. **Install Drawers and Doors:** Attach drawer slides, assemble drawers, and install doors according to the instructions. Ensure smooth operation.
6. **Secure to Wall:** For safety, it is crucial to securely mount the chest of drawers to a wall using the provided anti-tip hardware. This prevents accidental tipping, especially in households with children.




Image: Technical diagram illustrating the precise dimensions of the AKORD K-100 chest of drawers, including overall height, width, and depth, as well as internal compartment measurements.

OPERATING INSTRUCTIONS

The AKORD K-100 chest of drawers is designed for versatile storage in your living room or bedroom. It features three smooth-gliding drawers and two cabinet doors with internal shelving.

- **Drawers:** Gently pull the drawer handles to open. Push firmly to close. Avoid overloading drawers to ensure smooth

operation and prevent damage to the slides.

- **Cabinet Doors:** Use the handles to open the doors. The internal shelves provide additional space for organizing various items.
- **Storage Capacity:** With three drawers and four shelves behind the doors, you can keep items neatly organized and easily accessible.



Image: The AKORD K-100 chest of drawers with its drawers and cabinet doors open, showcasing the interior layout and storage possibilities.



Image: A detailed view of the drawer mechanism within the AKORD K-100 chest of drawers, highlighting the metal slides for smooth operation.

MAINTENANCE

The AKORD K-100 chest of drawers is constructed from high-quality engineered wood, making it robust and easy to maintain for durable daily use.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the laminate finish.
- **Spills:** Clean up spills immediately to prevent moisture absorption and staining.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary to maintain structural integrity and smooth operation of drawers and doors.
- **Avoid Overloading:** Do not place excessively heavy items on top of the unit or inside the drawers and cabinets to prevent structural stress.

TROUBLESHOOTING

- **Drawers or Doors Not Closing Smoothly:**
Check for obstructions in the drawer slides or door hinges. Ensure all assembly screws are properly tightened. Adjust hinges if doors are misaligned.
- **Unit Feels Unstable:**
Verify that the unit is placed on a level surface. Confirm that the anti-tip hardware is securely installed and attached to the wall. Re-tighten all assembly screws.
- **Missing or Damaged Parts:**
If you discover any missing or damaged components during unpacking or assembly, please contact AKORD customer support immediately for assistance.

SPECIFICATIONS

Brand	AKORD
Model Number	KOMMK1002D3SZ1PARTPK (K-100)
Material	Engineered Wood (Laminated top)
Color	Oak Artisan
Dimensions (P x L x H)	35 cm x 101 cm x 98 cm (13.8 in x 39.8 in x 38.6 in)
Weight	40.6 Kilograms (89.5 lbs)
Number of Drawers	3
Number of Doors	2
Number of Shelves	4 (internal)
Assembly Required	Yes
Mounting Type	Floor Mount (with wall anchoring recommended)

WARRANTY AND SUPPORT

For any questions regarding assembly, missing parts, or product performance, please contact AKORD customer support. While specific warranty details are not provided in this manual, please refer to your purchase documentation or the retailer's website for warranty information.

You can often find support contact information on the manufacturer's official website or through the retailer where the product was purchased.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question