

[Manuals.plus](#) /

› [Pagani Design](#) /

› Pagani Design PD1644 Chronograph Quartz Watch User Manual

Pagani Design PD-1644

Pagani Design PD1644 Chronograph Quartz Watch User Manual

INTRODUCTION

Welcome to your new Pagani Design PD1644 Chronograph Quartz Watch. This timepiece combines precision engineering with durable materials, featuring a reliable VK63 quartz movement, sapphire crystal, and 100-meter water resistance. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your watch.



Pagani Design PD1644 Chronograph Quartz Watch with blue dial and rose gold case on a black rubber strap.

SETUP

Setting the Time

1. Pull the crown out to the second click position.
2. Turn the crown to set the hour and minute hands.
3. Push the crown back to the normal position.

Setting the Date

1. Pull the crown out to the first click position.
2. Turn the crown clockwise or counter-clockwise to set the date.
3. Avoid setting the date between 9 PM and 3 AM, as this can interfere with the date change mechanism. If the date needs to be set during this period, first set the time outside this range, adjust the date, then reset the time.

4. Push the crown back to the normal position.

OPERATING THE CHRONOGRAPH

The PD1644 features a VK63 quartz chronograph movement, allowing for precise time measurement.

Chronograph Functions:

- **Start/Stop Button (A):** Press the top pusher (A) to start the chronograph. Press it again to stop the chronograph.
- **Reset Button (B):** With the chronograph stopped, press the bottom pusher (B) to reset all chronograph hands to their zero positions.

Chronograph Hand Adjustment (if hands do not reset to zero):

1. Pull the crown out to the second click position.
2. Press button A to adjust the 1/5 second chronograph hand.
3. Press button B to adjust the chronograph minute hand.
4. Once adjusted, push the crown back to the normal position.

WATER RESISTANCE

The Pagani Design PD1644 watch is water-resistant up to 100 meters (10 ATM). This makes it suitable for daily use, showering, swimming, and snorkeling. It is not suitable for diving.

Important: Do not operate the crown or pushers when the watch is wet or submerged in water. Ensure the crown is fully pushed in before exposing the watch to water.

MAINTENANCE

Cleaning:

- Wipe the watch case and strap regularly with a soft, dry cloth. For water-resistant models, a slightly damp cloth can be used, followed by a dry cloth.
- Avoid using chemical cleaners, as they can damage the watch's finish and seals.

Battery Replacement:

- This watch is powered by a quartz movement. When the battery runs low, the second hand may start skipping seconds (End-of-Life indicator).
- Battery replacement should be performed by a qualified watch technician to ensure proper sealing and water resistance.

Storage:

- When not wearing the watch for extended periods, store it in a cool, dry place, away from direct sunlight and strong magnetic fields.

TROUBLESHOOTING

Watch Not Running:

- Check if the crown is fully pushed in. If it is pulled out, the watch will not run.
- The battery may need replacement. Consult a professional watch technician.

Chronograph Hands Not Resetting to Zero:

- Follow the "Chronograph Hand Adjustment" steps in the Operating section.

Date Not Changing:

- Ensure the time is set correctly, especially the AM/PM cycle. The date changes around midnight.
- Avoid setting the date between 9 PM and 3 AM.

SPECIFICATIONS

The following are the general specifications for the Pagani Design PD1644 watch:

- **Model Number:** PD-1644
- **Movement:** Japanese VK63 Quartz Chronograph
- **Case Material:** 316L Stainless Steel
- **Dial Window Material:** Sapphire Crystal
- **Case Diameter:** 40 mm
- **Case Thickness:** 12 mm
- **Band Width:** 20 mm
- **Band Length:** 220 mm
- **Water Resistance:** 100 Meters (10 ATM)
- **Weight:** Approximately 110 Grams
- **Special Features:** Chronograph, Luminous Hands

Model: PD-1664

Style: Male



Case Thickness:12MM



Dial Diameter:40MM



Weight.:95G



Max Perimeter:250MM



Movement:
Japan VK63



Band Width:20MM



Band Material : Rubber strap



Dial Window Material Type:
Synthetic sapphire glass



Original gift box,User manual
warranty card and original watch



Note: This data is only store measurement data,
There is an error (size ± 1 MM, weight ± 2 G)

Diagram illustrating the key dimensions of the Pagani Design PD1644 watch.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your purchase or contact your retailer. The manufacturer, RollsTimi, provides support for this product.

Return Policy: This product may be eligible for returns within 7 days of purchase, subject to the retailer's return policy.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question