

## WLIVE ABZ049

# WLIVE End Table with Charging Station (Model ABZ049) Instruction Manual

Model: ABZ049 | Brand: WLIVE

## 1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your WLIVE End Table with Charging Station, Model ABZ049. Please read all instructions carefully before assembly and use to ensure safe and proper functionality.

The WLIVE End Table is designed to offer convenient storage and charging capabilities. It features a vintage farmhouse style, integrated charging station with AC outlets and USB ports, a multi-functional drawer with a detachable holder, and additional cabinet storage.

## 2. SAFETY INFORMATION

- Always unplug the table from the power outlet when not in use or before cleaning.
- Do not overload the AC outlets or USB ports. Refer to the specifications for maximum load.
- Keep the table away from water and excessive heat sources to prevent damage and electrical hazards.
- Follow all assembly instructions carefully to avoid injury or damage to the product.
- Keep the table away from children and pets when the charging station is in use or exposed.
- Ensure all connections are secure before plugging the unit into a power source.
- Do not attempt to modify or repair the electrical components of the charging station. Contact qualified personnel for service.

### 3. PACKAGE CONTENTS

---

Please verify that all parts and hardware are present before beginning assembly. Refer to the included parts list in your product packaging for a complete inventory. If any parts are missing or damaged, please contact customer support.

**Note:** The assembly video below provides a visual guide to the parts and assembly process.

### 4. ASSEMBLY INSTRUCTIONS

---

Assembly is required for this end table. It is recommended to have two people for certain steps. A screwdriver is the only tool recommended for assembly.

#### Assembly Video Guide

Your browser does not support the video tag.

**Video 1:** WLIVE Farmhouse Night Stand Installation Video. This video provides a step-by-step visual guide for assembling your end table.

#### General Assembly Steps:

1. **Prepare Components:** Unpack all components and hardware. Identify each part using the labels provided in the packaging.
2. **Assemble Side Panels:** Attach the side panels to the base and top sections using the provided screws and dowels. Ensure all connections are tight.
3. **Install Drawer Slides:** Secure the drawer slides to the interior side panels of the table. Ensure they are level and aligned for smooth drawer operation.
4. **Assemble Drawer:** Construct the drawer box, then attach the drawer face and handle.
5. **Install Charging Station:** Place the charging station into its designated compartment. Secure it with the provided fasteners. Route the power cord through the cable management groove.
6. **Attach Door:** Install the cabinet door using the hinges. Adjust as necessary for proper alignment and closure.
7. **Final Checks:** Ensure all screws are tightened and the table is stable.



Image 1: The fully assembled WLIVE End Table with Charging Station in a living room.

## 5. OPERATING INSTRUCTIONS

### 5.1 Charging Station

- **Power Connection:** Plug the table's main power cord into a standard 120V AC wall outlet.
- **Accessing Outlets:** The charging station is located under a flip-top panel on the tabletop. Lift the panel to access the 3 AC outlets and 2 USB ports.
- **Power Switch:** Use the independent power switch on the charging station to turn power on or off to all connected devices. This provides added safety and convenience.

- **Cable Management:** Utilize the designed grooves and flip-top feature to manage cables neatly and keep the tabletop clear.



Image 2: The integrated charging station with AC outlets and USB ports, accessible via a flip-top panel.

## 5.2 Multi-functional Drawer

- **Detachable Holder:** The top drawer includes a detachable holder designed for remote controls, cups, and small items.
- **Hidden Storage:** Removing the detachable holder reveals a deeper drawer space suitable for books, watches, or other personal items.
- **Smooth Operation:** The drawer is equipped with smooth slide rails for easy opening and closing.

# Drawer with *Detachable* Holder



Smooth  
Slide Rails



Rustic  
Handle

**Image 3:** The drawer features a detachable holder for convenient organization of small items.

## 5.3 Cabinet Storage

- The lower cabinet provides enclosed storage space, ideal for larger items or for keeping belongings dust-free.
- The cabinet door features an acrylic panel, allowing for display while protecting contents.



**Image 4:** The lower cabinet offers enclosed storage with an acrylic door.

## 6. MAINTENANCE AND CARE

- **Cleaning:** Wipe the table surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Spill Management:** The tabletop is made from a waterproof board. In case of spills, wipe immediately with a dry cloth to prevent water damage.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary.
- **Electrical Components:** Keep the charging station free from dust and debris. Do not immerse the charging station or power cord in water.



Image 5: The waterproof surface of the table allows for easy cleaning of spills.

## 7. TROUBLESHOOTING

- **Charging Station Not Working:**

- Ensure the main power cord is securely plugged into a functional wall outlet.
- Check the power switch on the charging station to ensure it is in the 'ON' position.
- Verify that the devices you are trying to charge are properly connected to the outlets/USB ports and are functional.
- If the issue persists, try plugging another device into the wall outlet to confirm the outlet is working.

- **Drawer Not Sliding Smoothly:**

- Check if any objects are obstructing the drawer slides.
- Ensure the drawer slides are properly aligned and securely fastened. Refer to the assembly instructions.

- **Table Instability:**

- Verify that all assembly screws are tightened.
- Ensure the table is placed on a flat, level surface.

## 8. SPECIFICATIONS

| Attribute | Detail |
|-----------|--------|
| Brand     | WLIVE  |

|                                |  |
|--------------------------------|--|
| Model Number                   | ABZ049                                   |
| Product Dimensions             | 23.7"D x 13.78"W x 23.7"H                |
| Item Weight                    | 31.6 Pounds                              |
| Maximum Weight Recommendation  | 44 Pounds                                |
| Frame Material                 | Engineered Wood                          |
| Color                          | Black                                    |
| Table Design                   | End Table                                |
| Style Name                     | Farmhouse                                |
| Furniture Finish               | Black Wooden                             |
| Top Color                      | Black                                    |
| Number of Drawers              | 2 (one main, one with detachable holder) |
| Required Assembly              | Yes                                      |
| Indoor Outdoor Usage           | Indoor                                   |
| Tools Recommended For Assembly | Screwdriver                              |

## 9. WARRANTY AND SUPPORT

---

For warranty information, please refer to the documentation included with your purchase or contact WLIVE customer support directly. If you encounter any issues or have questions regarding your product, please reach out to the manufacturer's customer service team for assistance. Contact information can typically be found on the product packaging or the official WLIVE website.