

FOHERE XD-1838FB

FOHERE Standing Fan Model XD-1838FB User Manual

Model: **XD-1838FB** | Brand: **FOHERE**

1. INTRODUCTION

Thank you for choosing the FOHERE Standing Fan Model XD-1838FB. This manual provides essential information for the safe and efficient operation of your new fan. Please read it thoroughly before use and retain it for future reference.

The FOHERE Standing Fan is designed to provide powerful whole-room air circulation with a quiet DC motor. It features 12 speeds, 4 modes (Normal, Natural, Sleep), 120° horizontal and 90° vertical oscillation, adjustable height from 27 to 46 inches, a 12-hour timer, and an RGB light. It is suitable for various indoor environments including homes and offices.

Rapid Cooling
More Comfortable



Image 1.1: FOHERE Standing Fan providing rapid cooling in a living room. It features 85 ft max distance, 24.6 ft/s max speed, and 950 CFM max air volume.

2. SAFETY INSTRUCTIONS

- Always ensure the fan is placed on a stable, flat surface to prevent tipping.
- Do not insert fingers or any objects into the fan grille when it is operating.

- Keep the fan away from water or moist environments.
- Unplug the fan from the power outlet before cleaning or maintenance.
- Do not use the fan if the power cord or plug is damaged.
- This appliance is for indoor use only.

3. SETUP AND ASSEMBLY

The FOHERE Standing Fan is designed for easy assembly. Follow these general steps:

1. Carefully unpack all components from the packaging.
2. Attach the main fan unit to the adjustable stand. Ensure it clicks securely into place.
3. Connect the stand to the weighted base. The weighted base ensures stability.
4. Plug the power cord into a suitable electrical outlet.



Image 3.1: The fan's adjustable height feature allows it to be used as a floor fan, a desk fan, or a standing fan, adapting to different room setups like living rooms, bedrooms, and offices.

4. OPERATING INSTRUCTIONS

Your FOHERE Standing Fan can be operated using the touch controls on the unit or the included remote control.

4.1 Power On/Off

Press the **Power** button on the unit or remote to turn the fan on or off.

4.2 Speed Adjustment

The fan offers 12 precision speeds. Use the **+** and **-** buttons on the remote control to increase or decrease the fan speed. The current speed level will be displayed on the unit's LED screen.



Versatile, Multi-purpose

3 Wind Modes 12 Wind Speeds 12 Hours Timer

Image 4.1: The fan's control panel and remote show options for 3 wind modes, 12 wind speeds, and a 12-hour timer.

4.3 Wind Modes

Select from 3 distinct wind modes using the **Speed/Mode** button:

- **Normal Mode:** Provides a consistent airflow at your selected speed.
- **Natural Mode:** Simulates a natural breeze by varying fan speeds.
- **Sleep Mode:** Operates at a lower, quieter speed for undisturbed rest.

4.4 Oscillation

Activate the oscillation feature by pressing the **Swing** button. The fan supports 120° horizontal and 90° vertical oscillation for comprehensive air distribution.

Omni-directional Air Supply



Image 4.2: The fan provides omni-directional air supply with 120° horizontal and 90° vertical oscillation, ensuring air reaches every corner of the room.

4.5 Timer Function

Set the fan to automatically turn off after a specified period (up to 12 hours) using the **Timer/Light** button. Each press adjusts the timer in 1-hour increments.

4.6 RGB Light

The fan includes an RGB ambient light with 3 brightness levels. Press and hold the **Timer/Light** button to cycle through the light settings.



Image 4.3: The fan's RGB light creates a comfortable lighting atmosphere, controllable via the remote.

4.7 Smart Memory Function

The fan features a Smart Memory Function that recalls your last speed and mode settings after power off, eliminating the need to reconfigure settings each time it is turned on.

5. MAINTENANCE

Regular cleaning ensures optimal performance and longevity of your FOHERE Standing Fan.

- **Cleaning the Exterior:** Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Cleaning the Grille and Blades:** The fan features a detachable grille and blades for easy cleaning. Refer to the detailed instructions in the full user manual for safe removal and reattachment. Ensure the fan is unplugged before attempting to clean internal components.

6. TROUBLESHOOTING

If you encounter issues with your FOHERE Standing Fan, refer to the following common troubleshooting steps:

- **Fan does not turn on:** Ensure the power cord is securely plugged into a working electrical outlet. Check if the outlet has power.
- **No airflow or weak airflow:** Verify the fan speed setting. Ensure the grilles are not obstructed by dust or debris.
- **Unusual noise:** Check for any foreign objects caught in the fan blades. Ensure the fan is on a stable surface.
- **Remote control not working:** Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the fan's sensor.
- **Automatic shut-off after 24 hours:** This is a built-in safety feature. The fan will turn off after 24 hours of continuous operation and requires a manual restart.

For further assistance, please contact FOHERE customer support.

7. SPECIFICATIONS

Feature	Specification
Brand	FOHERE
Model Number	XD-1838FB
Electric Fan Design	Floor Fan / Pedestal Fan
Power Source	Corded Electric
Product Dimensions (D x W x H)	29.33"D x 15.75"W x 14.17"H
Adjustable Height	27" to 46"
Special Features	Air Circulation, Remote Control, 12H Timer, Oscillating (120° Horizontal, 90° Vertical), 3 Modes, 12 Speeds, RGB Lights
Number of Speeds	12
Wattage	45 watts

Feature	Specification
Air Flow Capacity	950 Cubic Feet Per Minute
Motor Type	Brushless DC
Noise Level	25dB (Ultra-Quiet)
Indoor/Outdoor Usage	Indoor
Control Method	Remote
Included Components	Pedestal Fan, Remote, User Manual, Stand

Powerful Airflow Circulation



Image 7.1: Key dimensions and features of the FOHERE Standing Fan, including its function as a pedestal fan, oscillating fan, and air circulator.

8. OFFICIAL PRODUCT VIDEOS

Video 8.1: This video demonstrates the FOHERE Oscillating Quiet Floor Fan for Bedroom with Remote Control, showcasing its features and quiet operation.

Video 8.2: This video provides an overview of the FOHERE Floor Fan, highlighting its design and functionality.

9. WARRANTY AND SUPPORT

FOHERE products are manufactured to high-quality standards. For warranty information, product registration, or technical support, please refer to the warranty card included with your purchase or visit the official FOHERE website. Please have your model number (XD-1838FB) ready when contacting support.

© 2026 FOHERE. All rights reserved.