

[Manuals.plus](#) /

› [ANXRE](#) /

› ANXRE 71-inch Phone Tripod and Selfie Light User Manual

ANXRE NT79

ANXRE 71-inch Phone Tripod and Selfie Light User Manual

Model: NT79 | Brand: ANXRE

INTRODUCTION

Thank you for choosing the ANXRE 71-inch Phone Tripod and Selfie Light. This comprehensive manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your new device. Please read this manual carefully before use to ensure optimal performance and longevity of the product.

PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- 1 x ANXRE 71-inch Phone Tripod / Selfie Stick
- 1 x Bluetooth Remote Control
- 1 x ANXRE Selfie Light with Soft Diffuser
- 1 x USB Charging Cable (for Selfie Light)
- 1 x User Manual (this document)




Image: Overview of the ANXRE 71-inch Phone Tripod, Selfie Light, and Bluetooth remote control.

PRODUCT OVERVIEW

Familiarize yourself with the main components of your ANXRE Phone Tripod and Selfie Light.

Phone Tripod / Selfie Stick

- **Extendable Pole:** Adjustable height from 16 inches to 71 inches.
- **Tripod Base:** Provides stability for stationary shots.
- **Phone Holder:** Securely holds smartphones up to 3.7 inches wide.
- **Universal Screw Mount:** Compatible with cameras, GoPro, and other accessories.
- **Cold Shoe Mount:** For attaching accessories like the selfie light or an external microphone.
- **Bluetooth Remote Control:** Detachable for wireless photo and video capture.



Image: The ANXRE Phone Tripod in its compact form with the detachable Bluetooth remote control.



Reliable Base for Steady Shots



Easy Attach
&Detach

Image: Close-up view of the tripod's stable base, the phone holder's maximum extension (3.7 inches), and the secure slot for the Bluetooth remote control.



GoPro



Camera



Ring Light



Universal Compatibility



Fill Light



Microphone

Image: Illustration of the tripod's universal compatibility, showing attachment options for GoPro, cameras, ring lights, fill lights, and microphones via the universal screw mount and cold shoe mount.

Selfie Light

- **96 LED Beads:** Provides bright and even illumination.
- **Soft Diffuser:** Reduces harsh shadows and softens light output.

- **Adjustable Brightness:** Stepless control for precise light intensity.
- **Adjustable Color Temperature:** Stepless control from 2500K (warm) to 9900K (cool).
- **Built-in Stand:** Allows for standalone use on desktops or other surfaces.
- **Front Clip:** Securely attaches to phones, iPads, or laptops.
- **Rechargeable Battery:** Integrated battery for portable use.

96 LED Beads & Soft Diffuser

Protects eyes from harsh lights and softens your photos




Image: The selfie light showcasing its 96 LED beads and the effect of the soft diffuser, demonstrating improved lighting for photos.

Versatile Design for Effortless Lighting

A dual-purpose phone clip and hidden stand
for selfies and video lighting

Front Clip

Phone, iPad, Laptop



Built-In Stand

Desktop, Computer, Thick Walls



Image: The selfie light's versatile design, illustrating its use with the front clip for phones/laptops and its built-in stand for desktop or monitor mounting.

SETUP INSTRUCTIONS

1. Assembling the Phone Tripod / Selfie Stick

1. **Unfold the Tripod Legs:** Hold the handle and gently pull the legs outwards until they lock into position, forming a stable tripod base.
2. **Extend the Pole:** Pull the top section of the pole upwards to extend it to your desired height. The pole can extend up to 71 inches.
3. **Adjust Phone Holder:** Open the phone holder clamp and insert your smartphone. Ensure it is securely gripped. The holder supports phones up to 3.7 inches wide.
4. **Attach Remote Control:** If not already attached, slide the Bluetooth remote control into its designated slot on the tripod handle.

71" Tripod for Higher Angles

Adjustable to 8-stage heights for flexible tripod shooting

16"-71"

13.5"



Image: The ANXRE Phone Tripod fully extended to 71 inches, demonstrating its adjustable height for various shooting angles.

2. Setting up the Selfie Light

1. **Charge the Light:** Before first use, charge the selfie light using the provided USB cable until the indicator light shows a full charge.
2. **Attach to Tripod (Optional):** Slide the selfie light onto the cold shoe mount located on the phone holder or the tripod's

universal screw mount adapter.

3. **Use with Front Clip:** For direct attachment to a phone, iPad, or laptop, use the integrated front clip.
4. **Use with Built-in Stand:** For standalone use, deploy the built-in stand on the back of the light.

3. Pairing the Bluetooth Remote Control

1. **Power On:** Press and hold the button on the remote control until the indicator light flashes, indicating it is in pairing mode.
2. **Enable Bluetooth:** On your smartphone, go to Bluetooth settings and enable Bluetooth.
3. **Connect:** Look for "ANXRE Remote" or a similar device name in the list of available devices and tap to connect. The indicator light on the remote will stop flashing and remain solid once paired.
4. **Test:** Open your phone's camera app and press the remote control button to take a photo or start/stop video recording.

OPERATING INSTRUCTIONS

1. Using the Phone Tripod / Selfie Stick

- **Tripod Mode:** Extend the legs and place on a flat, stable surface for hands-free shooting, video calls, or live streaming.
- **Selfie Stick Mode:** Collapse the legs and hold the handle to use as an extendable selfie stick for wider group photos or higher angle shots.
- **Camera/GoPro Mount:** Unscrew the phone holder to reveal the universal 1/4-inch screw mount for attaching other compatible cameras or accessories.






Image: Demonstrates the versatility of the ANXRE Phone Tripod, showing its use as a desktop tripod, a full-height tripod stand, in GoPro mode, and as a handheld selfie stick.

2. Using the Selfie Light

- **Power On/Off:** Press the power button on the side of the light to turn it on or off.
- **Adjust Brightness:** Use the brightness control dial/buttons to increase or decrease the light intensity.

- **Adjust Color Temperature:** Use the color temperature control dial/buttons to switch between warm (2500K), natural, and cool (9900K) lighting modes.

Stepless Control for Brightness and Color Temperature




White



Natural



Warm



2500K

9900K

Image: Illustrates the stepless control for brightness and color temperature on the ANXRE Selfie Light, showing examples of white (cool), natural, and warm lighting from 2500K to 9900K.

MAINTENANCE

- **Cleaning:** Wipe the tripod and selfie light with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the product in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the tripod is fully collapsed and the remote is securely stored.
- **Battery Care (Selfie Light):** For optimal battery life, charge the selfie light regularly, even if not in frequent use. Avoid fully discharging the battery for extended periods.

TROUBLESHOOTING

Issue	Possible Cause	Solution
Remote control not pairing.	Remote battery low; Bluetooth not enabled on phone; remote not in pairing mode; interference.	Ensure remote has power. Enable Bluetooth on your phone. Press and hold remote button until light flashes. Move closer to phone. Restart phone and remote.
Selfie light not turning on.	Battery discharged; power button not pressed correctly.	Charge the selfie light using the USB cable. Press and hold the power button firmly.
Tripod unstable.	Legs not fully extended/locked; uneven surface; excessive weight.	Ensure tripod legs are fully extended and locked. Place on a flat, stable surface. Do not exceed recommended weight capacity.

SPECIFICATIONS

Feature	Detail
Tripod Extension Height	16 inches to 71 inches (40.6 cm to 180.3 cm)
Phone Holder Max Width	3.7 inches (9.4 cm)
Universal Mount	1/4-inch screw mount
Selfie Light LED Count	96 LED beads
Selfie Light Color Temperature	2500K - 9900K (Stepless adjustment)
Selfie Light Brightness	Stepless adjustment
Remote Control Connectivity	Bluetooth

WARRANTY AND SUPPORT

ANXRE products come with a standard manufacturer's warranty. For specific warranty details, please refer to the warranty card included in your package or visit the official ANXRE website. If you encounter any issues or have questions regarding your product, please contact ANXRE customer support through the retailer where you purchased the item or via the contact information provided on the ANXRE brand store page on Amazon.

ANXRE Store Link: [Visit the ANXRE Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question