



blastpods

Generic Blastpods Wireless Earbuds User Manual

Model: blastpods

1. INTRODUCTION

This manual provides detailed instructions for the safe and efficient use of your Generic Blastpods Wireless Earbuds. Please read this manual thoroughly before using the product and retain it for future reference.



Image 1.1: Generic Blastpods Wireless Earbuds in their charging case. The earbuds are white with metallic accents, nestled securely in the open white charging case.

2. PACKAGE CONTENTS

Ensure all items are present in the package:

- Generic Blastpods Wireless Earbuds (Left and Right)
- Charging Case

- USB Type-C Charging Cable
- User Manual (this document)

3. SETUP

3.1 Initial Charging

Before first use, fully charge the earbuds and charging case.

1. Place the earbuds into the charging case.
2. Connect the provided USB Type-C cable to the charging port on the case and to a compatible USB power source.
3. The charging indicator will illuminate. A full charge typically takes approximately 1 hour.
4. Once fully charged, disconnect the cable. The charging case provides up to 60 hours of total playback time for the earbuds.



Image 3.1: Illustration of earbuds charging via a Type-C cable. This image demonstrates the fast charging capability, which applies to the Blastpods model.

The ASAP Fast Charge technology allows for quick power replenishment.

3.2 Bluetooth Pairing

1. Open the charging case. The earbuds will automatically enter pairing mode (indicated by flashing LED lights on the earbuds).
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for available Bluetooth devices and select "Blastpods" from the list.
4. Once connected, the LED indicators on the earbuds will stop flashing.
5. The earbuds will automatically reconnect to the last paired device when removed from the case, if Bluetooth is enabled on the device.

The Blastpods use Bluetooth 5.0 for stable connectivity up to 10 meters.

3.3 Wearing the Earbuds

Insert the earbuds into your ears and gently rotate them to find a comfortable and secure fit. The ergonomic design ensures comfort for extended wear.



Image 3.2: Close-up of the white Generic Blastpods Wireless Earbuds, showing their in-ear design.

4. OPERATING INSTRUCTIONS

4.1 Touch Controls

The Blastpods feature intuitive touch controls on each earbud. Specific functions may vary slightly by device, but common controls include:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.
- **Activate Voice Assistant:** Triple tap on either earbud.

4.2 Gaming Mode

For an optimized gaming experience, the Blastpods offer a low-latency gaming mode (50ms audio latency).

- **Activate Gaming Mode:** Refer to your device's Bluetooth settings or the product's quick start guide for specific activation gestures, as this may vary.



Image 4.1: Visual representation of earbuds in gaming mode, highlighting the 50ms low latency feature, applicable to the Blastpods model.

5. MAINTENANCE

5.1 Cleaning

Regular cleaning helps maintain optimal performance and hygiene.

- Wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, solvents, or aerosol sprays.
- Ensure charging contacts are free of dust and debris.

5.2 Water Resistance

The Blastpods are rated IPX5 water resistant, meaning they can withstand sweat and light rain. They are not designed for submersion in water.

- Do not intentionally submerge the earbuds in water.
- Dry the earbuds thoroughly before placing them back in the charging case if they become wet.



Image 5.1: Earbuds shown with water droplets, illustrating the IPX5 water resistance rating, which protects against sweat and light splashes.

6. TROUBLESHOOTING

If you encounter issues, try the following steps:

- **No Sound:**

- Ensure earbuds are charged.
- Check Bluetooth connection on your device.
- Adjust volume on both earbuds and your device.

- **Earbuds Not Pairing:**

- Ensure earbuds are in pairing mode (flashing lights).
- Turn off and on Bluetooth on your device.
- Forget "Blastpods" from your device's Bluetooth list and try pairing again.
- Ensure earbuds are close to your device (within 10 meters).

- **Charging Issues:**

- Verify the USB Type-C cable is securely connected.
- Try a different charging cable or power adapter.
- Ensure charging contacts on earbuds and case are clean.

7. SPECIFICATIONS

Feature	Detail
Model Name	blastpods (6IG-00001)
Connectivity Technology	Wireless (Bluetooth 5.0)
Bluetooth Range	10 Metres
Audio Driver Type	Dynamic Driver
Audio Driver Size	13.4 Millimetres
Noise Control	Passive Noise Cancellation
Sensitivity	98 dB
Headphones Jack	Type-C
Control Type	Touch Control, Voice
Charging Time	1 Hour
Carrying Case Battery Life	60 Hours (total playback)
Carrying Case Battery Capacity	400 mAh
Water Resistance Level	IPX5 (Water Resistant)
Audio Latency	50 Milliseconds (Gaming Mode)
Material	Plastic, Silicone
Item Weight	100 Grams
Dimensions (LxWxH)	5.2 x 6 x 4.5 cm
Color	White



Image 7.1: Illustration emphasizing the 13.4mm dynamic driver for enhanced audio quality, a feature of the Blastpods earbuds.

8. WARRANTY AND SUPPORT

Your Generic Blastpods Wireless Earbuds are designed for durability and performance. For any concerns, please refer to the following:

- **Replacement Policy:** The product is eligible for a 10-day replacement policy from the date of purchase.
- **Warranty:** Please refer to the specific warranty policy provided at the time of purchase or contact the seller for details.
- **Manufacturer:** infinity collection hub
- **Customer Support:** For further assistance, please contact your point of purchase or visit the manufacturer's support channels.