

GOBOULT Bassbox X400

GOBOULT X400 5.1 Channel Bluetooth Soundbar with BoomX Subwoofer

Model: Bassbox X400

1. IMPORTANT SAFETY INSTRUCTIONS

- Read these instructions thoroughly before operating the device.
- Keep these instructions for future reference.
- Heed all warnings on the product and in the operating instructions.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with a dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- GOBOULT X400 Soundbar
- BoomX Subwoofer
- Remote Control
- User Manual (this document)
- Warranty Card
- Power Adapter/Cable
- Auxiliary Cable

400WATT

Unparalleled
power

**Dual
Drivers**
+ Subwoofer



5.1
Channel
Sound

**EQ
modes**

music, movie, news



**Master
remote
control**

Multi-compatibility



USB




AUX



HD
(ARC)



Bluetooth
5.3



**LED
Display**

Image: Overview of the GOBOULT X400 system components and key features.

3. SETUP GUIDE

3.1 Placement

For optimal audio performance, place the soundbar centrally below your television. Position the BoomX subwoofer on the floor near the soundbar, ensuring it has adequate space for bass dispersion. The two satellite speakers should be placed to the left and right of your listening area for a true 5.1 surround sound experience.

400 watt rated output

Turn up the volume;
feel the energy.



Room-filling audio

Image: Recommended placement of the soundbar and subwoofer in a home environment.

3.2 Connecting the Subwoofer

Connect the wired BoomX subwoofer to the 'SUBWOOFER OUT' port on the soundbar using the provided cable.

3.3 Power Connection

Connect the power cable to the soundbar's power input and then plug it into a wall outlet. Ensure the power switch on the soundbar (if present) is in the 'ON' position.

3.4 Audio Input Connections

The GOBOULT X400 offers multiple connectivity options:

- **HDMI ARC:** For the best audio quality and control, connect an HDMI cable from your TV's HDMI ARC port to the soundbar's HDMI ARC port. This allows your TV remote to control the soundbar's volume.
- **Optical:** Connect an optical cable from your TV's optical output to the soundbar's OPTICAL input.
- **AUX:** Use a 3.5mm auxiliary cable to connect devices with an AUX output to the soundbar's AUX input.

- **USB:** Insert a USB drive into the USB port to play audio files directly.



Image: Detailed view of the soundbar's input ports for various audio sources.

3.5 5.1 Channel Surround Sound Configuration

The X400 system includes a soundbar, a subwoofer, and two satellite speakers to deliver a 5.1 channel surround sound experience. Ensure the satellite speakers are connected to the soundbar and positioned appropriately to create an immersive audio field around the listener.

5.1 Channel Surround Sound)))

1 Subwoofer



2 Satellites



The Ultimate
Cinematic Experience

Image: Visual guide for setting up the 5.1 channel surround sound system.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

Press the **Power** button on the remote control or the soundbar to turn the unit on or off.

4.2 Input Source Selection

Press the **Input** button on the remote control to cycle through available input sources: Bluetooth, HDMI ARC, Optical, AUX, USB. The selected input will be displayed on the soundbar's LED panel.

4.3 Volume Control

Use the **VOL+** and **VOL-** buttons on the remote control or the soundbar to adjust the volume level.

4.4 Bluetooth Pairing

1. Select Bluetooth input mode on the soundbar. The LED display will show "BT" and flash, indicating it's in

pairing mode.

2. On your mobile device, enable Bluetooth and search for available devices.
3. Select "GOBOULT X400" from the list. Once connected, the LED display will show a steady "BT".

4.5 EQ Modes

The GOBOULT X400 features multiple equalizer (EQ) modes to optimize your listening experience. Press the dedicated **Movie**, **Music**, or **News** buttons on the remote control to switch between modes.

4.6 Remote Control Functions




Image: Layout and functions of the GOBOULT X400 remote control.

- **Power:** Turns the soundbar on or off.
- **Mute:** Mutes or unmutes the sound.
- **Input:** Selects the audio input source.
- **VOL+/VOL-:** Adjusts the master volume.
- **Play/Pause:** Controls media playback (Bluetooth/USB modes).

- **Previous/Next:** Skips tracks (Bluetooth/USB modes).
- **EQ Modes (Movie, Music, News):** Selects preset sound profiles.
- **PAIR:** Initiates Bluetooth pairing.
- **RESET:** Resets sound settings to default.
- **TREB+/TREB-:** Adjusts treble levels.
- **BASS+/BASS-:** Adjusts bass levels.

5. MAINTENANCE

To ensure the longevity and optimal performance of your GOBOULT X400 soundbar system, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the soundbar and subwoofer. Do not use liquid cleaners, aerosols, or abrasive materials, as they may damage the finish or internal components.
- **Ventilation:** Ensure that the ventilation openings on the soundbar and subwoofer are not blocked. Proper airflow prevents overheating.
- **Storage:** If storing the unit for an extended period, unplug it from the power outlet and store it in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Exposure:** While the product is water-resistant, avoid direct exposure to water or high humidity to prevent damage.

6. TROUBLESHOOTING

If you encounter issues with your GOBOULT X400, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power	Power cable not connected; Power outlet not active	Ensure power cable is securely connected to the soundbar and a working power outlet.
No sound	Incorrect input source; Volume too low; Mute activated; Incorrect cable connection	Select the correct input source. Increase volume. Deactivate mute. Check audio cable connections.
Bluetooth pairing fails	Soundbar not in pairing mode; Device too far; Interference	Ensure soundbar is in Bluetooth pairing mode. Move device closer. Clear previous pairings on your device.
Remote control not working	Batteries depleted; Obstruction; Remote out of range	Replace remote control batteries. Remove any obstructions between remote and soundbar. Ensure remote is within operating range.
Subwoofer not producing bass	Subwoofer cable loose; Bass level set too low	Check the connection of the subwoofer cable to the soundbar. Increase bass level using the remote control.

7. SPECIFICATIONS



Image: Internal view of the BoomX Dual Driver, highlighting its design for enhanced bass response.

Feature	Specification
Brand	GOBOULT
Model Name	Bassbox X400
Speaker Maximum Output Power	400 Watts
Number of Audio Channels	5.1
Connectivity Technology	Auxiliary, Bluetooth, USB, HDMI ARC, Optical
Bluetooth Version	5.3
Bluetooth Range	10 Metres

Feature	Specification
Audio Output Mode	Surround
Speaker Type	Soundbar with Wired Subwoofer
Control Method	Remote
Product Features	Bass Boost, LED Light, USB Port, Water Resistant
Power Source	Corded Electric
Item Dimensions (D x W x H)	8D x 9W x 7.5H Centimeters (Soundbar)
Item Weight	7.6 Kilograms

8. WARRANTY AND SUPPORT

8.1 Warranty Information

The GOBOULT X400 Soundbar System comes with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers manufacturing defects and ensures reliable operation under normal use. Please retain your purchase receipt and the warranty card for any warranty claims.

8.2 Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact GOBOULT customer support. Refer to the contact information provided on your warranty card or visit the official GOBOULT website for support details.