

[Manuals.plus](#) /

› [ROBUD](#) /

› ROBUD Wooden Dollhouse Model WDH16 Instruction Manual

ROBUD WDH16

ROBUD Wooden Dollhouse Model WDH16 Instruction Manual

Your guide to assembly, operation, and care for your ROBUD Dollhouse.

IMPORTANT SAFETY INFORMATION

WARNING: CHOKING HAZARD – Small parts. Not for children under 3 years.

- This toy is intended to be assembled by an adult.
- Keep away from fire and direct heat sources.
- Regularly inspect all parts for damage or loose connections. Discontinue use if any damage is found.
- Ensure all screws and fasteners are securely tightened before use.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly. The ROBUD Wooden Dollhouse includes the main structure and a 29-piece furniture set.

- Wooden Dollhouse Structure (various panels and supports)
- 29-piece Furniture Set (e.g., bed, sofa, kitchen counter, bathroom fixtures, outdoor lounge chair)
- Assembly Hardware (screws, connectors)
- Instruction Manual (this document)



Figure 1: The complete 29-piece furniture set, including items for the bedroom, living room, kitchen, bathroom, and outdoor areas.

ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. Adult supervision is required.

Step 1: Unpacking and Preparation

1. Carefully remove all components from the packaging.
2. Lay out all wooden panels and hardware on a clean, flat surface.
3. Identify each part using the provided diagrams in the separate assembly guide (if applicable).

Step 2: Constructing the Main Structure

1. Begin by attaching the base panels to the side walls using the designated screws.
2. Proceed to build each floor, ensuring all connections are secure.
3. Install the roof panels last, aligning them correctly with the top structure.

Step 3: Installing the Elevator and Garage

1. Attach the external elevator mechanism to the side of the dollhouse as indicated in the assembly diagrams.
2. Ensure the elevator moves smoothly up and down.
3. Install the garage door, verifying it slides open and closed without obstruction.

Step 4: Arranging Furniture and Accessories

1. Place the 29-piece furniture set in the appropriate rooms (bedroom, bathroom, living room, kitchen, outdoor pool area).
2. Customize the dollhouse interior to your preference.



Figure 2: The ROBUD Wooden Dollhouse fully assembled and furnished.

Your browser does not support the video tag.

Video 1: An overview of the ROBUD Dollhouse features, including room layouts and interactive elements. This video demonstrates the assembled product and its various play areas.

OPERATING THE DOLLHOUSE FEATURES

The ROBUD Dollhouse is designed for interactive play with several functional elements.

Working Elevator

The external elevator allows dolls to move between floors. Gently pull the cord or knob to raise and lower the elevator car.

Convenient External Elevator

Seamlessly move dolls between floors with ease ✨





Figure 3: Detail of the external elevator mechanism, showing how it operates.

Garage Door

The garage features a sliding door. Slide the door up to open and down to close, allowing for vehicle play.

Room Features

Explore the six distinct rooms: bedroom, bathroom, living room, kitchen, garage, and swimming pool area. Each room is designed with specific furniture pieces to enhance imaginative play.



 **Pavilion&Outdoor Pool**



 **Living Room**



 **Open Kitchen**



 **Garage**



 **Bathroom**



 **Bedroom**

Figure 4: Detailed views of the various rooms and features within the dollhouse.

MAINTENANCE AND CARE

Proper care will ensure the longevity of your ROBUD Dollhouse.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals.
- **Storage:** Store the dollhouse in a dry environment away from extreme temperatures and direct sunlight to prevent warping or fading.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.
- **Wood Care:** As this product is made of natural wood, minor variations in grain and color are normal. Avoid prolonged exposure to moisture.

TROUBLESHOOTING

Refer to this section for solutions to common issues.

Issue	Possible Cause	Solution
Elevator not moving smoothly	Rope tangled or mechanism obstructed.	Check for any obstructions in the elevator shaft. Untangle the rope if necessary. Ensure the mechanism is clean.
Loose parts or wobbly structure	Screws or connectors have loosened over time.	Carefully re-tighten all visible screws and check connections. Do not overtighten.
Missing furniture piece	Item may have been misplaced or not included in original packaging.	Refer to the package contents list. If genuinely missing, contact customer support.

SPECIFICATIONS

Key product details for the ROBUD Wooden Dollhouse Model WDH16.

- **Model Number:** WDH16
- **Product Dimensions:** 31.5 x 11.6 x 27.4 inches (80 x 29.5 x 69.5 cm)
- **Item Weight:** 18.3 pounds (8.3 kg)
- **Material:** Wood
- **Recommended Age:** 3 years and up
- **Number of Rooms:** 6
- **Furniture Pieces:** 29

LIMITED SPACE - INFINITE FUN



Natural



3+



Safe




Figure 5: Product dimensions of the ROBUD Wooden Dollhouse.

WARRANTY AND SUPPORT

ROBUD products are manufactured with quality and customer satisfaction in mind.

For warranty information, replacement parts, or technical support, please contact ROBUD customer service through the retailer where the product was purchased or visit the official ROBUD website. Please have your model number (WDH16) and purchase date available when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question