

DORESSshop D-GY019

DORESSshop 8-Color RGB LED Night Lights Instruction Manual

Model: D-GY019

1. PRODUCT OVERVIEW

Thank you for choosing the DORESSshop 8-Color RGB LED Night Lights. These plug-in night lights are designed to provide ambient illumination with customizable color options and an automatic dusk-to-dawn sensor for convenience. They are ideal for various indoor spaces such as bedrooms, bathrooms, hallways, and children's rooms.

Key Features:

- **3 Lighting Modes:** Choose between solid color, 3000K warm white light, or an 8-color cycling mode.
- **Dusk-to-Dawn Sensor:** Automatically turns the light on at dusk and off at dawn, optimizing energy use.
- **Compact and Stylish Design:** Features a unique 'bubble' acrylic element that diffuses light softly.
- **Energy Efficient:** Utilizes LED technology with a low 0.5W wattage.

2. SETUP INSTRUCTIONS

1. **Unpack:** Carefully remove the night light from its packaging.
2. **Select Location:** Choose an indoor wall outlet in the desired area. Ensure the location allows the dusk-to-dawn sensor to function correctly (not obstructed by furniture or curtains, and not in direct light during the day).
3. **Plug In:** Insert the night light directly into a standard 110-130V wall outlet. The light will automatically turn on if the ambient light is low enough.
4. **Multiple Units:** If using multiple night lights, maintain a distance of more than 1 meter (approximately 3.3 feet) between them to prevent sensor interference.



COMPACT & SLICK DESIGN



Image: The night light features a dusk-to-dawn sensor, automatically activating in darkness and deactivating in sufficient light.

3. OPERATING INSTRUCTIONS

The DORESSshop night light is controlled by a single button located on the front of the unit.

1. **Power On/Off:** The night light will automatically turn on at dusk and off at dawn due to its integrated sensor. To manually turn off the light, long-press the button for approximately 2 seconds.

2. **Change Lighting Mode:** Short-press the button to cycle through the three available lighting modes:

- **Mode 1: Solid Color:** Repeatedly short-press the button to select one of the 8 vibrant colors (red, cyan, purple, green, blue, yellow, pink, orange).
- **Mode 2: 3000K Warm White:** Provides a soft, warm white light.
- **Mode 3: Auto Color Changing:** The light will automatically cycle through all 8 colors.



Image: Illustration of the three lighting modes and how to switch between them using the control button.



AUTOMATIC ON/OFF

Dusk to Dawn Sensor



Only Activates in Darkness



Image: Examples of the 8 vibrant colors available in solid color mode.

4. MAINTENANCE

To ensure optimal performance and longevity of your DOREShop night light, follow these simple maintenance guidelines:

- **Cleaning:** Disconnect the night light from the power outlet before cleaning. Use a soft, dry cloth to wipe the

surface. Do not use abrasive cleaners, solvents, or immerse the unit in water.

- **Storage:** If storing the night light for an extended period, unplug it and keep it in a cool, dry place away from direct sunlight.
- **Avoid Obstructions:** Ensure the light sensor is not covered or obstructed, as this will affect its automatic operation.

5. TROUBLESHOOTING

If you encounter any issues with your DORESSshop night light, please refer to the following common troubleshooting steps:

- **Light does not turn on in darkness:**
 - Check if the night light is securely plugged into a working outlet.
 - Ensure the light sensor (small circle on the front) is not obstructed or covered.
 - Verify that the ambient light is sufficiently low for the sensor to activate. Test in a completely dark room.
- **Light does not turn off during the day:**
 - Ensure the light sensor is not in a shaded area or obstructed from natural light.
 - Confirm there are no other light sources (e.g., another night light, lamp) too close to the sensor, causing it to detect darkness.
- **Colors are not changing or stuck on one color:**
 - Short-press the control button to cycle through the modes until the desired color-changing mode is active.
 - If stuck on a solid color, repeatedly short-press the button to select a different color or the auto-cycle mode.

6. SPECIFICATIONS

Feature	Detail
Brand	DORESSshop
Model Number	D-GY019
Type	LED Night Light
Base Type	Plug-in
Wattage	0.5W
Color Temperature (Warm White)	3000K
Special Features	3 Lighting Modes, Color Changing (8 colors), Cordless, Dusk-to-Dawn Sensor
Material	Plastic


Input Voltage	110-130V
Product Dimensions	2.36"D x 2.17"W x 3.43"H (60mm D x 55mm W x 87mm H)
Item Weight	3.52 ounces
Indoor/Outdoor Usage	Indoor




DIFFERENT SCENARIOS



Bedroom



Kitchen



Bathroom

Image: Detailed dimensions and design elements of the night light.

7. WARRANTY AND SUPPORT

For any questions, concerns, or warranty inquiries regarding your DOREShop night lights, please contact DOREShop customer support through the retailer's platform where the product was purchased. Please retain your proof of purchase for any warranty claims.

We are committed to providing quality products and support.

© 2025 DOREShop. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question