
[Manuals.plus](#) /

› [Xiaomi](#) /

› Xiaomi Redmi Pad 2 Smart Pen User Manual

Xiaomi Redmi Pad 2 Smart Pen

Xiaomi Redmi Pad 2 Smart Pen User Manual

Model: Redmi Pad 2 Smart Pen

INTRODUCTION

The Xiaomi Redmi Pad 2 Smart Pen is designed to enhance your tablet experience with precise input and versatile functionality. This manual provides essential information for the setup, operation, and maintenance of your smart pen.

For optimal performance, ensure your Xiaomi Redmi Pad SE tablet is updated to Android 12.0 or a newer version.

PRODUCT FEATURES

本物のペンのような滑らかな書き心地

ミリ秒レベルの

超低遅延

10g

筆圧

4096段階の

筆圧感度

12時間

連続使用時間



Image: The Xiaomi Redmi Pad 2 Smart Pen, highlighting its sleek design and comfortable grip.

Smooth Writing Experience

The pen features an ergonomic grip and a responsive tip, designed to provide a smooth writing experience akin to using a traditional pen.

超低遅延によるシームレスな書き心地

ミリ秒単位の超低遅延と10gの筆圧により、
1つ1つの小さなストロークや筆圧変化に正確に反応。
あなたの創造性をスクリーンに描き出すことができます。



Image: The Smart Pen in use, demonstrating its ability to draw smooth, continuous lines on a tablet display.

Ultra-Low Latency and Pressure Sensitivity

Experience seamless writing with ultra-low latency, measured in milliseconds, and a 10g activation force. The pen accurately responds to every small stroke and pressure variation with 4096 levels of pressure sensitivity, allowing precise expression of your creativity on screen.

Xiaomi独自のスムーズ・ アルゴリズムとデュアルエンドの最適化。

240Hz

タッチサンプリングレート

120Hz

書き込み時の画面リフレッシュレート





Image: A visual representation comparing the writing experience with and without Xiaomi's optimized prediction algorithm, highlighting reduced latency.

Optimized Algorithm and Dual-End Design

Utilizing Xiaomi's proprietary smooth algorithm and dual-end optimization, the pen achieves a 240Hz touch sampling rate and a 120Hz screen refresh rate during writing, ensuring highly responsive interaction.

多機能ショートカットキー



Image: A diagram detailing the functions of the multi-functional shortcut keys on the pen, including opening Mi Canvas, taking screenshots, and scrolling.

Multi-functional Shortcut Keys

The pen includes multi-functional shortcut keys for enhanced productivity:

- **Writing Button (Long Press + Touch Display):** Opens Mi Canvas for quick notes or drawings.
- **Screenshot Button (Long Press + Touch Display):** Captures a quick screenshot of the current screen.
- **Writing or Screenshot Button (Single Tap):** Scrolls documents or articles.

スクリーンオフで書く インスピレーションを瞬時に捉える



Image: The Smart Pen being used to activate a full-screen canvas on a tablet that was previously off, demonstrating the screen-off memo feature.

Write with Screen Off

Capture inspiration instantly even when the screen is off. A simple tap on the display with the pen tip will activate the screen and open a full-screen canvas, ready for your notes or sketches.

Drawing App Compatibility

The pen is compatible with various drawing applications, acting as an efficient tablet partner. It features proprietary algorithms for single-stroke drawing and text recognition capabilities.

SETUP

Compatibility

The Xiaomi Redmi Pad 2 Smart Pen is designed for use with the Xiaomi Redmi Pad SE. Ensure your tablet is updated to Android 12.0 or higher for optimal compatibility.

Initial Connection

The pen typically connects automatically to compatible Xiaomi tablets. If it does not connect automatically, navigate to your tablet's Bluetooth settings and select 'Redmi Smart Pen' to pair.

Charging

Ensure the pen is charged before first use. A full charge provides approximately 12 hours of continuous use. Refer to your tablet's manual or Xiaomi's official support for specific charging methods.

OPERATING INSTRUCTIONS

Writing and Drawing

Simply touch the pen tip to the screen of your compatible Xiaomi tablet to begin writing or drawing. The pen's 4096 levels of pressure sensitivity allow for varied line thickness and shading based on your input.

Using Shortcut Key Functions

- **Open Mi Canvas:** Long-press the writing button on the pen, then touch the tablet display.
- **Take Screenshot:** Long-press the screenshot button on the pen, then touch the tablet display.
- **Scroll Documents/Articles:** Tap either the writing or screenshot button once.

Screen-Off Memo

When the tablet screen is off, tap the display with the pen tip. The screen will activate, and a full-screen canvas will appear, allowing you to quickly jot down notes or ideas.

MAINTENANCE

Cleaning

Use a soft, dry cloth to clean the pen's body. Do not use abrasive cleaners, solvents, or harsh chemicals. Keep the pen tip free from dust and debris.

Storage

Store the pen in a safe place to prevent damage. Avoid exposing the pen to extreme temperatures, high humidity, or direct sunlight. Keep it away from strong magnetic fields.

Tip Replacement

If the pen tip becomes worn or damaged, it may affect performance. Replacement tips may be available from

Xiaomi's official support channels. Follow the instructions provided with replacement tips for proper installation.

TROUBLESHOOTING

Pen Not Connecting

- Ensure the pen is sufficiently charged.
- Verify that Bluetooth is enabled on your Xiaomi Redmi Pad SE.
- Attempt to re-pair the pen via your tablet's Bluetooth settings.
- Restart both the pen (if applicable) and the tablet.

Inaccurate or Unresponsive Writing

- Check if the pen tip is clean and undamaged.
- Ensure the tablet screen is clean and free of smudges.
- Confirm the pen is fully charged.
- If issues persist, consider replacing the pen tip.

Battery Life Issues

- Ensure the pen is fully charged before each use.
- Close unnecessary applications on your tablet that might interfere with pen performance or battery consumption.

SPECIFICATIONS

Brand	Xiaomi
Model Name	Redmi Pad 2 Smart Pen
Model Number	6932554444136
Color	White
Pressure Sensitivity	4096 levels
Activation Force	10g
Touch Sampling Rate	240Hz
Screen Refresh Rate (Writing)	120Hz
Battery Type	1 AAAA battery (included)
Battery Life	Approx. 12 hours continuous use
Compatible Tablet Model	Xiaomi Redmi Pad SE

Minimum OS Version	Android 12.0
Product Weight	0.05 kg
Product Dimensions (LxWxH)	10 x 15 x 15 cm
Country of Origin	China

WARRANTY AND SUPPORT

The Xiaomi Redmi Pad 2 Smart Pen comes with a 1-year manufacturer's warranty. For warranty claims, technical support, or to purchase replacement parts, please contact Xiaomi customer service or visit their official website. Keep your proof of purchase for warranty validation.

For the most up-to-date support information, please visit the official Xiaomi support page:mi.com/global/support