

[Manuals.plus](#) /

› [SoarFlash](#) /

› SoarFlash Twin Over Twin House Bunk Bed Instruction Manual

SoarFlash Twin Over Twin House Bunk Bed

SoarFlash Twin Over Twin House Bunk Bed Instruction Manual

Model: Twin Over Twin House Bunk Bed | Brand: SoarFlash

1. INTRODUCTION AND OVERVIEW

Thank you for choosing the SoarFlash Twin Over Twin House Bunk Bed. This manual provides essential information for the safe assembly, proper use, and maintenance of your new bunk bed. Please read all instructions carefully before assembly and retain this manual for future reference.



Image 1.1: The SoarFlash Twin Over Twin House Bunk Bed, featuring a house-frame design and a low bunk for easy access.

2. SAFETY INFORMATION

Your safety and the safety of others are paramount. Adhere to the following guidelines to prevent injury or damage.

- Always use the ladder carefully to avoid tripping. Ensure children understand how to use the bed safely.
- Never climb on the guardrails. Guardrails are designed to prevent falls from the upper bunk, not for climbing.
- Follow the assembly instructions closely to prevent instability or collapse. Ensure all connections are securely fastened.
- Regularly check all bolts and screws to ensure they remain tight. Re-tighten as necessary.
- The top bunk is not suitable for children under six years of age.
- Ensure the mattress used on both bunks is of the correct size and thickness to maintain adequate guardrail height.



Image 2.1: Detailed view of the thoughtful guardrail design and intimate low-height design, highlighting safety features.

3. PRODUCT SPECIFICATIONS

Key specifications for the SoarFlash Twin Over Twin House Bunk Bed:

Feature	Detail
Brand	SoarFlash
Model	Twin Over Twin House Bunk Bed
Product Dimensions (L x W x H)	77.3" x 41.6" x 70.8"
Materials	High-quality Pine Wood and MDF
Item Weight	65.1 pounds
Guardrail Height (Upper Bunk)	14 inches

Feature	Detail
Ladder Width	11.8 inches
Color	White




Image 3.1: Dimensional drawing of the bunk bed, including length, width, height, and internal measurements.

4. ASSEMBLY INSTRUCTIONS

The SoarFlash Twin Over Twin House Bunk Bed is designed for easy assembly. An illustrated manual is included with your package, detailing each component and step. Please ensure you have all parts before beginning assembly.

Required Tools (Not Included):

- Phillips head screwdriver

- Allen wrench (often included with hardware)
- Rubber mallet (optional, for gentle tapping)

Assembly Steps:

1. **Unpack and Identify Components:** Carefully unpack all parts and hardware. Refer to the included parts list in your package to identify each component.
2. **Assemble Bed Ends:** Attach the side rails to the headboards and footboards for both the upper and lower bunks, following the specific instructions in your manual.
3. **Install Slats:** Securely place and fasten the bed slats onto the support rails for both bunks. Ensure even spacing and firm attachment.
4. **Attach Ladder:** Mount the widened and lengthened ladder to the designated side of the bunk bed, ensuring it is stable and securely fastened.
5. **Install Guardrails:** Attach the 14-inch high guardrails to the upper bunk. Verify that they are firmly in place to prevent falls.
6. **Final Checks:** Once assembled, double-check all bolts, screws, and connections to ensure they are tight and secure.



Image 4.1: Detailed views illustrating the sturdy staircase, the low bunk design for safety, and the stable solid wood components used

5. USAGE GUIDELINES

To ensure the longevity and safe use of your SoarFlash bunk bed, please observe the following:

- **Weight Capacity:** Adhere to the maximum weight capacity specified in your detailed assembly manual for both the upper and lower bunks.
- **Mattress Requirements:** Use only mattresses that comply with the recommended dimensions and thickness to ensure the effectiveness of the guardrails.
- **Ladder Use:** Always use the ladder when accessing the upper bunk. Do not jump onto or off the bed.
- **Decoration:** The house-frame design allows for versatile decoration. You can personalize the bed with small light bulbs, ribbons, or mosquito nets. Ensure any decorations are safely secured and do not pose a choking or entanglement hazard.



Image 5.1: Examples demonstrating how to personalize and decorate the house-frame bunk bed with various elements.

6. MAINTENANCE

Proper maintenance will help preserve the quality and appearance of your bunk bed.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Regular Inspection:** Periodically inspect all structural components, including the frame, ladder, and guardrails, for any signs of wear, damage, or loose connections.
- **Tighten Hardware:** Re-tighten all bolts and screws every few months, or as needed, to maintain structural integrity.
- **Avoid Moisture:** Protect the bed from excessive moisture and direct sunlight to prevent warping or fading of the wood.

7. TROUBLESHOOTING

If you encounter any issues with your bunk bed, refer to the following common solutions:

- **Squeaking Noises:** Squeaking often indicates loose hardware. Re-tighten all bolts and screws, especially those connecting the main frame components.
- **Wobbly Frame:** A wobbly frame is typically due to incomplete or uneven tightening of assembly hardware. Ensure all connections are fully tightened and the bed is on a level surface.
- **Damaged Parts:** If any part is damaged or missing upon arrival, do not proceed with assembly. Contact customer support for replacement parts.

8. WARRANTY AND SUPPORT

For warranty information, replacement parts, or any other support inquiries, please refer to the contact details provided with your purchase documentation or visit the official SoarFlash website. Ensure you have your purchase receipt and model information available when contacting support.