

[manuals.plus](#) /› [weselon](#) /› [Weselon 41-78 inch Extendable Dining Room Table User Manual](#)**weselon B0F9PBYJTH**

Weselon 41-78 inch Extendable Dining Room Table User Manual

Model: B0F9PBYJTH | Brand: weselon

1. INTRODUCTION

Thank you for choosing the Weselon 41-78 inch Extendable Dining Room Table. This versatile and stylish table is designed to adapt to your needs, transforming from a compact round table for intimate settings to a spacious oval table for larger gatherings. Its modern design with a fluted base adds a touch of elegance to any dining space.

This manual provides essential information for the proper assembly, operation, maintenance, and troubleshooting of your new dining table. Please read it thoroughly before beginning assembly or use.



Image: The Weselon Extendable Dining Table shown in its fully extended oval configuration, featuring a sleek black finish and fluted base design.

2. IMPORTANT SAFETY INFORMATION

Please observe the following safety precautions to ensure safe use and longevity of your dining table:

- **Assembly:** Always assemble the table according to the provided instructions.
- **Weight Limit:** Do not exceed the maximum weight recommendation of 130 pounds.
- **Stability:** Ensure the table is properly anchored to the floor to prevent tipping.
- **Heat Sources:** Keep the table away from heat sources.
- **Heavy Objects:** Do not place excessively heavy objects on the tabletop to avoid damage or injury.

3. PACKAGE CONTENTS

Before beginning assembly, please verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Tabletop Sections (Main and Extension Leaf)
- Fluted Base Components
- Extension Mechanism (Rails, Locks)
- Hardware Pack (Screws, Bolts, Allen Wrench, etc.)
- Assembly Guide

4. SETUP AND ASSEMBLY

Assembly of the Weselon Extendable Dining Table is designed to be straightforward. It is recommended to have two people for assembly to ensure stability and ease of handling larger components. Please follow the included Assembly Guide for detailed, step-by-step instructions.

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a soft, clean surface to prevent scratches. Identify each part using the labels and the parts list in the Assembly Guide.
2. **Assemble Base:** Follow the instructions to assemble the fluted base components. Ensure all connections are secure.
3. **Attach Extension Mechanism:** Securely attach the extension rails and locking mechanisms to the base and main tabletop sections as indicated in the guide.
4. **Attach Tabletop Sections:** Carefully align and attach the main tabletop sections to the assembled base.
5. **Final Checks:** Once assembled, ensure all screws and fasteners are tightened. Do not overtighten.

Note: While the table is designed for easy assembly, some users have noted that diagrams in the printed guide can be small. Pay close attention to the orientation of parts and the correct screw types for each step. If you encounter any difficulties, refer to the troubleshooting section or contact customer support.

5. OPERATING INSTRUCTIONS: EXTENDING AND RETRACTING THE TABLE

Your Weselon dining table features a convenient extendable design, allowing you to easily adjust its length to accommodate 4 to 8 people. The table can transition between a compact round shape (41.73 inches) and an extended oval shape (78.74 inches) by utilizing the removable extension leaf.

To Extend the Table:

1. **Release Latches:** Locate and loosen the latches underneath the tabletop. These secure the two halves of the table.
2. **Pull Apart:** Gently slide the two table ends outward. The smooth track mechanism will allow them to separate, revealing the space for the extension leaf.
3. **Insert Extension Leaf:** Carefully place the extension leaf into the gap created between the two table halves. Ensure it is properly seated and aligned.
4. **Push Inward:** Gently push the table ends back together until they meet the extension leaf, creating a seamless oval surface.
5. **Lock Latches:** Fasten the latches underneath the tabletop to secure the extended configuration.

To Retract the Table:

- Release Latches:** Loosen the latches underneath the tabletop.
- Pull Apart:** Gently slide the two table ends outward to create a gap.
- Remove Extension Leaf:** Carefully lift and remove the extension leaf. Store it safely to prevent damage.
- Push Inward:** Gently push the two table ends back together until they meet, forming the compact round table.
- Lock Latches:** Fasten the latches underneath the tabletop to secure the compact configuration.



Image: Visual guide illustrating the five-step process for extending the dining table, highlighting the smooth sliding mechanism and locking latches.



Waterproof



Anti-Scratch



Wear Resistant



Easy to Clean



Image: The dining table shown in its three adjustable lengths: compact (round), medium (oval with one leaf), and fully extended (oval with two leaves), demonstrating its versatility.

Official Product Video:

Your browser does not support the video tag.

Video: An official demonstration video from Weselon Furniture showcasing the extendable functionality of the dining room table, transitioning between its compact and extended forms.

6. CARE AND MAINTENANCE

To keep your Weselon dining table in excellent condition, follow these simple care guidelines:

- **Cleaning:** The table features a resin-coated, water-resistant surface. For daily cleaning, simply wipe with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Spills:** Wipe up spills immediately to prevent staining, especially for liquids that are not water.
- **Protection:** Use placemats or coasters to protect the tabletop from hot dishes, sharp objects, and excessive moisture.

- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration over time.
- **Moving:** When moving the table, lift it rather than dragging it to prevent damage to the legs and floor.



Image: Visual representation of the table's durable surface properties: waterproof, anti-scratch, wear-resistant, and easy to clean.

7. TROUBLESHOOTING

If you encounter any issues with your Weselon dining table, please refer to the common problems and solutions below:


Problem	Possible Cause	Solution
Table is wobbly.	Loose fasteners; uneven floor; improper assembly.	Check and tighten all screws and bolts. Ensure the table is on a level surface. Re-check assembly steps.

Problem	Possible Cause	Solution
Extension mechanism is stiff or not sliding smoothly.	Debris in tracks; misaligned rails; latches not fully released.	Clean tracks of any dust or debris. Ensure latches are fully disengaged. Verify rails are correctly installed and aligned.
Tabletop appears discolored or damaged.	Exposure to harsh chemicals/sunlight; manufacturing defect.	Avoid harsh cleaners and direct sunlight. If it appears to be a manufacturing defect, contact customer support.
Missing or defective parts during assembly.	Packaging error; transit damage.	Refer to the parts list in the Assembly Guide. Contact Weselon Furniture customer support immediately for replacements.

8. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	weselon
Model	B0F9PBYJTH
Product Dimensions (Compact)	41.73"D x 41.73"W x 29.53"H
Product Dimensions (Extended)	41.73"D x 78.74"W x 29.53"H
Maximum Weight Recommendation	130 Pounds
Color	Black 41"-78" Extendable Round Oval
Table Design	Dining Table
Frame Material Type	Metal
Top Material Type	Resin, Engineered Wood (MDF core)
Seating Capacity	4 (unextended), 6-8 (extended)
Number of Leaves	1
Item Weight	116 Pounds
Tabletop Thickness	1.18 Inches
Tools Recommended For Assembly	Screw Driver (Allen Wrench included)
Shape	Oval (Extended), Round (Compact)
Furniture Finish	Glossy

Extendable Design: 41.73" to 78.74"



Dining table for 4

Dining table for 6 to 8 people //




Image: Detailed dimensions for both the compact round and extended oval configurations of the dining table.

9. WARRANTY AND CUSTOMER SUPPORT

While specific warranty details are not provided in this manual, Weselon Furniture is committed to customer satisfaction. For any product-related inquiries, missing parts, or issues not covered in the troubleshooting section, please contact Weselon Furniture customer support directly.

You may also refer to the product listing on Amazon for information regarding protection plans or return policies.

Seller: [Weselon Furniture](#)

