



Manuals.plus /

› Pxdiiiry /

› Pxdiiiry USB Charger Cord for Hatteker RSCW-2018 Trimmer & Electric Shaver Razor User Manual

Pxdiiiry USB Charger Cord (for Hatteker RSCW-2018)

Pxdiiiry USB Charger Cord User Manual

For Hatteker RSCW-2018 Trimmer & Electric Shaver Razor

1. INTRODUCTION

This manual provides essential instructions for the safe and effective use of your Pxdiiiry USB Charger Cord. This cable is specifically designed to power and charge compatible devices, such as the Hatteker RSCW-2018 trimmer and electric shaver. Please read this manual thoroughly before use and retain it for future reference.

2. PRODUCT FEATURES

- **Durable Construction:** Made from high-quality materials for long-term reliability and stable performance.
- **Optimized Efficiency:** Designed for quick response and efficient power delivery, suitable for regular use.
- **Safety Certified:** Features multiple safety certifications to prevent overload and short circuits, ensuring safe operation.
- **Energy Efficient:** Low power design that complies with environmental standards, promoting green and energy-saving use.
- **Portable Design:** Lightweight and compact, making it easy to carry and store for use anytime, anywhere.



Image 2.1: The Pxdairy USB Charger Cord, featuring a standard USB-A connector on one end and a 2-pin shaver charging connector on the other.

3. COMPATIBILITY

This USB charger cord is specifically designed for the Hatteker RSCW-2018 Trimmer & Electric Shaver Razor. Before purchasing or using, it is crucial to compare the charging cable interface with your device's charging port to ensure compatibility and avoid incorrect model usage.

Tip

Before purchasing, please compare the charging cable interface with the shaver to avoid buying the wrong model.



Shaver interface



Charging cable interface

Image 3.1: Visual guide for checking compatibility. Ensure your shaver's charging interface matches the 2-pin connector of this cable.



Image 3.2: This image highlights the correct 2-pin connector type (left) compatible with the Hatteker RSCW-2018, distinguishing it from incompatible types (middle and right). The cable length is approximately 1.5 meters.

4. SETUP AND OPERATION

- 1. Connect to Device:** Insert the 2-pin connector end of the USB charger cord firmly into the charging port of your Hatteker RSCW-2018 trimmer or electric shaver.
- 2. Connect to Power Source:** Insert the USB-A end of the charger cord into a compatible USB power source. Compatible sources include:
 - Standard USB wall chargers (5V)
 - Power banks
 - Laptop or desktop computer USB ports
 - Car USB chargers
- 3. Initiate Charging:** Once connected to a power source, your device should begin charging. Refer to your device's manual for indicators of charging status (e.g., LED lights).

Power by USB devices



Image 4.1: Examples of compatible USB power sources for charging your device with the Pxdairy USB Charger Cord.

5. MAINTENANCE

- **Cleaning:** Keep the cable and connectors clean and free from dust or debris. Use a dry, soft cloth for cleaning. Do not use liquid cleaners.
- **Storage:** When not in use, store the cable in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling or bending the cable sharply to prevent damage.
- **Inspection:** Periodically inspect the cable for any signs of wear, fraying, or damage to the insulation or connectors. If damage is observed, discontinue use immediately and replace the cable.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not charging.	<ul style="list-style-type: none"> o Cable not properly connected. o Faulty USB power source. o Incompatible device charging port. o Damaged cable. 	<ul style="list-style-type: none"> o Ensure both ends of the cable are securely plugged in. o Try a different USB wall adapter, power bank, or computer USB port. o Verify your device is the Hatteker RSCW-2018 or a compatible model with the correct 2-pin port. o Inspect the cable for visible damage. If damaged, replace it.
Slow charging.	<ul style="list-style-type: none"> o Low power output from USB source. o Device battery issues. 	<ul style="list-style-type: none"> o Use a USB power source with adequate output (e.g., a dedicated wall charger instead of a computer port). o Consult your device's manual or manufacturer for battery-related concerns.

7. SPECIFICATIONS

Product Name	Pxdiiry USB Charger Cord
Model Compatibility	Hatteker RSCW-2018 Trimmer & Electric Shaver Razor
Connector Type (Input)	USB-A Male
Connector Type (Output)	2-Pin Shaver Charging Connector
Color	Black
Manufacturer	Pxdiiry
ASIN	B0F9PD9PZ8

8. SAFETY INFORMATION

- Do not expose the cable to water or excessive moisture.
- Avoid using the cable if it is damaged or frayed.
- Do not attempt to modify or repair the cable. Contact support if issues arise.
- Keep out of reach of children and pets.
- Use only with compatible devices and appropriate power sources.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your original purchase or contact the manufacturer, Pxdiiry, directly through their official channels. Please have your product model and purchase details ready when contacting support.

