

Gudsunal I3616

Gudsunal I3616 2-Plate Built-in Induction Cooktop User Manual

Model: I3616

1. INTRODUCTION

Thank you for choosing the Gudsunal I3616 2-Plate Built-in Induction Cooktop. This manual provides essential information for the safe installation, operation, and maintenance of your new appliance. Please read it thoroughly before use and keep it for future reference.

1.1 Important Safety Information

- Read all instructions before using the appliance.
- Ensure the appliance is properly installed by a qualified person.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- Only use cookware suitable for induction cooking.
- Keep children away from the appliance during operation due to hot surfaces and potential hazards.

2. PRODUCT OVERVIEW

The Gudsunal I3616 is a modern, efficient 2-plate built-in induction cooktop designed for seamless integration into your kitchen. It features advanced touch controls, multiple power levels, and safety functions to enhance your cooking experience.



BOOST



BOOST

88

8



8



Front view of the Gudsunal I3616 2-plate induction cooktop, showcasing its sleek black ceramic glass surface and touch control panel. The two cooking zones are clearly marked with 'BOOST' indicators, and the digital display shows power levels and timer settings.

2.1 Key Features

- **Dual Cooking Zones:** Two independent induction zones with a total power output of 3600 W (1500 W and 2100 W).
- **9 Power Levels:** Precise control over cooking temperature for various dishes.
- **Booster Function:** Provides a rapid heat boost for up to 5 minutes for faster boiling or searing.
- **Timer Function:** Set cooking times for each zone, with automatic shutdown.
- **Automatic Shutdown:** Enhances safety by turning off the cooktop after a set period of inactivity or if overheating occurs.
- **Child Lock:** Prevents accidental operation, ensuring safety in households with children.
- **Hot Surface Indicator:** Visual warning when a cooking zone is still hot after use.
- **Pot Detection:** Automatically detects suitable induction cookware and will not activate without a pot.

3. PACKAGE CONTENTS

Upon unpacking, please verify that all items listed below are present and undamaged. If any items are missing or damaged, contact customer support immediately.



The brown cardboard packaging box for the Gudsunal I3616 30 cm Induction Hob, displaying the model number, dimensions, weight, and 'Made in P.R.C.' label. The internal tracking number X002BB66BV is also visible.

- Gudsunal I3616 2-Plate Built-in Induction Cooktop
- User Manual (this document)
- Installation Kits (mounting brackets, screws)
- Sealing Tape
- Cutout Size Chart



Top view of the Gudsunal I3616 induction hob packaging, featuring 'FRAGILE HANDLE WITH CARE DO NOT STACK OR DROP KEEP DRY' labels and multilingual warnings regarding hot surfaces and child safety. The model number 'I3616' is also visible.

4. INSTALLATION AND SETUP

The Gudsunal I3616 induction cooktop is designed for built-in installation. Professional installation by a qualified electrician is highly recommended to ensure safety and proper functionality.

4.1 Electrical Requirements

- The appliance operates on 220-240V.
- Ensure your electrical supply meets the cooktop's power requirements (3600 W total).
- A dedicated circuit breaker may be required. Consult local electrical codes.

4.2 Countertop Cutout

- Refer to the included Cutout Size Chart for precise dimensions.
- Ensure adequate ventilation space around and beneath the cooktop.
- The cooktop dimensions are approximately 52 cm (length) x 29 cm (width) x 5.8 cm (height).

4.3 Installation Steps

1. Prepare the countertop cutout according to the provided template.
2. Apply the sealing tape around the edges of the cooktop to prevent liquid ingress.
3. Carefully lower the cooktop into the cutout.
4. Secure the cooktop from underneath using the supplied installation kits (brackets and screws).
5. Connect the cooktop to the electrical supply as per local regulations and the wiring diagram in the full manual.
6. Perform a test run to ensure all functions operate correctly.

5. OPERATING INSTRUCTIONS

The Gudsunal I3616 features intuitive touch controls. Ensure the cooktop surface is clean and dry before use.

5.1 Powering On/Off

- **To Power On:** Touch the Power button (⏻) for approximately 1 second. The display will show '0' or '-'.

- **To Power Off:** Touch the Power button (⏻) again.

5.2 Selecting a Cooking Zone and Adjusting Power

1. Place suitable induction cookware on the desired cooking zone.
2. Touch the corresponding Zone Selection button (e.g., for the left or right zone).
3. Use the '+' or '-' buttons, or slide your finger along the power level slider, to select a power level from 1 to 9.

5.3 Booster Function

- To activate the Booster function, select a cooking zone and then touch the 'Boost' button (P). The display will show 'P'.
- The Booster provides maximum power for up to 5 minutes. After this period, the power level will automatically revert to a lower setting.

5.4 Timer Function

- With a cooking zone active, touch the Timer button (Clock icon).
- Use the '+' or '-' buttons to set the desired cooking time. The timer can be set for up to 99 minutes.
- Once the time expires, the cooking zone will automatically turn off.

5.5 Child Lock

- **To Activate:** With the cooktop on but no cooking zones active, touch and hold the Child Lock button (Lock icon) for a few seconds. The display will show 'Lo'.
- **To Deactivate:** Touch and hold the Child Lock button (Lock icon) again until 'Lo' disappears.

5.6 Pot Detection

The cooktop will only activate a cooking zone if suitable induction cookware is placed on it. If an unsuitable pot is used or no pot is detected, an error code (e.g., 'U') may appear, and the zone will not heat.

5.7 Hot Surface Indicator

After a cooking zone is turned off, the display may show 'H' to indicate that the surface is still hot. Do not touch the surface until the 'H' disappears.

6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your induction cooktop.

6.1 Cleaning the Cooktop Surface

- Always ensure the cooktop is turned off and completely cool before cleaning.
- Wipe the ceramic glass surface with a soft cloth and a mild detergent or a specialized ceramic hob cleaner.
- For stubborn stains, use a ceramic hob scraper, holding it at a shallow angle.
- Avoid abrasive cleaners, scouring pads, or harsh chemicals, as these can scratch or damage the surface.
- Wipe dry with a clean cloth to prevent water spots.

6.2 General Care

- Avoid dropping heavy objects on the cooktop surface, as this can cause cracks.
- Do not use the cooktop as a storage surface.

- Ensure ventilation openings are not blocked.

7. TROUBLESHOOTING

If you encounter issues with your Gudsunal I3616 cooktop, refer to the following common problems and solutions. For more complex issues, contact customer support.

Problem	Possible Cause	Solution
Cooktop does not turn on	No power supply; Child lock active	Check power connection and circuit breaker; Deactivate child lock.
Cooking zone not heating (display shows 'U' or flashing)	Unsuitable cookware; No cookware present	Use induction-compatible cookware; Place a pot on the zone.
Cooktop turns off unexpectedly	Overheating; Timer expired; Spillage on controls	Allow to cool; Check timer settings; Clean control panel.
Error code displayed (e.g., 'E0', 'E1')	Internal fault; Sensor issue	Turn off and unplug the cooktop for a few minutes, then restart. If the error persists, contact customer support.

8. SPECIFICATIONS

Technical details for the Gudsunal I3616 2-Plate Built-in Induction Cooktop.

Feature	Specification
Brand	Gudsunal
Model Number	I3616
Product Dimensions (L x W x H)	52 x 29 x 5.8 cm
Total Power	3600 Watts
Cooking Zone 1 Power	1500 Watts
Cooking Zone 2 Power	2100 Watts
Voltage	220-240 Volts
Material	Metal, Ceramic Glass
Number of Heating Elements	2
Fuel Type	Electric
Special Features	Automatic Shutdown, Child Lock, Dual Induction, Hot Surface Indicator, Timer
Product Weight	6.01 Kilograms

9. WARRANTY AND SUPPORT

Gudsunal products are manufactured to high-quality standards. For warranty information, please refer to the warranty card included with your purchase or contact customer support.

9.1 Customer Support

If you have any questions, require technical assistance, or need to report a fault, please contact our customer service team:

- **Email:** service@gudsunakitchen.com
- Please have your model number (I3616) and purchase details ready when contacting support.



Side view of the Gudsunal induction hob packaging, showing manufacturer details, importer information, and the service contact email: service@gudsunakitchen.com. The 'Made in P.R.C.' and WEEE symbols are also present.

10. DISPOSAL INFORMATION

This product is marked with the symbol indicating that it should not be disposed of with other household waste at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of waste and recycle it responsibly to promote the sustainable reuse of material resources. Contact your local authority for details regarding the collection points for electrical and electronic waste.