

[Manuals.plus](#) /

› [Effireli](#) /

› Effireli K-DK1339 Replacement Remote Control User Manual for Daikin Air Conditioners

Effireli YK-K-DK1339

Effireli K-DK1339 Replacement Remote Control User Manual

For Daikin Air Conditioners

1. INTRODUCTION

This manual provides comprehensive instructions for the Effireli K-DK1339 replacement remote control, designed for use with compatible Daikin air conditioning units. This remote control requires no programming or setup; it is ready for immediate use upon battery installation.

2. SETUP AND BATTERY INSTALLATION

To begin using your Effireli K-DK1339 remote control, follow these simple steps for battery installation.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two new AAA batteries (not included), ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery compartment cover, sliding it back into place until it clicks securely.

The remote is now ready for operation.

3. OPERATING INSTRUCTIONS

Point the remote control directly at the air conditioner's receiver. Ensure there are no obstructions between the remote and the unit.



Image: Effireli K-DK1339 Replacement Remote Control. This image displays the remote control with its LCD screen and various function buttons, including ON/OFF, Temperature adjustment, Mode selection, Fan speed, Swing, Timer, and special functions like Powerful and Silent.

Button Functions:

- **ON/OFF:** Press to turn the air conditioner unit on or off.
- **TEMP ▲/▼ (Up/Down Arrows):** Adjusts the desired temperature setting.
- **MODE:** Cycles through available operating modes such as Auto, Cool, Dry, Fan, and Heat.
- **FAN:** Adjusts the fan speed (e.g., Auto, Low, Medium, High).
- **SWING:** Activates or deactivates the automatic louver swing function, directing airflow.
- **SILENT:** Engages a quiet operation mode, reducing fan noise.

- **POWERFUL:** Activates a rapid cooling or heating function for quick temperature changes.
- **HOME LEAVE:** Activates a specific mode for maintaining a comfortable temperature while you are away.
- **SENSOR:** Activates or deactivates the intelligent sensor function, which may detect room occupancy or temperature distribution.
- **TIMER ON:** Sets a time for the air conditioner to turn on automatically.
- **TIMER OFF:** Sets a time for the air conditioner to turn off automatically.
- **CANCEL:** Cancels any active timer settings.

4. MAINTENANCE

Proper maintenance ensures the longevity and reliable operation of your remote control.

- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or the display fades. Always replace both batteries simultaneously with new ones of the same type.
- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage. Store in a cool, dry place away from direct sunlight.

5. TROUBLESHOOTING

If you encounter issues with your remote control, refer to the following common problems and solutions:

- **Remote not responding:**
 - Ensure batteries are inserted correctly with the correct polarity.
 - Replace old batteries with new ones.
 - Check for any obstructions between the remote and the air conditioner unit.
 - Ensure you are within the effective operating range of the air conditioner.
- **Display is dim or blank:**
 - This usually indicates low battery power. Replace the batteries.
- **Air conditioner not responding to specific functions:**
 - Verify that the remote control model K-DK1339 is compatible with your specific Daikin air conditioner model. If your original remote looks different or your model number is not K-DK1339, contact support for compatibility confirmation.

6. SPECIFICATIONS

Brand	Effireli
Model Number	YK-K-DK1339
Special Feature	No Programming Required
Max Number of Supported Devices	1
Compatible Devices	Air Conditioner
Connectivity Technology	Infrared

7. WARRANTY AND SUPPORT

Your Effireli K-DK1339 replacement remote control comes with the following assurances:

- **Money-Back Guarantee:** Enjoy a 30-day money-back guarantee from the date of purchase.
- **Warranty:** A 12-month warranty covers manufacturing defects. Returns and exchanges are accepted within this warranty period.
- **Compatibility Support:** If your air conditioner model number is not K-DK1339 or your original remote appears different, please contact the seller directly to confirm compatibility before use.

Effireli K-DK1339 User Manual © 2024. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F9PQXD6P>

More documents and user manuals: <https://manuals.plus/>