

Shark SV2002

Shark Freestyle Max Cordless Upright Vacuum (Model SV2002) Instruction Manual

Your guide to powerful, quick, and efficient home cleaning.

1. INTRODUCTION

This manual provides essential information for the safe and effective operation and maintenance of your Shark Freestyle Max Cordless Upright Vacuum, Model SV2002. Please read these instructions thoroughly before first use and retain for future reference.





Image 1: Shark Freestyle Max Cordless Upright Vacuum, Nordic Blue.

2. WHAT'S INCLUDED

Your Shark Freestyle Max Cordless Upright Vacuum package includes the following components:

- Shark Freestyle Max Cordless Upright Vacuum
- Charging Dock

3. KEY FEATURES

The Shark Freestyle Max Cordless Upright Vacuum is engineered for powerful and convenient cleaning across various surfaces. Key features include:

- **Powerful Multi-Surface Cleaning:** Offers two brushroll speeds for deep-cleaning both carpets and bare floors with powerful suction.
- **Cordless Convenience:** Provides the freedom to clean any room quickly and easily without tangled cords or the need for nearby wall outlets.

- **Lightweight Maneuverability:** Weighs less than 7 lbs, allowing for easy swiveling around corners and into tight spaces.
- **Easy Maintenance:** Designed to reduce clogs and blockages for long-lasting, consistent performance with minimal upkeep.
- **Large-Capacity Dust Cup:** A larger, removable dust cup allows for extended cleaning sessions and effortless, hands-free debris disposal.
- **LED Headlights:** Integrated headlights on the nozzle illuminate and reveal hidden dirt, debris, and pet hair.



Cordless convenience

The freedom to clean any room, anytime—without tangled cords or the need for nearby wall outlets.

Image 2: The cordless design provides freedom of movement for cleaning.

4. SETUP AND INITIAL CHARGING

Before first use, assemble your vacuum and ensure it is fully charged.

1. **Assembly:** Connect the main vacuum body to the floor nozzle and the handle to the top of the main body until they click securely into place.
2. **Charging:** Place the vacuum onto the charging dock. Ensure the charging dock is plugged into a standard electrical outlet. The indicator lights on the vacuum will show charging status. A full charge provides approximately 20 minutes of battery life.



Cordless battery power

Features a hassle-free charging dock for convenient grab & go access.

Image 3: The charging dock provides convenient storage and power.

Your browser does not support the video tag.

Video 1: Official product video demonstrating the Shark Freestyle Max Cordless Vacuum's lightweight design and strong suction, including assembly and usage examples.

5. OPERATING INSTRUCTIONS

Your Shark Freestyle Max is designed for versatile cleaning. Follow these steps for optimal performance:

1. **Power On/Off:** Press the power button located on the handle to turn the vacuum on or off.
2. **Select Surface Setting:** Use the 2-speed brushroll control to switch between settings optimized for carpets or bare floors.
3. **Maneuverability:** The lightweight design allows for easy swiveling around furniture and into tight spaces.
4. **LED Headlights:** The headlights automatically illuminate, helping to spot hidden debris on all surfaces.




Powerful multi-surface pickup

Tackle debris on carpets and hard floors with Shark's most powerful cordless upright vacuum*.

*Based on ASTM F558, measured at the nozzle, vs. Shark SV1106.

Image 4: Powerful suction effectively cleans both carpets and hard floors.



Lightweight maneuverability
Glide around furniture and corners with Shark's lightest cordless upright vacuum*—under 7 lbs.
*vs. Shark SV1106.

Image 5: The lightweight design ensures easy maneuverability.



Image 6: LED headlights reveal hidden dirt for thorough cleaning.

6. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your vacuum.

1. **Emptying the Dust Cup:** The large-capacity dust cup is designed for easy, hands-free debris disposal. Simply detach the dust cup and empty its contents into a trash receptacle.
2. **Cleaning the Filter:** The foam filter can be removed and washed with water. Allow it to air dry completely before reinserting.
3. **Nozzle Maintenance:** The redesigned nozzle helps reduce clogs and blockages. Periodically check the brushroll for any tangled hair or debris and remove as necessary.



Never touch the mess

Larger-capacity* dust cup ejects debris with ease.

*vs. Shark BU3521.

Image 7: The easy-empty dust cup allows for hygienic disposal of debris.



Image 8: The redesigned nozzle minimizes clogs for consistent performance.

7. TROUBLESHOOTING

If you encounter any issues with your Shark Freestyle Max Cordless Upright Vacuum, please refer to the following general advice:

- **No Power:** Ensure the vacuum is fully charged. Check that the charging dock is properly connected to a working power outlet.
- **Reduced Suction:** Empty the dust cup and clean the filter. Check the nozzle and hose for any blockages and remove them.
- **Brushroll Not Spinning:** Ensure the vacuum is powered on and the correct surface setting is selected. Check the brushroll for any obstructions.

For persistent issues, please contact Shark Customer Support.

8. SPECIFICATIONS

Attribute	Detail
Brand	Shark

Model Name	Freestyle Max Cordless Upright Vacuum
Model Number	SV2002
Special Feature	Compact, Cordless, Headlight, High Power, Portable
Filter Type	Foam
Is Cordless?	Yes
Capacity	0.74 Quarts
Wattage	30 watts
Form Factor	Upright
Color	Nordic Blue
Product Dimensions	10.23"L x 9.8"W x 44.88"H
Amperage	2.78 Amps
Battery Life	20 minutes
Manufacturer	SharkNinja
Number of Speeds	2
Surface Recommendation	Carpet & Hardfloor
Power Source	Battery Powered

9. WARRANTY AND SUPPORT

For warranty information, product registration, or customer support, please visit the official Shark website or contact their customer service line. Keep your purchase receipt as proof of purchase.