



[Manuals.plus](#) /

> [ZHRCLY](#) /

> ZHRCLY AK-100W General Accessories for FOKPOND Pump User Manual

ZHRCLY AK-100W

ZHRCLY AK-100W General Accessories for FOKPOND Pump User Manual

Model: AK-100W

1. INTRODUCTION

Thank you for choosing the ZHRCLY AK-100W General Accessory. This manual provides essential information for the safe and efficient use of your new accessory. This product is designed to be compatible with FOKPOND pump models AK-50W, AK-75W, AK-100W, and AK-150W. Please read these instructions carefully before installation and operation, and retain them for future reference.



Figure 1: ZHRCLY AK-100W General Accessory. This image shows the compact design of the accessory, highlighting its robust construction suitable for pump systems.

2. SETUP INSTRUCTIONS

Proper installation is crucial for the optimal performance and longevity of your ZHRCLY AK-100W accessory. Ensure all safety precautions are followed.

2.1 Safety Precautions

- Always disconnect power to the FOKPOND pump before attempting any installation or maintenance.
- Wear appropriate personal protective equipment (PPE), such as gloves and eye protection.
- Ensure the installation area is clean, dry, and well-lit.
- Refer to the FOKPOND pump's original manual for specific compatibility and installation guidelines.

2.2 Installation Steps

1. **Unpack the Accessory:** Carefully remove the AK-100W accessory from its packaging. Inspect for any signs of damage during transit.
2. **Identify Connection Points:** Locate the designated connection points on your FOKPOND pump (AK-50W, AK-75W, AK-100W, or AK-150W) where this accessory is to be installed. Consult your pump's manual if unsure.

3. **Secure Attachment:** Align the AK-100W accessory with the pump's connection points. Use appropriate fasteners or connectors (not included unless specified) to securely attach the accessory. Ensure a tight, leak-free connection.
4. **Verify Connections:** Double-check all connections to ensure they are firm and properly sealed. Loose connections can lead to operational issues or damage.
5. **Initial Power-Up:** Once installation is complete, carefully reconnect power to the FOKPOND pump. Observe the system for any unusual noises, leaks, or malfunctions during the initial startup.

3. OPERATING INSTRUCTIONS

The ZHRCLY AK-100W accessory is designed to integrate seamlessly with your FOKPOND pump. Its operation is generally dependent on the pump's functionality.

1. **System Activation:** Once the accessory is installed, operate your FOKPOND pump according to its specific operating instructions. The AK-100W accessory will function in conjunction with the pump.
2. **Monitoring Performance:** Regularly monitor the pump system for optimal performance. Pay attention to flow rates, pressure, and any changes in sound or vibration.
3. **Normal Operation:** The accessory is designed for continuous operation within the specified parameters of the FOKPOND pump. Avoid exceeding the pump's recommended operating limits.

4. MAINTENANCE

Regular maintenance ensures the longevity and efficient operation of your ZHRCLY AK-100W accessory and the overall pump system.

- **Routine Inspection:** Periodically inspect the accessory for any signs of wear, corrosion, or damage. Check for loose connections or leaks.
- **Cleaning:** If necessary, clean the exterior of the accessory with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials that could damage the surface.
- **Component Check:** Ensure all components of the accessory remain securely fastened. Tighten any loose screws or fittings as needed.
- **Storage:** If the pump system is to be stored for an extended period, ensure the accessory is clean and dry. Store in a cool, dry place away from direct sunlight and extreme temperatures.

5. TROUBLESHOOTING

This section provides solutions to common issues you might encounter with your ZHRCLY AK-100W accessory. For complex problems, consult a qualified technician or contact customer support.

Problem	Possible Cause	Solution
Accessory not functioning	Improper installation; Pump not operating; Damaged component.	Verify all connections are secure. Ensure the FOKPOND pump is powered and operating correctly. Inspect the accessory for visible damage.
Leaks detected	Loose connections; Damaged seals.	Tighten all fittings. Check and replace any worn or damaged seals or gaskets.
Unusual noise/vibration	Loose mounting; Foreign object interference.	Ensure the accessory is securely mounted. Inspect for any debris or foreign objects obstructing its operation.

6. SPECIFICATIONS

The following are the general specifications for the ZHRCLY AK-100W accessory. These may vary slightly based on manufacturing tolerances.

Feature	Detail
Model Number	AK-100W
Manufacturer	Original factory
Item Weight	20 pounds
Product Dimensions	1 x 1 x 1 inches
Color	new
Included Components	NEW
Compatibility	FOKPOND Pump AK-50W, AK-75W, AK-100W, AK-150W

7. WARRANTY AND SUPPORT

This product is subject to a 30-day return policy from the date of purchase. For specific warranty details, please refer to the terms provided by the seller at the time of purchase.

For technical assistance, troubleshooting beyond this manual, or to inquire about replacement parts, please contact the seller directly through your purchase platform. Provide your model number (AK-100W) and purchase details for faster service.

Seller: Keyang Mechanical parts factory

ASIN: B0F9SNQLNQ