Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Ambition /
- > Ambition Seher Pro Wireless Tattoo Pen Machine User Manual

Ambition Seher Pro

Ambition Seher Pro Wireless Tattoo Pen Machine User Manual

Model: Seher Pro (AB-Seher73187904j-1)

1. Introduction

This manual provides essential instructions for the safe and effective operation, setup, and maintenance of your Ambition Seher Pro Wireless Tattoo Pen Machine. Please read this manual thoroughly before using the device to ensure proper function and longevity.

2. PRODUCT OVERVIEW

The Ambition Seher Pro is a wireless rotary tattoo pen machine designed for professional artists. It features a coreless motor, adjustable stroke length, and a large display battery with billing functionality. Its robust construction and ergonomic design aim to provide stability and control during extended use.





Figure 2.1: Ambition Seher Pro Wireless Tattoo Pen Machine, Gold variant.

Key Features:

- Coreless Motor: Integrated high-performance coreless motor for stable output and low vibration.
- Adjustable Stroke Length: Six precise stroke settings (2.2mm, 2.6mm, 3.0mm, 3.4mm, 3.8mm, 4.2mm) for versatile tattooing styles.
- High Capacity Battery: 2400mAh battery providing 6-7 hours of continuous operation at 8V.
- OLED Display: Large screen displays real-time voltage (1-12V), timer, and auto-billing function.
- **Ergonomic Design:** 42mm grip diameter and balanced weight (321g) for enhanced stability and comfort.

3. COMPONENTS AND PACKAGE CONTENTS

The Ambition Seher Pro package includes the following items:



Figure 3.1: Contents of the Ambition Seher Pro package.

- 1x Ambition Seher Pro Cordless Tattoo Machine
- 1x RCA Adapter
- 1x Extra 34mm Grip
- 1x RCA Cable
- 1x Charging Cable (USB)
- 1x Accessory Pouch
- 1x Hard-shell Zippered Case

4. SETUP

4.1 Charging the Battery

1. Connect the provided USB charging cable to the charging port on the battery unit.

- 2. Connect the other end of the USB cable to a 5V/2A charging adapter (not included).
- 3. The OLED display will indicate charging status. A full charge typically takes 2-3 hours.
- 4. **Important:** Do not completely drain the battery before charging. Use the original charging cable and a 5V/2A adapter to prevent damage.



Figure 4.1: Battery unit with charging port and display.

4.2 Attaching the Grip

The machine comes with a 42mm grip pre-installed and an extra 34mm grip. To change the grip:

- 1. Gently twist and pull the current grip off the machine body.
- 2. Align the desired grip with the machine body and push it firmly until it clicks into place.



Figure 4.2: The two available grip sizes for user preference.

4.3 Inserting a Needle Cartridge

- 1. Ensure the machine is powered off.
- 2. Carefully insert a compatible cartridge needle into the front opening of the grip.
- 3. Twist the cartridge gently until it is securely seated.

4.4 Using the RCA Adapter (Optional)

If you prefer to use a traditional power supply, attach the RCA adapter to the battery connection point and then connect your RCA cable to the adapter.

5. OPERATION

5.1 Power On/Off

- To power on, press and hold the power button until the OLED display illuminates.
- To power off, press and hold the power button again until the display turns off.

5.2 Adjusting Voltage

- Use the '+' and '-' buttons on the battery unit to increase or decrease the voltage.
- The voltage range is 1V to 12V, displayed in real-time on the OLED screen.

5.3 Adjusting Stroke Length

The Seher Pro allows for on-the-fly stroke adjustment:

- 1. Locate the adjustment knob on the machine body, above the grip.
- 2. Rotate the knob to select your desired stroke length: 2.2mm, 2.6mm, 3.0mm, 3.4mm, 3.8mm, or 4.2mm.



Figure 5.1: Diagram illustrating the adjustable stroke mechanism.

5.4 Adjusting Needle Depth

Needle depth is adjusted by rotating the grip. Turn the grip clockwise to extend the needle and counter-clockwise to retract it.

5.5 Billing Function

The integrated OLED screen includes an auto-billing function. This feature calculates fees based on

adjustable per-minute rates during pauses in operation, streamlining workflow for artists.

6. MAINTENANCE

6.1 Cleaning

- Always disconnect the machine from any power source before cleaning.
- Wipe the exterior of the machine with a clean, damp cloth and a mild, non-abrasive disinfectant.
- Do not immerse the machine in liquid or allow liquids to enter internal components.
- Ensure all surfaces are dry before storage or next use.

6.2 Battery Care

- Store the battery in a cool, dry place away from direct sunlight.
- Avoid fully discharging the battery regularly to prolong its lifespan.
- If storing for an extended period, charge the battery to approximately 50% capacity.

7. TROUBLESHOOTING

7.1 Machine Not Powering On

- Check if the battery is sufficiently charged. Recharge if necessary.
- Ensure the battery unit is securely attached to the machine body.

7.2 Inconsistent Performance

- Verify that the needle cartridge is correctly inserted and not damaged.
- Check the selected voltage and stroke settings.
- Ensure the battery has adequate charge.

7.3 Display Issues

- If the display is unresponsive or flickering, try restarting the machine.
- Ensure the battery is fully charged.

For persistent issues not resolved by these steps, please contact Ambition customer support.

8. SPECIFICATIONS



Figure 8.1: Detailed technical specifications for the Ambition Seher Pro.

Feature	Specification
Model Number	AB-Seher73187904j-1
Motor	Coreless Motor
Motor Speed	12V - 10500 RPM
Operating Voltage	1V - 12V
Battery Capacity	2400 mAh
Battery Life (at 8V)	6-7 hours
Charging Time	2-3 hours (with 5V/2A adapter)
Stroke Lengths	2.2mm, 2.6mm, 3.0mm, 3.4mm, 3.8mm, 4.2mm
Length	148mm

Feature	Specification
Grip Diameter	42mm (standard), 34mm (extra)
Weight	321g (15.7 ounces)
Product Dimensions	7.48 x 5.1 x 2.3 inches
Manufacturer	Ambition

9. SAFETY INFORMATION

- For professional external use only.
- · Avoid contact with eyes.
- Keep away from naked flame and extreme heat sources.
- Do not attempt to disassemble or modify the device, as this may void the warranty and pose safety risks.
- Always follow proper sterilization and hygiene protocols for all tattoo equipment and accessories.

10. WARRANTY AND SUPPORT

The Ambition Seher Pro Wireless Tattoo Pen Machine is backed by a**1-year warranty** covering all malfunctions under normal use. For warranty claims, technical assistance, or any inquiries, please contact Ambition official support. Refer to the product packaging or the Ambition website for specific contact details.

© 2025 Ambition. All rights reserved.

Related Documents - Seher Pro



Ambition Spice Grinder User Manual: Operation, Cleaning, and Safety

Comprehensive user guide for the Ambition spice grinder, covering battery replacement, filling, grind adjustment, operation, cleaning, maintenance, and essential safety precautions.



EZ P3 Pro Touch Wireless Tattoo Machine User Guide

Comprehensive user guide for the EZ P3 Pro Touch wireless tattoo machine, covering specifications, operation, and warranty information.



EZ P3 Pro Turbo Wireless Pen Machine User Guide

Comprehensive guide to the EZ P3 Pro Turbo Wireless Pen Machine, covering overview, specifications, basic operation, stroke adjustment, and warranty information.



EZ P3 Pro Wireless Tattoo Pen Machine: Specs, Operation, and Warranty

Detailed guide for the EZ P3 Pro Wireless Tattoo Pen Machine by EZ Tattoo. Covers specifications, basic operation, included items, and warranty information for this professional tattoo equipment.



Dragonhawk Fold Pro Snake Year Limited Edition Wireless Tattoo Machine User Manual

User manual for the Dragonhawk Fold Pro Snake Year Limited Edition Wireless Tattoo Machine (Model WQP-080), detailing its components, features, operation, and technical specifications.



Heta Ambition Stove: Operating and Installation Instructions

Comprehensive guide for the Heta Ambition wood stove, covering operation, installation, maintenance, troubleshooting, and safety guidelines. Includes technical specifications and EU conformity.