Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LUXOAK CNS166

LUXOAK Modern Glossy White 6-Drawer Chest (Model CNS166) - Instruction Manual

Brand: LUXOAK | Model: CNS166

Introduction

Thank you for choosing the LUXOAK Modern Glossy White 6-Drawer Chest. This elegant and functional piece of furniture is designed to enhance your bedroom, living room, or dressing area with its minimalist design and ample storage. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure you get the most out of your new chest of drawers. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Setup and Assembly

Assembly of your LUXOAK chest of drawers requires careful attention to detail. It is recommended that two people assemble this unit. Ensure you have sufficient space and all tools listed below before starting.

Tools Required (Not Included):

- Phillips Head Screwdriver
- Hammer
- Measuring Tape (optional)

Package Contents:

Your chest of drawers is delivered in flat packaging with numbered parts. Please verify all components against the parts list provided in your separate assembly guide. If any parts are missing or damaged, please contact customer service.




Figure 1: Product Dimensions and Drawer Components. This diagram illustrates the overall dimensions of the chest (40P x 138L x 80H cm) and the dimensions of a single drawer (13H x 30W x 67D cm). Note that the product may arrive in two separate packages.

Assembly Steps:

1. **Unpack and Identify Parts:** Carefully unpack all components. Lay them out on a clean, soft surface to prevent scratches. Identify each part using the numbered labels and the assembly guide.
2. **Assemble the Frame:** Follow the step-by-step instructions in your assembly guide to construct the main frame of the chest. Ensure all screws and fasteners are tightened securely.
3. **Install Drawer Glides:** Attach the drawer glides to the inside of the chest frame and to the sides of the drawer boxes as indicated in the instructions. Ensure they are level and aligned for smooth operation.
4. **Assemble Drawers:** Construct each of the six drawers. Pay attention to the orientation of the drawer fronts and backs.
5. **Insert Drawers:** Carefully slide the assembled drawers into the chest frame. Test each drawer for smooth movement.
6. **Attach Feet:** Secure the metal feet to the base of the chest.

7. **Final Inspection:** Check all connections and ensure the chest is stable and level.



Figure 2: Key Features and Components. This image highlights the layered chrome handles, the thick top panel, and the sturdy cabinet feet, which are important elements during assembly and for the overall stability and aesthetic.

Operating Instructions

The LUXOAK 6-Drawer Chest is designed for convenient storage in various rooms.

Using the Drawers:

- **Opening and Closing:** Gently pull the integrated handles to open the drawers. Push firmly to close them completely.
- **Storage Capacity:** Each of the six deep drawers offers ample space for clothing, accessories, or household items. The wide top surface is suitable for decorative items, picture frames, or plants.
- **Weight Distribution:** Distribute weight evenly within the drawers to prevent strain on the glides and maintain

stability. Avoid overloading drawers.



Figure 3: Ample Storage Capacity. This image demonstrates the spacious interior of the six drawers, suitable for organizing a wide range of items.



Figure 4: Versatile Storage Options. The chest is designed to accommodate various items, from clothing and books to accessories and important documents, making it suitable for different rooms.

Maintenance and Care

Proper care will ensure the longevity and appearance of your LUXOAK chest of drawers.

- **Cleaning the Surface:** The glossy white surface is water-repellent and easy to clean. Use a soft, damp cloth with a mild, non-abrasive cleaner. Avoid harsh chemicals or abrasive materials that could scratch the finish.
- **Chrome Handles:** Wipe chrome handles with a soft, dry cloth to maintain their shine. Avoid using chemical cleaners that may tarnish the finish.
- **Drawer Glides:** Periodically check drawer glides for smooth operation. If they become stiff, a small amount of silicone lubricant can be applied.
- **Stability Check:** Regularly check all screws and fasteners to ensure they remain tight. Retighten if necessary to maintain the chest's stability.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration. Position the chest

away from direct sunlight or use curtains/blinds.

- **Humidity Control:** Maintain a stable room temperature and humidity level to prevent warping or damage to the engineered wood.

Troubleshooting

If you encounter any issues with your LUXOAK chest of drawers, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Drawers do not slide smoothly or get stuck.	• Incorrectly installed drawer glides. • Obstruction in the glide mechanism. • Overloaded drawer. • Loose screws on glides or drawer box.	• Remove the drawer and re-check the installation of the glides on both the drawer and the cabinet frame. Ensure they are level. • Inspect the glides for any debris and remove it. • Reduce the weight in the drawer. • Tighten all screws on the drawer glides and drawer box.
Chest feels unstable or wobbly.	• Loose assembly screws. • Uneven floor surface. • Feet not properly attached.	• Retighten all assembly screws throughout the chest. • Place shims under the feet to level the chest on an uneven floor. • Ensure the feet are securely fastened to the base.
Missing or damaged parts upon delivery.	Shipping or packaging error.	Contact LUXOAK customer service immediately with your order details and a description of the missing/damaged parts.

Product Specifications

Feature	Detail
Brand	LUXOAK
Model Name	Kommode (Model CNS166)
Material	Engineered Wood
Color	White
Product Dimensions (D x W x H)	40P x 138L x 80H cm (15.75"D x 54.33"W x 31.5"H)
Number of Drawers	6
Item Weight	126 Pounds (approx. 57.15 kg)
Finish Type	Lacquered, Glossy Finish
Mounting Type	Floor Mount

Feature	Detail
Assembly Required	Yes
Special Features	Storage
Target Audience	Adults

Warranty Information

LUXOAK products are manufactured to high-quality standards. For specific warranty details, please refer to the documentation included with your purchase or contact LUXOAK customer service. Generally, products are returnable within 30 days of receipt.

Customer Support

Should you have any questions, require assistance with assembly, or need to report missing/damaged parts, our customer service team is available to help.
Please refer to your purchase documentation for direct contact information or visit the LUXOAK official website. When contacting support, please have your model number (CNS166) and purchase date ready.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F9T46DH7

More documents and user manuals: **https://manuals.plus/**