

**110.22882101**

## Instruction Manual

REPLACEMENT SOFTENER DISPENSER FOR KENMORE WASHER MODEL 110.22882101

### 1. Product Overview and Compatibility

This document provides instructions for the installation and use of the Fricparts replacement softener dispenser, designed for Kenmore washer model 110.22882101. This part is a direct replacement for the original equipment manufacturer (OEM) dispenser.

**Important:** Before proceeding with installation, verify that your washer's model number is 110.22882101 to ensure compatibility. Appliance parts can appear similar, so confirming the model number is crucial for correct fit and function.

### 2. Safety Information

- **WARNING:** Always disconnect the washer from its power source (unplug it or turn off the circuit breaker) before attempting any installation, repair, or maintenance. Failure to do so can result in electric shock, injury, or death.
- Wear appropriate personal protective equipment, such as gloves, to prevent injury during handling and installation.
- If you are unsure about any step of the installation process, consult a qualified appliance technician.
- Keep small parts away from children.

### 3. Package Contents

- 1 x Replacement Softener Dispenser (Fricpart-054588)

### 4. Setup and Installation

This section outlines the general steps for replacing the softener dispenser in your Kenmore washer. Specific steps may vary slightly depending on your washer's exact configuration.

1. **Disconnect Power:** Unplug the washer from the electrical outlet or turn off the circuit breaker supplying power to the washer.
2. **Access the Dispenser:** Open the washer lid. The softener dispenser is typically located in the center agitator or near the top rim of the wash tub.
3. **Remove the Old Dispenser:** Carefully pull or twist the old dispenser to remove it. Some dispensers

may require a slight push down and twist motion to unlock. Observe how the old dispenser is seated to aid in installing the new one.

4. **Install the New Dispenser:** Align the new replacement softener dispenser with the opening. Gently push down and twist (if applicable) until it seats securely in place. Ensure it is firmly attached and does not wobble.



Image 1: The Fricparts replacement softener dispenser. This white cylindrical component features a central opening for fabric softener and a light blue ring at its base, indicating the 'PUSH DOWN' mechanism for secure installation or removal.

5. **Reconnect Power:** Plug the washer back into the electrical outlet or turn the circuit breaker back on.
6. **Test Operation:** Run a short cycle with water to ensure the dispenser is properly installed and there are

no leaks.

## 5. Operating Instructions

---

Once installed, the softener dispenser operates as follows:

- **Filling:** Pour the recommended amount of liquid fabric softener into the dispenser cup. Do not overfill beyond the 'MAX FILL' line, if indicated.
- **Dispensing:** During the rinse cycle, the washer will automatically fill the dispenser with water, causing the softener to be diluted and dispensed into the wash tub.

## 6. Maintenance

---

Regular cleaning of the softener dispenser is recommended to prevent buildup and ensure proper function.

- **Cleaning:** Periodically remove the dispenser from the washer (refer to installation steps for removal). Rinse it thoroughly under warm water to remove any fabric softener residue. Use a small brush if necessary to clean stubborn buildup.
- **Drying:** Allow the dispenser to air dry completely before reinstalling it.

## 7. Troubleshooting

---

If you encounter issues with your softener dispenser, consider the following:

- **Softener Not Dispensing:**
  - Ensure the dispenser is clean and free of clogs.
  - Check that the dispenser is correctly seated and sealed.
  - Verify that you are not overfilling the dispenser, which can prevent proper siphoning.
- **Softener Dispensing Too Early/Late:** This is typically controlled by the washer's internal mechanisms. Ensure the dispenser is correctly installed and not obstructed. If the issue persists, it may indicate a problem with the washer itself rather than the dispenser.

## 8. Specifications

---

- **Product Type:** Replacement Washer Softener Dispenser
- **Compatible Washer Model:** Kenmore 110.22882101
- **Manufacturer:** Fricparts
- **Part Number:** FRIC-PL-APP-TP-22052025-022609 (Fricpart-054588)
- **Color:** Black/White (as per product description, actual visible part is white)
- **Item Package Quantity:** 1

## 9. Warranty and Support

---

For warranty information or technical support regarding this replacement part, please contact the seller or manufacturer directly. Keep your purchase receipt and product information handy when contacting support.

