

Missyou MS5

User Manual

Missyou 3D Hologram Fan Display Projector

Model: MS5

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Missyou 3D Hologram Fan Display Projector. Please read this manual carefully before using the product to ensure proper functionality and safety.

PRODUCT OVERVIEW

The Missyou 3D Hologram Fan Display Projector utilizes advanced LED technology to create stunning 3D visual effects that appear to float in the air. It is designed for various applications, including retail displays, trade shows, and events, to attract attention and enhance visual engagement. The 22-inch model (MS56S4) features 672 high-brightness LED beads, offering vivid colors and sharp details. It supports control via a dedicated mobile application (APP), WiFi, and a remote control, with integrated Bluetooth for audio synchronization.



Image: The Missyou 3D Hologram Fan in operation, projecting a vibrant 3D dragon image. A hand is shown holding a smartphone, illustrating the mobile app control feature.

WHAT'S IN THE BOX

Upon unpacking, please verify that all components listed below are present and in good condition:

- Missyou 3D Hologram Fan Unit (MS56S4)
- User Manual
- Power Adapter
- Power Cord
- Remote Control
- Mounting Screws and Accessories
- Memory Card (pre-installed or included)
- Blades (pre-attached or separate for assembly)



Image: A complete view of the product packaging contents, showing the main hologram fan unit, its remote control, user manual, power supply, and various accessories.

SETUP AND INSTALLATION

Follow these steps to set up your 3D Hologram Fan:

1. **Unpacking:** Carefully remove all components from the packaging.
2. **Blade Assembly (if applicable):** If the blades are not pre-attached, align each blade with its corresponding slot on the fan hub and secure them using the provided screws. Ensure they are firmly attached.
3. **Mounting:**
 - **Wall Mounting:** Use the included mounting bracket and screws to securely attach the fan to a sturdy wall. Ensure the mounting surface can support the weight of the unit.
 - **Stand Mounting (Optional):** If using an optional tripod or floor stand, attach the fan unit to the stand's mounting plate according to the stand's instructions.
4. **Power Connection:** Connect the power adapter to the fan's power port and then plug the adapter into a standard electrical outlet.
5. **Initial Power On:** Once connected, the fan will power on. The blades will begin to rotate, and the LED lights will illuminate.




Image: An exploded view diagram highlighting key components of the hologram fan, such as the LED lights on the blades, the internal chip, the pendant, and the power port.

OPERATING INSTRUCTIONS

The Missyou 3D Hologram Fan offers multiple control methods:

1. Mobile Application (APP) Control

1. **Download APP:** Scan the QR code in the user manual or search for "Missyou Hologram" (or similar, as specified in the manual) in your device's app store (Android and iOS compatible).
2. **Connect via WiFi:**
 - Power on the hologram fan.
 - On your smartphone, go to WiFi settings and connect to the fan's WiFi network (e.g., "Hologram_XXXX"). The password is usually provided in the manual or on the device.
 - Open the Missyou APP. The app should automatically detect and connect to the fan.

3. Content Upload:

- Within the APP, navigate to the content management section.

- You can upload new videos and images directly from your phone to the fan's memory card via WiFi. The APP supports direct playback of MP4 and AVI formats after conversion.

4. **Playback Control:** Use the APP to select content, adjust playback order, loop videos, and control power on/off.

Mobile phone APP control



Computer
upload (TF card)



Compatible with
Android system



High transfer speed
Upload by APP and play MP4 directly




Image: A smartphone displaying the Missyou mobile application, illustrating how users can control the hologram fan and manage content directly from their device.

2. Remote Control Operation

The included remote control provides basic functions:

- **Power On/Off:** Turn the fan on or off.
- **Play/Pause:** Control content playback.
- **Next/Previous:** Navigate through content.
- **Brightness Adjustment:** Adjust the display brightness (if supported by model).

3. Bluetooth Connectivity

The fan features built-in Bluetooth for audio synchronization:

1. **Pairing:** Enable Bluetooth on your external speaker or audio device.
2. **Connect:** Search for the fan's Bluetooth name (e.g., "Missyou MS56S4") and pair.
3. **Audio Playback:** Once paired, audio from your content will play through the connected Bluetooth speaker, enhancing the immersive experience.



Image: A visual representation of the fan's Bluetooth capabilities, demonstrating how it can connect to an external speaker to provide synchronized audio for the holographic display, featuring a Santa Claus hologram.

CONTENT MANAGEMENT AND CREATION

The Missyou 3D Hologram Fan supports various content formats and offers tools for easy management:

- **Supported Formats:** The fan primarily supports MP4 and AVI video formats.
- **Video Conversion Tool:** A free video conversion tool is provided by Missyou to help convert popular video formats into compatible ones for smooth playback. This ensures your custom content is ready for display

without complex editing.

- **Pre-loaded Content:** The device comes with over 700 pre-loaded 3D video clips, including holiday themes, brand ads, and party effects, ready for immediate use.
- **Multi-Fan Splicing:** Multiple Missyou 3D Hologram Fans (MS56S4) can be seamlessly connected to create a larger, more impactful 3D video wall. This modular design allows for scalable visual displays.



APP support IOS and Android
PC support Windows
Control by APP






Image: A collage showcasing a wide variety of 3D video clips from the extensive library included with the Missyou Hologram Fan, demonstrating the diverse content options available.

SAFETY AND PLACEMENT

Consider the following for safe operation and optimal display:

- **Acrylic Cover (Optional):** For high-traffic areas or environments where accidental contact is possible, an optional acrylic protective cover is recommended. This also helps minimize dust buildup.
- **Tripod Stand (Optional):** A tripod stand provides flexible placement options and enhanced stability, especially for temporary setups or when wall mounting is not feasible.
- **Ventilation:** Ensure adequate airflow around the fan unit to prevent overheating. Do not block the ventilation openings.
- **Indoor Use:** This product is designed for indoor use. Avoid exposure to moisture, extreme temperatures, or direct sunlight.



Image: The hologram fan unit encased in an optional clear acrylic protective cover, positioned on a display table, illustrating its use in public or commercial settings for added safety and protection.

SPECIFICATIONS

Feature	Detail
Brand	Missyou
Model Number	MS5
Display Size	22 inches
Item Weight	1.1 pounds
Product Dimensions	2 x 22 x 22 inches
Color	Black
Special Feature	Built-In 3D
Connectivity Technology	Bluetooth, Wireless (WiFi)
Display Resolution	1024 x 768
Recommended Use	Indoor

- **Cleaning:** Use a soft, dry cloth to gently wipe the fan blades and main unit. Do not use liquid cleaners or abrasive materials.

- **Dust Removal:** Regularly check for dust accumulation, especially around the LED beads and ventilation areas. Use compressed air if necessary to clear dust from hard-to-reach spots.
- **Storage:** When not in use for extended periods, store the fan in its original packaging or a protective case in a cool, dry place.
- **Blade Inspection:** Periodically inspect the blades for any signs of damage or looseness. Ensure they are securely fastened.
- **Software Updates:** Check the Missyou APP regularly for any available firmware or software updates to ensure the best performance and access to new features.

The upgraded silent motor is designed for long periods of operation with efficient heat dissipation, minimizing noise and risk of overheating.

TROUBLESHOOTING

If you encounter issues with your Missyou 3D Hologram Fan, refer to the following common problems and solutions:

Problem: Fan does not power on.

Solution:

- Ensure the power adapter is securely connected to both the fan and a working electrical outlet.
- Verify the power cord is not damaged.
- Try a different power outlet.

Problem: No 3D image or image is distorted.

Solution:

- Check if the blades are securely attached and not bent or damaged.
- Ensure the content being played is in a supported format (MP4, AVI) and has been properly converted.
- Verify the memory card is correctly inserted and contains valid content.
- Restart the fan unit.

Problem: Cannot connect to the APP via WiFi.

Solution:

- Ensure the fan is powered on and its WiFi network is visible in your phone's settings.
- Double-check the WiFi password.
- Move closer to the fan to ensure a strong signal.
- Restart both the fan and your smartphone.
- Ensure your APP is updated to the latest version.

Problem: No sound from Bluetooth speaker.

Solution:

- Ensure the Bluetooth speaker is powered on and in pairing mode.
- Verify the fan is successfully paired with the speaker.
- Check the volume levels on both the fan (if adjustable) and the speaker.
- Try unpairing and re-pairing the devices.

For further assistance, refer to the complete English user guide and online tutorials provided by Missyou.

WARRANTY AND SUPPORT

Missyou provides a complete English user guide and online tutorials to assist you with the setup and operation of your 3D Hologram Fan. These resources cover everything from installation to content uploading and remote control usage.

For specific warranty information, please refer to the documentation included with your purchase or contact Missyou customer support directly. Keep your purchase receipt as proof of purchase for warranty claims.

© 2024 Missyou. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question