Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bellemave Full Size Loft Bed with Desk

Bellemave Full Size Loft Bed with Desk and Storage Shelf User Manual

Model: Full Size Loft Bed with Desk

1. Introduction

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your Bellemave Full Size Loft Bed with Desk and Storage Shelf. Please read all instructions carefully before assembly and use to ensure safe and proper operation.

Important Safety Information

- Exercise caution around sharp edges during assembly.
- Do not load the bed with more than 400 pounds.
- Always follow assembly instructions carefully to prevent instability or collapse.
- Ensure all connections are secure before use.
- This loft bed is designed for full-size mattresses. Recommended mattress thickness is 6 inches.

2. Product Overview

The Bellemave Full Size Loft Bed is constructed from high-quality steel and MDF, offering a durable and stable sleeping solution with integrated workspace and storage. Its industrial design features clean lines suitable for various room aesthetics.



Figure 2.1: Bellemave Full Size Loft Bed with Desk and Storage Shelf.

Key Features:

- **Sturdy Construction:** Made from steel and MDF for enhanced durability and stability.
- **Integrated Workspace:** Features an L-shaped desk for study or work.
- **Storage Shelf:** Includes an upper storage shelf above the desk for books or supplies.
- **Safety Design:** Equipped with full-length guardrails, an integrated ladder, and 21 secured metal slats.
- **No Box Spring Required:** The metal slat system supports the mattress directly.

3. Package Contents

Your Bellemave Full Size Loft Bed package includes all necessary components for assembly. Please verify that all parts are present and undamaged before beginning assembly. The product is shipped in two separate boxes.



Figure 3.1: Illustration of components for easy assembly.

4. Setup and Assembly

Assembly of the Bellemave Full Size Loft Bed requires careful attention to detail. Detailed assembly instructions and all necessary tools are included in the package. It is recommended that two adults perform the assembly.

Assembly Steps:

1. **Unpack and Identify Parts:** Carefully unpack all components from both boxes. Lay them out and identify each part using the provided parts list in the instruction manual.
2. **Assemble Main Frame:** Begin by assembling the main vertical and horizontal support frames. Pay close attention to the orientation of parts, especially when attaching side supports (Frame A), as some holes are specific for certain connections.
3. **Install Desk and Shelf:** Attach the L-shaped desk and the upper storage shelf to the designated frame sections. Ensure all connections are tight and stable.
4. **Attach Ladder:** Securely attach the integrated ladder to the bed frame. Verify that the ladder is firmly in place and does not wobble.
5. **Install Guardrails:** Mount the full-length guardrails around the perimeter of the bed platform. These are crucial for safety.
6. **Place Metal Slats:** Install the 21 secured metal slats onto the bed frame. Ensure each slat is properly seated and secured to provide adequate mattress support.
7. **Final Inspection:** After completing all steps, perform a thorough inspection. Check all bolts, screws, and connections to ensure they are tightened securely. Confirm the bed is stable and does not creak or shake.




Figure 4.1: Product dimensions for planning placement.



Figure 4.2: View of the integrated L-shaped desk and storage shelf.



Figure 4.3: Safety features including guardrails and metal slats.

5. Operating Instructions

The Bellemave Full Size Loft Bed is designed for daily use, providing both a sleeping area and a functional workspace.

Using the Loft Bed:

- **Accessing the Bed:** Use the integrated ladder to safely access the loft bed. Always face the ladder when climbing up or down.
- **Using the Desk:** The L-shaped desk provides ample space for a computer, books, and other study or work materials. Ensure items are placed stably on the desk surface.
- **Utilizing Storage:** The upper shelf is suitable for lightweight items such as books, decorative objects, or small electronic devices. Avoid overloading the shelf.
- **Weight Capacity:** Adhere strictly to the maximum weight capacity of 400 pounds for the bed.

6. Maintenance and Care

Regular maintenance will help preserve the condition and longevity of your Bellemave Loft Bed.

- **Cleaning:** Wipe metal surfaces with a soft, damp cloth. For MDF surfaces, use a mild cleaner and dry immediately to prevent moisture damage. Avoid abrasive cleaners or harsh chemicals.
- **Hardware Check:** Periodically check all bolts, screws, and connections to ensure they remain tight. Re-tighten as necessary to maintain structural integrity.
- **Inspection:** Regularly inspect the bed frame, ladder, and guardrails for any signs of wear, damage, or loose components. Address any issues promptly.
- **Avoid Excessive Moisture:** Keep the bed in a dry environment to prevent rust on metal parts and swelling of MDF components.

7. Troubleshooting

This section addresses common issues that may arise during assembly or use.

- **Bed is Wobbly or Shakes:**
  Solution: Ensure all bolts and screws are fully tightened. Re-check the assembly instructions to confirm all parts are correctly oriented and installed. Verify that the bed is placed on a level surface.

- **Parts Do Not Align During Assembly:**
  Solution: Double-check the orientation of the parts against the assembly diagrams. Some components, like main side supports, have specific orientations. If a welded plate or hole does not align, carefully review the instructions for potential misplacement or contact customer support if a manufacturing defect is suspected. Do not force parts together.
- **Mattress Slats Fall Out:**
  Solution: Ensure each slat is properly inserted into its designated slot and secured according to the instructions. Verify that the bed frame is not warped or damaged.
- **Noise (Creaking/Squeaking):**
  Solution: Tighten all hardware. Apply a small amount of lubricant (e.g., silicone spray) to metal-on-metal contact points if noise persists after tightening.

8. Specifications

Feature	Detail
Material	Metal + MDF
Color	Black Desk Shelf
Overall Product Dimensions	78"L x 56.3"W x 70.9"H
Loft Bed Dimension	75" x 54"
Number of Slats	21 pcs
Bed Weight Capability	400 lbs
Recommended Mattress Thickness	6 inches (Mattress not included)
Assembly Required	Yes
Item Weight	56 pounds
Special Features	Desk, Guardrail, Ladder, No Box Spring Needed, Shelf

9. Warranty Information

Specific warranty details for the Bellemave Full Size Loft Bed are not provided in this manual. Please refer to your purchase documentation or contact Bellemave customer support for information regarding warranty coverage and terms.

10. Customer Support

For assistance with assembly, missing parts, or any other inquiries regarding your Bellemave Full Size Loft Bed, please contact Bellemave customer support. Refer to the contact information provided with your purchase or visit the official Bellemave website for support options.
You can also visit the Bellemave Store on Amazon for additional product information and support resources.

© 2025 Bellemave. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F9W3PH4B

More documents and user manuals: **https://manuals.plus/**