

[manuals.plus](#) /› [MAXLEGEN](#) /› [MAXLEGEN M14 Tablet Android 14 User Manual](#)

MAXLEGEN M14

MAXLEGEN M14 Tablet Android 14 User Manual

Model: M14 | Brand: MAXLEGEN

1. INTRODUCTION

This manual provides essential information for setting up, operating, and maintaining your MAXLEGEN M14 Android 14 Tablet. Please read it thoroughly to ensure optimal performance and longevity of your device. Keep this manual for future reference.

2. WHAT'S IN THE Box

Upon unboxing your MAXLEGEN M14 Tablet, please verify that all the following items are included:

- 14-inch Tablet
- Protective Case
- Stylus
- Earphones
- Type-C Cable
- Charger
- User Manual
- SIM Card Tray Tool

3. PRODUCT OVERVIEW

The MAXLEGEN M14 Tablet features an elegant metallic design with a thickness of only 7.8 mm, combining lightness and solidity for comfortable handling and portability.



Figure 3.1: Front and back view of the MAXLEGEN M14 Tablet, highlighting its sleek design and dual camera module.

14" Vue Maximale, Meilleure Expérience

14-inch Max View | Octa-core CPU
Android 14 | Max 36GB+256GB



Écran maximum de 14 pouces

16:10 Screen Ratio
2240*1400 FHD Resolution
Écran IPS à grand angle de vision



Mode et Elegant

7.8mm Thin
Bords Droits
Unicorp en métal
Texture optique



11580mAh

Extra Large Battery
18W Type-C Fast Charging



Android 14

Barre des tâches
Écran partagé
Contrôle parental
Protection de la vie privée



Store More

Max 36GB(12GB+24GB Expansion)
256GB ROM
1TB TF Expansion



Figure 3.2: The MAXLEGEN M14 Tablet shown with its included protective case, which also functions as a stand.



Figure 3.3: Detail of the tablet's rear AI Dual Camera and side ports, including the Type-C charging port.

4. SETUP

4.1 Initial Power On

1. Press and hold the Power button located on the side of the tablet until the MAXLEGEN logo appears on the screen.
2. Follow the on-screen prompts to select your language, connect to a Wi-Fi network, and set up your Google account.

4.2 SIM Card and MicroSD Card Installation

The MAXLEGEN M14 supports dual Nano SIM cards for cellular connectivity and a microSD card for expandable storage up to 1TB.

1. Locate the SIM card tray on the side of the tablet.
2. Insert the SIM card tray tool into the small hole next to the tray and gently push until the tray ejects.
3. Place your Nano SIM card(s) and/or microSD card into the designated slots on the tray. Ensure they are correctly oriented.

4. Carefully reinsert the tray into the tablet until it clicks into place.

5. OPERATING INSTRUCTIONS

5.1 Basic Navigation

The tablet uses standard Android touch gestures:

- **Tap:** Select an item or open an application.
- **Swipe:** Scroll through screens or lists.
- **Pinch:** Zoom in or out on images and web pages.
- **Long Press:** Access contextual menus or move icons.

5.2 Android 14 Features

Your tablet runs on the latest Android 14 system, offering enhanced features:

- **Taskbar:** For efficient multitasking and quick app switching.
- **Privacy & Security:** Improved controls over app permissions and personal data.
- **Parental Control:** Manage screen time and app usage for children.
- **Parallel View:** Optimized landscape experience for certain applications.



Figure 5.1: Overview of Android 14 features, including the taskbar, privacy settings, and parental controls.

5.3 Multitasking (Split Screen)

The split-screen functionality allows you to manage and use multiple applications simultaneously, enhancing productivity.




Figure 5.2: The tablet displaying two applications side-by-side in split-screen mode.

6. DISPLAY FEATURES

The MAXLEGEN M14 boasts an incredible 14-inch 2.5K IPS Incell display with a resolution of 2240 x 1400 pixels, providing sharp images and vibrant colors. The IPS Incell technology ensures a clearer display, richer colors, and wider viewing angles, while also protecting your eyes from harmful blue light.



Figure 6.1: The MAXLEGEN M14 Tablet featuring its 14-inch QHD IPS 2.5K display.



Figure 6.2: Visual comparison demonstrating the larger display area of the 14-inch screen compared to a 12-inch screen.

Écran Incell IPS QHD 14" MAX 2,5K

 **14 pouces**
Entièrement laminé  **2240*1400**
Résolution IPS QHD  **6.5mm***
Lunette ultra-étroite  **92%***
Rapport écran/corps



Figure 6.3: Close-up of the Incell IPS QHD 14-inch 2.5K screen, emphasizing its clarity and vibrant colors.

7. PERFORMANCE AND STORAGE

The MAXLEGEN M14 is powered by a 2.0 GHz octa-core processor and features 36GB of RAM (12GB base + 24GB expandable), ensuring smooth operation for multiple applications and a fluid gaming experience. It comes with 256GB of internal storage, expandable up to 1TB via a microSD card, providing ample space for all your files.




Figure 7.1: Visual representation of the tablet's 36GB RAM, 256GB ROM, and support for up to 1TB Micro SD expansion.

8. CONNECTIVITY

Stay connected with the MAXLEGEN M14's versatile connectivity options:

- **Dual SIM 4G LTE:** Supports two Nano SIM cards for fast and stable cellular internet access.
- **Dual-band Wi-Fi (2.4G/5G):** Ensures reliable and high-speed wireless internet connection.
- **Bluetooth 5.0:** For faster transmission speeds and improved stability with wireless accessories.
- **Wireless Screen Mirroring:** Easily connect your tablet to a TV or other compatible display.




Figure 8.1: Illustration of the tablet's various connectivity options, including Wi-Fi, 4G LTE, Bluetooth, and screen mirroring.

9. CAMERA FEATURES

Capture moments with clarity using the MAXLEGEN M14's dual AI cameras:

- **Rear Camera:** 16 MP with autofocus for remarkable image quality.
- **Front Camera:** 8 MP for clear video calls and selfies.
- **LED Flash:** For low-light conditions.
- **AI Sub-camera:** Optimized imaging capabilities.



Figure 9.1: Details of the tablet's HD AI Dual Cameras, including specifications for front and rear lenses.

10. BATTERY AND CHARGING

The MAXLEGEN M14 is equipped with a large 11580 mAh battery, providing sufficient power for all-day use. The included 18W fast charger and Type-C interface allow for quick recharging.



Figure 10.1: Visual representation of the tablet's 11580mAh battery and 18W fast charging capability via Type-C.

11. AUDIO FEATURES

Experience immersive audio with the MAXLEGEN M14:

- **Four Stereo Speakers:** Deliver exceptional sound with noise reduction technology.
- **3.5mm Headphone Jack:** For private listening with the included earphones or your preferred headphones.
- **FM Radio:** For additional entertainment options.




Figure 11.1: Depiction of the tablet's four stereo speakers, providing a rich audio experience.




Figure 11.2: Location of the 3.5mm headphone jack for connecting external audio devices.

12. NAVIGATION (GPS)

The MAXLEGEN M14 is equipped with advanced GPS capabilities, supporting multiple satellite positioning systems including GPS, BDS, Galileo, and GLONASS. This allows for precise navigation and access to offline maps for your travels.



Figure 12.1: The tablet displaying a map application, illustrating its multi-mode satellite positioning capabilities.

13. SECURITY AND PARENTAL CONTROLS

Your MAXLEGEN M14 Tablet offers various features to protect your data and manage usage:

- **Facial Recognition:** Securely unlock your device using your face.
- **Android 14 Privacy Settings:** Granular control over app permissions and data access.
- **Parental Controls:** Utilize integrated Google Family Link to set screen time limits, manage app usage, remotely lock devices, and monitor your child's tablet location.




Figure 13.1: A child using the tablet, demonstrating the parental control features for a safe digital environment.

14. MAINTENANCE

To ensure the longevity and optimal performance of your MAXLEGEN M14 Tablet, follow these maintenance guidelines:

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body. Avoid abrasive materials or harsh chemicals.
- **Storage:** Store the tablet in a cool, dry place away from direct sunlight and extreme temperatures.
- **Protection:** Always use the provided protective case and screen protector to guard against scratches and minor impacts.

- **Software Updates:** Regularly check for and install system updates to ensure your device has the latest security patches and performance improvements.

15. TROUBLESHOOTING

If you encounter issues with your MAXLEGEN M14 Tablet, refer to the following common troubleshooting steps:

- **Device Not Powering On:** Ensure the battery is charged. Connect the tablet to the charger and wait a few minutes before attempting to power it on again.
- **Screen Unresponsive:** Try restarting the tablet by holding down the Power button for approximately 10-15 seconds until the device powers off and then on again.
- **App Crashing/Freezing:** Close the problematic app and reopen it. If the issue persists, clear the app's cache and data in Settings > Apps.
- **Poor Wi-Fi Connection:** Ensure you are within range of your Wi-Fi router. Try restarting your router and the tablet.
- **Slow Performance:** Close unnecessary background applications. Consider clearing cache data or uninstalling unused apps to free up storage.
- **SIM/MicroSD Card Not Detected:** Ensure the card(s) are correctly inserted into the tray and the tray is fully seated. Restart the tablet.

If problems persist, consult the official MAXLEGEN support resources or contact customer service.

16. SPECIFICATIONS

Feature	Detail
Brand	MAXLEGEN
Model Number	M14
Color	Gray
Operating System	Android 14
Screen Size	14 Inches
Max Display Resolution	2240 x 1400 Pixels
Installed RAM Size	36 GB (12GB + 24GB expandable)
Storage Capacity	256 GB (Expandable up to 1TB via MicroSD)
Processor	Octa-Core 2.0 GHz
Connections	Cellular/LTE/GSM, Bluetooth 5.0, 2.4G/5G Wi-Fi
Battery Type	Lithium-polymer
Battery Capacity	11580 mAh
Charging	18W Fast Charging, Type-C Interface

Feature	Detail
Rear Camera	16 MP
Front Camera	8 MP
Navigation	GPS, BDS, Galileo, GLONASS
Model Year	2025

17. WARRANTY AND SUPPORT

17.1 Manufacturer Warranty

The MAXLEGEN M14 Tablet comes with a **1-year manufacturer warranty**. Please retain your proof of purchase for warranty claims.

17.2 Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please refer to the official MAXLEGEN website or contact their customer support channels. Contact information can typically be found on the product packaging or the brand's official online presence.

Related Documents - M14

	<p>Carlo Gavazzi MPF.RSL Fotocelle – Teknisk Datablad</p> <p>Oversigt over tekniske specifikationer, bestillingsinformation og installationsvejledning for Carlo Gavazzi MPF.RSL serie fotoelektriske sensorer, designet til industrielle døre og porte.</p>



Carlo Gavazzi MPF.RSL Photoelectric Sensor System

Technical specifications and selection guide for the Carlo Gavazzi MPF.RSL photoelectric sensor system, designed for industrial gates and doors. Includes details on amplifier and sensor characteristics, wiring diagrams, and installation advice.



[Guía del Usuario HP LaserJet Pro M14-M17: Instalación, Uso y Solución de Problemas](#)


Explore la Guía del Usuario para la impresora HP LaserJet Pro M14-M17. Aprenda sobre instalación, configuración, impresión, gestión y solución de problemas comunes.



Bruksanvisning Timmerslipprondell - ASKOGMA

Användningsområde, montering, justering och säkerhetsanvisningar för ASKOGMA

Timmersliprondell. Information om hur man använder produkten för barkning, formning och bilning av timmerstockar och plankor.



[WITTER FT57A Towbar Fitting Instructions for Fiat Multipla \(2000-\)](#)

Detailed fitting instructions for the WITTER FT57A towbar, designed for the Fiat Multipla (2000 onwards). Includes parts list, step-by-step assembly, and torque settings for secure installation.