

Aeitto Cold Press Juicer

Aeitto Juicer Machines Instruction Manual

MODEL: COLD PRESS JUICER

Brand: Aeitto

1. Important Safeguards

Please read all instructions carefully before operating your Aeitto Juicer Machine. Keep this manual for future reference. Improper use can lead to injury or damage to the appliance.

- Always unplug the juicer from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Avoid contact with moving parts.
- Do not immerse the motor base in water or other liquids.
- Ensure all parts are correctly assembled and locked before operation.
- This appliance is for household use only.

2. Setup and Assembly

The Aeitto Juicer Machine features a one-button disassembly design for easy setup and cleaning. Follow these steps to assemble your juicer:

1. Place the motor base on a stable, flat surface.
2. Align the juicing bowl with the motor base and twist to lock it into place.
3. Insert the filter basket into the juicing bowl, ensuring it sits securely.
4. Place the auger (spiral part) into the center of the filter basket.
5. Attach the feeding chute assembly to the top of the juicing bowl, aligning the marks and twisting until it locks.

6. Position the pulp and juice collection cups under their respective spouts.

Before first use, wash all detachable parts with warm, soapy water and rinse thoroughly.



Figure 2.1: Easy Assembly and Disassembly of the Aeitto Juicer.

3. Operating Instructions

The Aeitto Juicer Machine is designed for efficient juice extraction with minimal noise. It features three modes for various fruits and vegetables.

Preparation of Ingredients:

- Wash all fruits and vegetables thoroughly.
- Remove large seeds, pits, or hard skins (e.g., citrus peels).
- Cut ingredients into smaller chunks to fit the feeding chute and prevent clogging. This is especially important for harder produce like carrots and beets.

Mode Selection:

The juicer offers three distinct modes controlled by the dial:

- **SOFT MODE (85-100 RPM):** Ideal for softer fruits and vegetables such as oranges, watermelon, grapes, berries, and tomatoes.
- **HARD MODE (95-110 RPM):** Suitable for harder produce like apples, pears, carrots, beets, celery, ginger, and kale. This mode ensures better extraction and reduced oxidation for fibrous ingredients.
- **REVERSE FUNCTION (REV):** Use this function to clear any clogs if ingredients get stuck in the auger. Ensure the juicer is switched to 'O' (off) before engaging the reverse function.

Insert prepared ingredients into the feeding chute and gently push them down with the food pusher. Do not force ingredients. The juicer operates quietly, typically below 60 decibels, allowing for use at any time without disturbing others.

Higher Juice Yield & Drier Pulp

Upgraded filter extracts purest juice



Figure 3.1: Two Masticating Speeds for Optimal Juicing.

2 Mastigating Speeds

Suitable for different fruits and vegetables



Figure 3.2: Efficient Juice and Pulp Separation.

Note: To ensure optimal performance and motor longevity, avoid continuous operation for more than 10 minutes. Allow the motor to cool down if extended juicing is required.

4. Maintenance and Cleaning

Regular cleaning and proper maintenance will ensure the longevity and optimal performance of your Aeito Juicer Machine.

Cleaning Steps:

1. Unplug the juicer from the power outlet.
2. Press the one-button release to disassemble the juicing components.
3. Rinse all detachable parts under running water immediately after use to prevent pulp from drying and sticking.
4. Use the included cleaning brush to thoroughly clean the filter screen and other intricate parts.
5. All detachable parts are dishwasher safe for convenience. However, for the metal grate piece, hand washing immediately after use is recommended to prevent food from drying on it, which can make cleaning difficult.
6. Wipe the motor base with a damp cloth. Never immerse the motor base in water.
7. Allow all parts to dry completely before reassembling or storing.

Extract Celery Juice To The Max

7-segments upgraded auger leads to higher juice yield



VS

✓ **Aeitto**
Slow Juicer

✗ **Other**
juicer



Higher Juicer Yield



Low Juicer Yield




Maximum Nutrients



Nutrient Loss



Minimal Oxidation



More Oxidation

Figure 4.1: Easy Cleaning and Dishwasher Safe Parts.

5. Troubleshooting

If you encounter any issues with your Aeitto Juicer Machine, please refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Juicer does not turn on	Not plugged in; parts not assembled correctly; power outage.	Ensure the power cord is securely plugged into a working outlet. Check that all components are correctly assembled and locked into place. Verify power supply.
Ingredients are stuck / Juicer stops during operation	Overloading; large pieces of produce; fibrous ingredients causing blockage.	Switch the juicer to 'O' (off), then use the 'REV' (Reverse) function to clear the blockage. Cut ingredients into smaller pieces before juicing. Do not overload the feeding chute.
Low juice yield / Wet pulp	Incorrect mode selected; very soft or very hard produce.	Ensure you are using the appropriate 'SOFT' or 'HARD' mode for your ingredients. For some very soft fruits, a slightly wetter pulp is normal. For harder produce, ensure pieces are small enough for efficient mastication.
Unusual noise or vibration	Improper assembly; foreign object inside; motor strain.	Disassemble and reassemble all parts, ensuring they are securely locked. Check for any foreign objects. If the noise persists, discontinue use and contact customer support.

If the problem persists after trying these solutions, please contact Aeitto customer support for assistance.

6. Product Specifications

Feature	Detail
Brand	Aeitto
Model Name	Aeitto Juicer Machines
Item Model Number	Cold Press Juicer
Color	Charcoal Grey
Special Features	Dishwasher Safe, Juice & Pulp Separation, One-button Disassembly Design, Quiet Motor, Triple Modes (SOFE+HARD+Reverse)
Product Dimensions	11.61"D x 10.06"W x 7.68"H
Finish Type	Painted
Recommended Uses	Fruits, Vegetables
Product Care Instructions	Dishwasher Safe
Capacity	600 Milliliters
Maximum Power	150.0 Watts

Feature	Detail
Power Source	Corded Electric
Blade Material	Acrylonitrile Butadiene Styrene
Voltage	120.0 Volts
Number of Speeds	3
Item Weight	9.4 pounds

7. Warranty and Support

Aeitto provides a 12-month warranty service for this slow masticating juicer. If you experience any issues with your product, please do not hesitate to contact our customer support team.

For further assistance, product registration, or to purchase accessories, please visit the official Aeitto Store or contact our customer service department through the retailer where you purchased the product.

We are committed to providing high-quality appliance products and the best user experiences.

Visit the Aeitto Store: <https://www.amazon.com/stores/Aeitto/page/5301B7FD-EC1A-4BEB-AFCC-5D8611FB1E97>

© 2025 Aeitto. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question