

## AMACOOOL D07

# AMACOOOL Stroller Fan User Manual

Model: D07

## 1. INTRODUCTION

---

Thank you for choosing the AMACOOOL Battery Operated Stroller Fan. This versatile and portable fan is designed to provide a cooling breeze in various settings, from strollers and car seats to offices and outdoor activities. Its flexible tripod legs allow for secure attachment and versatile positioning. This manual provides essential information for safe and effective use of your fan.

## 2. SAFETY INFORMATION

---

- Keep fingers, hair, and loose clothing away from the fan blades during operation.
- Do not immerse the fan in water or expose it to excessive moisture.
- Ensure the fan is placed on a stable surface or securely attached to prevent it from falling.
- Do not attempt to disassemble or repair the fan yourself. Contact customer support for assistance.
- Keep out of reach of small children when not in use, despite its baby-friendly design.
- Use only the provided charging cable or a certified USB charger.

## 3. PACKAGE CONTENTS

---

- AMACOOOL Stroller Fan (Model D07)
- USB Charging Cable (Type-C)
- User Manual


## 4. PRODUCT OVERVIEW

---

Familiarize yourself with the main components of your AMACOOOL Stroller Fan.



**Figure 1:** Front view of the AMACOOOL Stroller Fan in purple, showcasing its flexible tripod legs wrapped around a bar. The fan head features the AMACOOOL logo.



**Figure 2:** Rear view of the fan, highlighting the control panel with the power/speed dial, USB charging port, and LED light button. The image also illustrates the three levels of LED night light.

## 5. SETUP

1. **Unpack:** Carefully remove the fan and all accessories from the packaging.
2. **Initial Charge:** Before first use, fully charge the fan using the provided USB cable. Connect the Type-C end to the fan's charging port and the USB-A end to a compatible power source (e.g., computer, wall adapter). The charging indicator light will show charging status.
3. **Positioning:**
  - **Standing:** Extend the flexible tripod legs to form a stable base on any flat surface.
  - **Wrapping/Clipping:** Bend and wrap the flexible legs around stroller handles, car seat bars, crib rails, bike handlebars, or treadmill handles. Ensure a secure grip to prevent slippage.
  - **Handheld:** Fold the legs together to use the fan as a handheld device.
4. **Adjust Angle:** The fan head can be manually rotated 360 degrees horizontally and vertically to direct airflow as needed.

# RECHARGEABLE COOL & EASY ALL-DAY OUTINGS



**Figure 3:** The fan securely attached to a stroller, providing a cooling breeze for a child. This demonstrates the fan's use for all-day outings.

# 360° AIR CIRCULATION

for Forward & Rear-Facing Carseat



**Figure 4:** The fan positioned to provide 360-degree air circulation for a child in a rear-facing car seat, highlighting its adaptability for various angles.

## 6. OPERATING INSTRUCTIONS

- 1. Power On/Off & Speed Adjustment:** Locate the rotary dial on the back of the fan.
  - Turn the dial clockwise to power on the fan and increase the fan speed.
  - The fan has 3 adjustable speeds:
    - **Speed 1:** Soft Wind (approx. 4.9 ft/s), lasts up to 10 hours.
    - **Speed 2:** Soft Wind (approx. 7.9 ft/s), lasts up to 6 hours.
    - **Speed 3:** Soft Wind (approx. 9.5 ft/s), lasts up to 2.5 hours.
  - Turn the dial counter-clockwise to decrease the fan speed and eventually power off the fan.
- 2. LED Night Light:** Press the dedicated LED button on the back of the fan to cycle through the 3 brightness levels of the night light. Press again to turn off the light.

# STRONG AIRFLOW

3 Speeds Adjustable

<b>Speed 1</b>	Soft Wind <b>4.9ft/s</b>	<b>10H</b>	
<b>Speed 2</b>	Soft Wind <b>7.9ft/s</b>	<b>6H</b>	
<b>Speed 3</b>	Soft Wind <b>9.5ft/s</b>	<b>2.5H</b>	



Figure 5: Visual representation of the three adjustable fan speeds and their approximate battery life durations.

## 7. CHARGING

The fan is equipped with a built-in 2600mAh non-replaceable battery. To charge:

1. Connect the provided USB Type-C cable to the charging port on the back of the fan.
2. Connect the other end of the USB cable to a USB power source (e.g., wall adapter, power bank, computer USB port).
3. A full charge takes approximately 2.5 hours.
4. The blue indicator light on the back of the fan will illuminate when charging and turn off when fully charged.

## Bendable Design Ideal for Outdoor



Figure 6: A detailed view of the fan's Type-C fast charging port, indicating its quick charging capability.

### 8. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the fan. Do not use abrasive cleaners or immerse the fan in water. For dust accumulation on the blades, use a soft brush or compressed air.
- **Storage:** When not in use for extended periods, store the fan in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the fan regularly, even if not in constant use.

### 9. TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not turn on.	Battery is depleted.	Charge the fan fully.
Weak airflow.	Low battery or fan speed setting.	Charge the fan or increase the fan speed.
Fan makes unusual noise.	Obstruction in blades or internal issue.	Turn off the fan and check for obstructions. If noise persists, contact customer support.
LED light not working.	Battery is depleted or light function is off.	Charge the fan. Press the LED button to cycle through brightness levels.

### 10. SPECIFICATIONS

- **Brand:** AMACOOOL
- **Model Name:** D07
- **Color:** Purple
- **Electric Fan Design:** Table Fan
- **Power Source:** Battery Powered
- **Product Dimensions:** 2.5"D x 5.4"W x 11"H

- **Item Weight:** 12.3 ounces
- **Number of Power Levels:** 3
- **Control Method:** Touch (referring to the dial/button interface)
- **Battery:** 1 Lithium Polymer battery (included, non-replaceable)
- **Charging Time:** Approximately 2.5 hours (from A+ content)
- **Run Time:** 2.5-10 hours (depending on speed setting)
- **Special Feature:** Adjustable Height (via flexible tripod), LED Night Light
- **Indoor/Outdoor Usage:** Indoor

## 11. WARRANTY AND SUPPORT

---

AMACOOOL is committed to providing high-quality products and excellent customer service.

- **Warranty:** We offer a 12-month replacement warranty for your product.
- **Free Replacement:** Enjoy 365 days of free replacement service.
- **Customer Support:** We aim for a 24-hour response time for all inquiries.
- For any questions, concerns, or warranty claims, please contact AMACOOOL customer support through your purchase platform or visit the official AMACOOOL store.