

[Manuals.plus](#) /

› [KYBOLT](#) /

› KYBOLT 10x13 Ft Regular Aluminum Pergola Instruction Manual

KYBOLT 10x13 Ft Regular

KYBOLT 10x13 Ft Regular Aluminum Pergola Instruction Manual

MODEL: 10x13 Ft REGULAR

1. Introduction

Thank you for choosing the KYBOLT 10x13 Ft Regular Aluminum Pergola. This manual provides essential information for the safe assembly, operation, and maintenance of your new pergola. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Figure 1: Fully assembled KYBOLT 10x13 Ft Regular Aluminum Pergola.

2. Safety Information

Your safety and the safety of others are very important. Please observe the following safety precautions:

- Always secure the pergola to a stable foundation to prevent it from tipping over, especially in windy conditions.
- Follow the assembly instructions carefully and do not hesitate to contact customer support if you have any questions

or concerns during the assembly process.

- Ensure all bolts and fasteners are tightened securely before use. Periodically check and re-tighten as necessary.
- Do not hang heavy objects from the pergola frame or canopy.
- Keep children and pets away from the assembly area during installation.
- In case of extreme weather conditions (heavy winds, snow), retract the canopy to prevent damage.

3. Product Specifications

Feature	Specification
Brand	KYBOLT
Material	Aluminum
Style	Regular
Product Dimensions (L x W x H)	58.66"L x 18.9"W x 8.27"H (Packaged)
Frame Material	Aluminum
Water Resistance Level	Water Resistant
Shape	Rectangular
Ultraviolet Light Protection	Yes
Assembly Required	Yes
Floor Area	130 Square Feet

OUTDOOR PERGOLA

10FT x 13FT




Figure 2: Detailed dimensions of the pergola structure.

4. Assembly Instructions

Assembly requires at least two people. Ensure you have all parts and tools before starting. A power drill is recommended for faster assembly.

- Step 1: Assemble the Frame Sections.** Begin by connecting the horizontal beams using the provided connectors and screws. Ensure all connections are secure.



Figure 3: Illustration of initial frame assembly.

2. **Step 2: Attach Crossbeams and Canopy Rails.** Install the crossbeams and the rails for the retractable canopy. Ensure the canopy rollers are correctly inserted into the rails.

REINFORCED STRUCTURE

Upgrade additional beams to enhance load-bearing capacity and stability.



Figure 4: Detail of the reinforced structure and beam connections.

3. **Step 3: Secure Base Columns.** Attach the upgraded 4-side anchored base columns to the main frame. These provide enhanced stability.



UPGRADED BASE COLUMN DESIGN

Reinforced on all four sides for comprehensive stability
increasing stability by 50%

Figure 5: Close-up of the upgraded base column design for stability.

4. **Step 4: Install Retractable Canopy.** Carefully slide the canopy fabric onto the rails, ensuring the ties are accessible for operation.
5. **Step 5: Raise and Secure Pergola.** With assistance, carefully raise the assembled pergola and position it in your desired location. Secure the base columns to the ground using appropriate anchors (not included, depending on surface type).

For a visual guide, please refer to the official assembly video:

Your browser does not support the video tag.

Video 1: Official KYBOLT Outdoor Pergola Assembly and Operation Guide.

5. Operating Instructions

The KYBOLT Pergola features a retractable canopy for adjustable shade.

- **To Extend the Canopy:** Gently pull the attached strap(s) to slide the canopy fabric along the rails until it reaches the desired extension.
- **To Retract the Canopy:** Push the canopy fabric back along the rails. The fabric will neatly fold, allowing for full sun exposure.
- **Securing the Canopy:** Use the hook locking design to secure the canopy in its desired position, preventing unwanted movement.



Figure 6: Mechanism for adjusting the retractable canopy.

6. Maintenance

Regular maintenance will prolong the life and appearance of your pergola.

- **Cleaning the Frame:** Wipe the aluminum frame with a damp cloth and mild soap. Rinse thoroughly and dry to prevent water spots. Avoid abrasive cleaners.
- **Cleaning the Canopy:** The UPF 50+ waterproof canopy can be cleaned with a soft brush, mild soap, and water. Allow it to air dry completely before retracting or storing.
- **Seasonal Care:** In regions with harsh winters or extreme weather, it is recommended to remove and store the canopy fabric indoors to prevent damage.
- **Hardware Check:** Periodically inspect all bolts, screws, and connections for tightness. Re-tighten as needed to maintain structural integrity.

7. Troubleshooting

If you encounter issues with your pergola, refer to the following common solutions:

- **Canopy not retracting/extending smoothly:** Check the canopy rails for obstructions or debris. Ensure the rollers are clean and properly seated. Lubricate the rails if necessary with a silicone-based spray.
- **Pergola feels unstable:** Verify that all frame connections are securely tightened. Ensure the base columns are properly anchored to the ground. Re-check the ground surface for levelness.
- **Water pooling on canopy:** Ensure the canopy is properly tensioned and angled to allow for water runoff. If the issue persists, check for any sagging in the support bars.

- **Missing parts during assembly:** Double-check the packaging and parts list. If parts are genuinely missing, contact KYBOLT customer support immediately.

8. Warranty and Support

KYBOLT stands behind the quality of its products. For warranty information, replacement parts, or technical assistance, please visit the official KYBOLT website or contact customer support directly. Please have your model number and purchase date available when contacting support.

Visit the [KYBOLT Store](#) for more products and information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B0F9WHZR3K>

More documents and user manuals: <https://manuals.plus/>