

HYSEYY HY-1314-QH

HYSEYY Clothes Rack (Model HY-1314-QH) Instruction Manual

Your guide to assembly, operation, and maintenance.

1. INTRODUCTION

Thank you for choosing the HYSEYY Clothes Rack, Model HY-1314-QH. This sturdy, portable, and rolling garment rack is designed to provide convenient and efficient clothing storage in various environments, including bedrooms, laundry rooms, living rooms, or commercial spaces. This manual provides essential information for the safe assembly, operation, and maintenance of your new clothes rack.

2. SAFETY INFORMATION

- **Weight Capacity:** Do not exceed the maximum load capacity of **180 pounds (81.6 kg)**. Overloading can cause instability and damage.
- **Even Distribution:** Distribute weight evenly across the hanging rod to prevent tipping.
- **Lock Wheels:** Always engage the wheel locks when the rack is stationary to ensure stability.
- **Stable Surface:** Place the rack on a flat, level, and stable surface.
- **Children and Pets:** Keep children and pets away from the rack during assembly and ensure it is stable when in use to prevent accidents.
- **Assembly:** Ensure all components are securely fastened according to the assembly instructions before use.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly:

- Main Hanging Rod (1)
- Vertical Support Poles (2)
- Base Frame with Wheel Attachments (1)
- PP Wheels (4, including 2 lockable)

- Assembly Hardware (screws, bolts, wrench, etc.)
- Instruction Manual (this document)

4. SETUP AND ASSEMBLY

The HYSEYY Clothes Rack features a thread-rolling mounting design for quick and straightforward assembly. Follow these steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Verify all components listed in Section 3 are present.
2. **Attach Wheels to Base:** Insert the four PP wheels into the designated slots on the base frame. Ensure the two lockable wheels are positioned on the same side for easier access. Tighten any securing mechanisms if provided.
3. **Connect Vertical Support Poles:** Attach the vertical support poles to the base frame. The thread-rolling design allows for easy screwing together of the metal pipes.
4. **Install Main Hanging Rod:** Secure the main hanging rod to the top of the vertical support poles using the thread-rolling mechanism. Ensure all connections are tight and stable.
5. **Final Check:** Gently shake the assembled rack to ensure all connections are secure and the rack is stable before placing any items on it.

Thread Rolling Mounting

Easy to assemble




Figure 4.1: Illustration of the thread-rolling mounting for easy assembly.

5. OPERATING INSTRUCTIONS

Using your HYSEYY Clothes Rack is simple and efficient:

- **Hanging Clothes:** Utilize the main hanging rod for various clothing items, from short tops to long dresses. The rack's height of 63.8 inches (162 cm) is designed to prevent hems from dragging on the floor.
- **Moving the Rack:** To move the rack, ensure the two lockable wheels are in the unlocked position. Gently push or pull the rack to its desired location.
- **Securing the Rack:** Once the rack is in position, engage the locks on the two lockable wheels to prevent unintended movement and ensure stability.
- **Bottom Storage:** The base frame provides additional space for items such as shoes, storage baskets, or folded garments.



Figure 5.1: The HYSEYY Clothes Rack in use, displaying hanging garments and bottom storage.

360° Lockable Wheels

PP material wheels for smooth rolling



Lockable Wheels



360° Rotation



Silent Design



2in




Figure 5.2: Detail of the 360-degree lockable wheel for mobility and stability.

6. MAINTENANCE

Regular maintenance will help prolong the life and functionality of your clothes rack:

- **Cleaning:** Wipe down the metal frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Wheel Inspection:** Periodically check the wheels for any accumulated debris (lint, hair, etc.) and clean them to ensure smooth rolling.
- **Connection Check:** Every few months, inspect all threaded connections and tighten them if they have become loose.

7. TROUBLESHOOTING

If you encounter any issues with your clothes rack, refer to the following common solutions:

- **Rack is Wobbling:**

- Ensure all threaded connections are fully tightened.
- Verify that the weight of the clothes is distributed evenly across the hanging rod.
- Check if the rack is placed on a flat and level surface.

- **Wheels Not Rolling Smoothly:**

- Inspect the wheels for any hair, dust, or debris that might be obstructing their movement. Clean as necessary.
- Ensure the wheel locks are fully disengaged.

- **Wheels Not Locking:**

- Ensure the lock levers are fully engaged.
- Check for any obstructions preventing the lock mechanism from functioning correctly.

8. SPECIFICATIONS

Brand	HYSEYY
Model Number	HY-1314-QH
Color	Black
Material	Metal
Product Dimensions (D x W x H)	16.5"D x 46.5"W x 63.8"H (41.9 cm D x 118.1 cm W x 162.1 cm H)
Load Capacity	180 Pounds (81.6 kg)
Special Features	Lockable Wheels, Portable, Rolling
Installation Type	Free Standing
Assembly Required	Yes
Item Weight	8.88 pounds (4.03 kg)

Product Dimension



Figure 8.1: Product dimensions overview.

180LBS Load Capacity



T-shirts
100 pcs



Dresses
70 pcs



Jackets
50 pcs



Coats
35 pcs



Figure 8.2: Load capacity details.

Reinforced 25.4mm Tubes

Holds more, lasts longer




Figure 8.3: Reinforced 25.4mm tubes for enhanced durability.

9. WARRANTY INFORMATION

Specific warranty details for the HYSEYY Clothes Rack (Model HY-1314-QH) may vary. Please refer to the product packaging or contact the seller directly for comprehensive warranty terms and conditions.

10. CUSTOMER SUPPORT

For any questions, concerns, or assistance regarding your HYSEYY Clothes Rack, please contact our dedicated customer support team. We aim to respond to inquiries within 24 hours to ensure your satisfaction.

Please refer to your purchase documentation or the seller's contact information for the most direct way to reach support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question