

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [WYBOT](#) /

› [WYBOT Cordless Robotic Pool Cleaner Model AS User Manual](#)

## WYBOT AS

# WYBOT Cordless Robotic Pool Cleaner Model AS User Manual

Model: AS

## 1. IMPORTANT SAFETY INFORMATION

Read all instructions carefully before using the WYBOT Cordless Robotic Pool Cleaner. Failure to follow these safety guidelines may result in injury or damage to the product.

- Do not operate the cleaner when people or animals are in the pool.
- Ensure the charging port is dry before connecting the charger.
- Use only the original power adapter provided with the cleaner.
- Keep the cleaner out of reach of children.
- Do not use the cleaner to remove chemicals or hazardous materials from the pool.
- Always remove the cleaner from the pool before performing any maintenance or cleaning.
- Store the cleaner in a cool, dry place when not in use.

## 2. PRODUCT OVERVIEW

The WYBOT Cordless Robotic Pool Cleaner Model AS is designed for efficient and autonomous cleaning of various flat-bottomed pools. Its cordless design offers convenience and ease of use.



Image 2.1: WYBOT Cordless Robotic Pool Cleaner Model AS. This image shows the blue and black robotic pool cleaner with water splashing around it, highlighting its aquatic function.

## 2.1 Package Contents

Verify that all items are present in the package:



Image 2.2: Package contents including the pool cleaner, power adapter, flipper & handle, scrapers, retrieving hook, user manual, and quick guide.

- Pool Cleaner x 1
- Power Adapter x 1
- Flipper & Handle x 1
- Scraper x 2
- Retrieving Hook x 1
- User Manual x 1
- Quick Guide x 1

## 3. SETUP

### 3.1 Initial Charging

Before first use, fully charge the cleaner. The battery takes approximately 3-4 hours to fully charge.

1. Ensure the cleaner is dry and clean.
2. Connect the power adapter to the charging port on the cleaner.
3. Plug the power adapter into a suitable electrical outlet.
4. The indicator light will show red during charging and turn green when charging is complete.



Image 3.1: The robotic pool cleaner connected to its charger, with indicator lights showing charging status (red for charging, green for completed).

### 3.2 Handle Installation

Attach the flipper and handle to the cleaner as shown in the diagram (refer to quick guide for detailed visual instructions).

## 4. OPERATING INSTRUCTIONS

The WYBOT Cordless Robotic Pool Cleaner is designed for ease of operation.

### 4.1 Placing the Cleaner in the Pool

1. Ensure the cleaner is fully charged.

2. Turn on the cleaner using the power button.
3. Gently lower the cleaner into the pool. It will sink to the bottom and begin its cleaning cycle.



Image 4.1: A person carefully lowering the robotic pool cleaner into a tiled swimming pool.

## 4.2 Cleaning Cycle

The cleaner will navigate the pool bottom using its intelligent sensing technology to ensure comprehensive coverage. It is suitable for various flat pool types including square, round, and irregular shapes.



Image 4.2: Diagram illustrating the intelligent sensing technology and cleaning path of the robotic pool cleaner across the pool floor.




Image 4.3: Illustrations of square, round, and irregular shaped pools, indicating the cleaner's compatibility with all flat pool types.

### 4.3 Retrieving the Cleaner

Once the cleaning cycle is complete or the battery is low, the cleaner will typically stop. Use the provided retrieving hook to carefully lift the cleaner out of the pool.

## 5. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your pool cleaner.

### 5.1 Cleaning the Filter

After each use, clean the filter basket to remove trapped debris.

1. Remove the cleaner from the pool.
2. Open the cleaner's cover to access the filter basket.
3. Remove the filter basket.
4. Rinse the filter basket thoroughly with a hose to remove all debris.
5. Reinstall the clean filter basket and close the cover securely.




Image 5.1: A person cleaning the filter basket of the robotic pool cleaner with a hose, showing debris being washed away.

### 5.2 Battery Care

- Always fully charge the battery before storing the cleaner for extended periods.
- Recharge the battery every three months if not in use to maintain battery health.
- Avoid exposing the cleaner to extreme temperatures during storage.

## 6. TROUBLESHOOTING

If you encounter issues with your WYBOT Cordless Robotic Pool Cleaner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cleaner does not turn on.	Low battery; Power button not pressed correctly.	Charge the cleaner fully; Ensure the power button is pressed firmly.
Cleaner moves slowly or stops during operation.	Low battery; Filter basket is clogged; Obstruction in wheels/brushes.	Recharge the cleaner; Clean the filter basket; Check for and remove any obstructions.
Poor cleaning performance.	Clogged filter; Dirty pool water (high algae); Incorrect pool chemistry.	Clean the filter thoroughly; Balance pool chemistry; Perform manual cleaning if necessary.
Cleaner does not cover the entire pool.	Large debris blocking path; Pool shape complexity.	Remove large debris before operation; For complex shapes, multiple cycles may be needed.

If the problem persists after trying these solutions, please contact customer support.

## 7. SPECIFICATIONS

Feature	Detail
Model Number	AS
Product Dimensions	16.14 x 15.94 x 8.46 inches
Item Weight	10.68 pounds (4.85 Kilograms)
Power Source	Battery Powered
Battery Type	Lithium Ion
Lithium Battery Voltage	10.95 Volts
Lithium Battery Energy Content	28.47 Watt Hours
Charging Time	3-4 hours (approx.)
Control Method	App (functionality may vary by model)
Assembly Required	No (minor handle attachment required)

## 8. WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please refer to the official WYBOT website or contact their customer service directly.

Keep your purchase receipt as proof of purchase for warranty claims.

**Manufacturer:** WYBOT

**Brand:** WYBOT

## Related Documents - AS

	<p><a href="#"><b>WYBOT C2 Intelligent Cordless Pool Robot User Manual</b></a></p> <p>Comprehensive user manual for the WYBOT C2 intelligent cordless pool robot. Covers setup, operation, maintenance, troubleshooting, and specifications for efficient pool cleaning with 180 minutes of runtime.</p>
	<p><a href="#"><b>Wybot Osprey 700 Robotic Pool Cleaner User Manual</b></a></p> <p>Comprehensive user manual for the Wybot Osprey 700 robotic pool cleaner, detailing its features, specifications, operation, maintenance, and safety precautions for efficient pool cleaning.</p>
	<p><a href="#"><b>WYBOT SC1 Robotic Pool Cleaner User Manual</b></a></p> <p>Comprehensive user manual for the WYBOT SC1 Robotic Pool Cleaner, detailing setup, operation, maintenance, troubleshooting, and specifications. Learn how to effectively clean your pool with this advanced robotic cleaner.</p>
	<p><a href="#"><b>WYBOT WY1102MAX Pool Cleaner FAQs and Troubleshooting</b></a></p> <p>Frequently asked questions and solutions for common problems encountered with the WYBOT WY1102MAX cordless robotic pool cleaner, covering cleaning effectiveness, battery life, indicator lights, and mechanical issues.</p>
	<p><a href="#"><b>WYBOT A1(OS2010) Quick Start Guide - Assembly, Charging, Operation, and Maintenance</b></a></p> <p>A concise quick start guide for the WYBOT A1(OS2010) cordless robotic pool cleaner, covering assembly, charging, cycle customization, submerging, removal, and filter cleaning.</p>
	<p><a href="#"><b>WYBOT S2 Solar Robotic Pool Cleaner User Manual</b></a></p> <p>Comprehensive user manual for the WYBOT S2 Solar robotic pool cleaner, detailing setup, operation, maintenance, safety instructions, and troubleshooting.</p>

