

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [GEODMAER](#) /
- › [GEODMAER 65% Wireless Gaming Keyboard Instruction Manual](#)

GEODMAER Wireless Gaming Keyboard-KB

GEODMAER 65% Wireless Gaming Keyboard Instruction Manual

Model: Wireless Gaming Keyboard-KB

INTRODUCTION

Thank you for choosing the GEODMAER 65% Wireless Gaming Keyboard. This ultra-compact keyboard is designed for both gaming and office use, offering a reliable 2.4G wireless connection, LED backlighting, and a long-lasting rechargeable battery. This manual provides detailed instructions to help you get the most out of your new keyboard.



Image: The GEODMAER 65% Wireless Gaming Keyboard in Gray-Black, showcasing its compact layout and included USB receiver.

PACKAGE CONTENTS

Please verify that all items are present in your package:

- GEODMAER 65% Wireless Gaming Keyboard
- 2.4G USB Receiver
- Type-C Charging Cable

- User Manual (this document)

SETUP

1. Initial Charging

Before first use, it is recommended to fully charge the keyboard. Connect the supplied Type-C charging cable to the keyboard's charging port and the other end to a USB power source (e.g., computer USB port, USB wall adapter). The LED indicator will show charging status.

2. Connecting the 2.4G Wireless Receiver

1. Locate the 2.4G USB receiver, typically found in a compartment on the keyboard or within the packaging.
2. Plug the USB receiver into an available USB port on your computer or laptop.
3. Turn on the keyboard using the power switch (usually located on the back or side of the keyboard).
4. The keyboard should automatically connect to your device. No additional drivers are typically required for Windows or macOS.



Image: The keyboard positioned on a desk, illustrating its wireless connectivity and compact form factor for an organized workspace.

OPERATING INSTRUCTIONS

Keyboard Layout and Functions

This 65% compact keyboard features 68 keys. Many functions are accessed using the **Fn** key in combination with other keys.

LED Backlight Control

- **Turn On/Off Backlight:** Press **Fn + Light Key** (usually a key with a lightbulb icon).
- **Switch Backlight Mode:** Press **Fn + Light Key** repeatedly to cycle through modes (e.g., always bright, breathing mode).
- **Adjust Brightness:** Press **Fn + ↑ (Up Arrow)** to increase brightness, **Fn + ↓ (Down Arrow)** to decrease brightness.
- **Adjust Breathing Frequency:** Press **Fn + ← (Left Arrow)** to slow down breathing frequency, **Fn + → (Right Arrow)** to speed up breathing frequency.

Power Management

The keyboard is equipped with a 2000 mAh rechargeable battery, providing extended usage times.

- **Battery Life:** Up to 500 hours of continuous use without backlighting, and up to 50 hours with maximum brightness backlighting.
- **Auto-Sleep Function:** To conserve power, the keyboard will automatically enter sleep mode after 1 minute of inactivity. Press any key to reactivate it.
- **Charging:** Use the provided Type-C cable. The keyboard can be used while charging.




Image: A visual representation of the keyboard's 2000mAh battery capacity, indicating 50 hours of use with lights on, 500 hours with lights off, 1 minute auto-stop, and Type-C charging.

MAINTENANCE

Cleaning the Keyboard

To maintain optimal performance and appearance, follow these cleaning guidelines:

- Disconnect the keyboard from your device and power source before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution to wipe the keycaps and surface.
- Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the keyboard's finish or keycap legends.
- For dust and debris between keys, use compressed air.

Storage

When not in use for extended periods, store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.

High Quality Making For Strong Working Life

Working life of more than **10 million** keystrokes



Image: The keyboard highlighting its durable construction, designed for a working life of over 10 million keystrokes.

TROUBLESHOOTING

If you encounter any issues with your GEODMAER keyboard, please refer to the following common solutions:

Problem	Possible Cause	Solution
Keyboard does not turn on / Not charging	Low battery, faulty cable, power switch off	Ensure the power switch is ON. Connect the keyboard to a power source using the Type-C cable. Try a different USB port or charging cable.
Keys do not work / Connection is intermittent	Connection issue, low battery, interference	Re-pairing Steps: <ol style="list-style-type: none">1. Turn off the keyboard.2. Unplug the 2.4G USB receiver from your device.3. Plug the USB receiver back into a different USB port if possible.4. Turn on the keyboard. It should automatically re-establish the connection. Ensure the keyboard is charged. Move the keyboard closer to the receiver. Avoid sources of strong wireless interference.

Problem	Possible Cause	Solution
Backlight not working or dim	Backlight off, low brightness, low battery	Press Fn + Light Key to turn on/cycle modes. Press Fn + ↑ to increase brightness. Charge the keyboard.

SPECIFICATIONS

Feature	Detail
Model Number	Wireless Gaming Keyboard-KB
Connectivity Technology	2.4G Wireless
Compatible Devices	Laptop, PC (Windows)
Keyboard Description	Gaming, 65% Compact
Special Features	Backlit, Hotkeys and Media Keys, Rechargeable, Anti-ghosting, No-Conflict, Ergonomic Design
Battery	2000 mAh (1 Nonstandard Battery included)
Backlight Color Support	Single Color (LED)
Material	Plastic
Item Weight	1.26 pounds
Package Dimensions	12.95 x 5.2 x 1.73 inches



Image: A close-up view of the keyboard demonstrating its ergonomic high and low keycap design for comfortable long-term use.

WARRANTY INFORMATION

The GEODMAER 65% Wireless Gaming Keyboard comes with a **3-year after-sales service**. This warranty covers manufacturing defects and ensures support for product quality issues.

SUPPORT

For any quality problems or questions regarding your GEODMAER keyboard, please contact our customer support. Your inquiries will be addressed within 24 hours.

Please refer to the product packaging or the official GEODMAER website for specific contact details.