Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VECELO KHD-CC-ZL01-WHE

VECELO KHD-CC-ZL01-WHE Accent Chair User Manual

Model: KHD-CC-ZL01-WHE

1. Introduction

Thank you for choosing the VECELO Accent Chair. This manual provides essential information for the safe assembly, proper use, and effective maintenance of your new chair. Please read these instructions carefully before assembly and retain them for future reference.
The VECELO Accent Chair is designed with a modern mid-century style, featuring white PU leather upholstery and a gold metal frame. It is suitable for various indoor settings such as living rooms, bedrooms, and office spaces.

2. Safety Information

- **Weight Limit:** Do not exceed the maximum weight capacity of 285 pounds (129 kg). Exceeding this limit may result in damage to the chair or personal injury.
- **Stability:** Always ensure the chair is placed on a stable, flat, and level surface before use to prevent tipping.
- **Assembly:** Follow all assembly instructions precisely. Ensure all screws and fasteners are securely tightened before using the chair. Periodically check and re-tighten fasteners as needed.
- **Children:** Keep small parts and packaging materials away from children during assembly to prevent choking hazards.
- **Indoor Use Only:** This chair is designed for indoor use. Exposure to outdoor elements can damage the materials and compromise structural integrity.

3. Setup and Assembly

The VECELO Accent Chair requires simple assembly. All necessary tools are included in the package.

3.1. Package Contents

Before beginning assembly, verify that all components are present:

- Chair Seat and Backrest Assembly (1)
- Gold Metal Leg Frame (1)
- Assembly Hardware (screws, washers, Allen wrench)

3.2. Assembly Steps

1. Carefully unpack all components and place them on a clean, soft surface to prevent scratches.
2. Attach the gold metal leg frame to the underside of the chair seat using the provided screws and Allen wrench. Ensure the legs are oriented correctly.
3. Tighten all screws firmly, but do not overtighten to avoid damaging the threads.
4. Once assembled, gently place the chair upright and test its stability before use.



Image 3.2.1: Chair Dimensions and Weight Capacity. This diagram illustrates the chair's measurements (21.26"D x 20.87"W x 35.04"H) and highlights the maximum weight capacity of 285 pounds.

4. Operating Instructions

The VECELO Accent Chair is designed for comfortable seating in various indoor environments.

4.1. Intended Use

This chair is recommended for use as an accent chair, dining chair, or reading chair. Its ergonomic design and cushioned backrest provide support for extended periods of sitting.



Image 4.1.1: Comfort Design Features. This image highlights the ergonomic features such as the curved backrest for spinal support, wide armrests, and a padded seat with 25D high-resilience foam for comfort.

4.2. Placement

Place the chair in your desired indoor location, ensuring it is on a flat, stable surface. Avoid placing the chair in direct sunlight or near heat sources to prevent material degradation.




Image 4.2.1: Chair in a Living Room Setting. This image shows the chair positioned in a living room, demonstrating its suitability for various home environments.

5. Maintenance

Proper care and maintenance will extend the life and appearance of your VECELO Accent Chair.

5.1. Cleaning Instructions

The chair's PU leather upholstery is water-resistant and easy to clean.

- For general cleaning, wipe the surface with a soft, damp cloth.
- For spills, immediately blot the area with a clean, dry cloth. Use a mild soap solution if necessary, then wipe with a clean, damp cloth and dry thoroughly.
- Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the PU leather and metal finish.



Image 5.1.1: Easy Cleaning of PU Leather. This image illustrates the water-resistant nature of the PU leather, showing how easily it can be wiped clean.

5.2. General Care

- Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.

- Avoid dragging the chair across floors, as this can damage the leg frame or floor surface. Lift the chair when moving it.
- Protect the chair from sharp objects that could puncture or scratch the upholstery.

6. Troubleshooting

This section addresses common issues you might encounter with your VECELO Accent Chair.

6.1. Chair Feels Unstable/Wobbly

- **Check Fasteners:** Ensure all screws connecting the leg frame to the seat are fully tightened. Loosen slightly, adjust the chair on a flat surface, then re-tighten.
- **Level Surface:** Verify that the chair is placed on a completely flat and level floor. Uneven surfaces can cause wobbling.
- **Leg Glides:** Check if the protective glides on the bottom of the legs are intact and evenly placed.

6.2. Squeaking Noises

- **Tighten Screws:** Squeaking often indicates loose connections. Re-tighten all assembly screws.
- **Inspect Joints:** Examine the joints where the metal frame connects for any signs of friction.

6.3. Upholstery Damage

- **Scratches/Punctures:** Minor scratches on PU leather can sometimes be minimized with a leather repair kit. For significant damage, professional repair or replacement of the chair may be necessary.
- **Stains:** Refer to the cleaning instructions in Section 5.1. Act quickly on spills to prevent permanent staining.

7. Specifications

Feature	Detail
Brand	VECELO
Model Name	VECELO Set of 1 Modern Mid-Century Accent Chairs
Item Model Number	KHD-CC-ZL01-WHE
Color	White
Product Dimensions (D x W x H)	21.26" x 20.87" x 35.04" (54cm x 53cm x 89cm)
Item Weight	13.67 pounds (6.2 kg)
Maximum Weight Recommendation	285 Pounds (129 kg)
Back Style	Cushioned
Special Feature	Ergonomic, Upholstered Leather
Product Care Instructions	Wipe Clean
Recommended Uses	Accent, Dining, Reading
Included Components	Chair (1)
Fill Material	Sponge

Leg Style	Straight Leg (Gold Metal Frame)
Indoor/Outdoor Usage	Indoor

© 2025 VECELO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F9WSZ4WK

More documents and user manuals: **https://manuals.plus/**