

[Manuals.plus](#) /

› [Ailltopd](#) /

› Portable Carpet & Upholstery Spot Cleaner Instruction Manual

Ailltopd C5

Portable Carpet & Upholstery Spot Cleaner

Model: C5 | Brand: Ailltopd

INTRODUCTION

Thank you for choosing the Ailltopd Portable Carpet & Upholstery Spot Cleaner. This powerful and versatile cleaning machine is designed to effectively remove stubborn stains and dirt from various fabric surfaces, including carpets, upholstery, car seats, and mattresses. Its compact design and dual tank system make cleaning efficient and convenient, ensuring a healthier and safer home environment.

SAFETY INFORMATION

- Always read all instructions before using the appliance.
- Use only cleaning solutions recommended for spot cleaners.
- Do not immerse the appliance in water or other liquids.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Unplug from outlet when not in use and before cleaning or servicing.
- Do not exceed the MAX fill line on the water tanks to prevent suction issues.

WHAT'S INCLUDED

Your Ailltopd Portable Carpet & Upholstery Spot Cleaner comes with the following components:

- Ailltopd Carpet Cleaner Main Unit
- Clean Water Tank (1.5L capacity)

- Sewage/Dirty Water Tank (0.8L capacity)
- Spray Hose with Integrated Handle
- Large Brush Head
- Small Brush Head
- Power Cord
- Sample Cleaning Agent



The Ailltopd Portable Carpet & Upholstery Spot Cleaner with its included accessories, including the main unit, hose, and brush heads.

Accessory List



A visual representation of the accessory list, showing the main unit, spray hose, wire storage, hook for brush, waste water tank, clean water tank, big brush, and small brush.

SETUP

1. **Fill the Clean Water Tank:** Locate the clean water tank (1.5L capacity) on the right side of the unit. Flip the lever to open the tank. Fill it with clean water and, if desired, add the provided cleaning agent or your preferred solution. Ensure you do not exceed the MAX fill line to prevent suction issues.



The clean water tank (1500ml) and dirty water tank (Max 800ml) are removable. Remember not to exceed the MAX line when filling.



Detailed view showing how to open and close the water tanks for filling and emptying.

2. **Attach the Desired Brush Head:** Select either the large or small brush head based on the cleaning area. The brush

heads attach to the end of the spray hose. Ensure it clicks securely into place.

3. **Connect to Power:** Plug the power cord into a standard electrical outlet.

OPERATING INSTRUCTIONS

The Ailltopd Spot Cleaner operates in three simple steps: Spray, Brush, and Suction.

1. **Power On:** Press the power button located on the main unit to turn on the cleaner.
2. **Spray:** Aim the brush head at the stained area. Press the trigger on the handle to spray cleaning solution onto the stain.
3. **Brush:** Gently scrub the stained area with the brush head to agitate the dirt and allow the solution to penetrate the fibers.
4. **Suction:** Release the spray trigger and press the brush head firmly against the surface. Move it slowly over the treated area to suction up the dirty water and loosened debris. Repeat as necessary until the stain is removed.

CLEAN MESSSES IN 3 EASY STEPS



► SPRAY



► SCRUB



► SUCTION

The cleaning process involves three easy steps: Spraying the solution, scrubbing with the brush, and then suctioning the dirty water.

ALL-IN-ONE FUNCTION



Diagram illustrating the all-in-one function of the cleaner: spray clean water under booster pressure, thoroughly remove dirt with the brush, and suck waste water under booster pressure.

Applications

This portable cleaner is ideal for a wide range of fabric cleaning tasks:

- Carpets and Rugs
- Upholstery (Sofas, Chairs)
- Car Interiors (Seats, Floor Mats)
- Mattresses
- Stairs



Examples of multi-purpose cleaning on various surfaces: sofa, carpeting, car interior, and mattress.

MAINTENANCE

1. **Empty and Clean the Dirty Water Tank:** After each use, remove the dirty water tank (on the left side) and empty its contents. Rinse the tank thoroughly with clean water.
2. **Clean Brush Heads:** Detach the brush head from the hose. Rinse it under running water to remove any trapped debris or residue.
3. **Self-Cleaning Hose Tool:** The cleaner features a self-cleaning hose tool. Attach the hose to the designated port on the unit and run clean water through it to flush out any remaining dirt or solution.

Remove for Brush Cleaning & Self-Cleaning Hose Tool




Illustration of the self-cleaning hose tool, showing how water flows through to clean the hose and brush attachment.

4. **Wipe Down Unit:** Use a damp cloth to wipe down the exterior of the main unit.
5. **Storage:** Store the cleaner in a cool, dry place. The hose and power cord can be wrapped around the unit for compact storage, and the brush heads can be stored on the machine's dual brush hook.



The compact size of the cleaner allows for easy storage, such as under a sink, and features a slim handle for portability.



The compact design saves space and includes dedicated storage for wires, a hook for the brush, and a detachable hose for organized storage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No suction	Dirty water tank is full or clean water tank is empty. Tank not properly seated. Hose or nozzle clogged.	Empty dirty water tank. Refill clean water tank. Ensure tanks are securely in place. Check and clear any clogs in the hose or nozzle.
No spray	Clean water tank is empty. Spray nozzle is clogged.	Refill clean water tank. Clean the spray nozzle.
Machine not turning on	Not plugged in. Power outlet issue.	Ensure the power cord is securely plugged into a working outlet. Try a different outlet.

SPECIFICATIONS

- **Brand:** Ailltopd
- **Model Name:** C5
- **Product Dimensions:** 6.81 x 12.83 x 12.04 inches
- **Item Weight:** 11.33 pounds
- **Clean Water Tank Capacity:** 1.5 Liters
- **Sewage Tank Capacity:** 0.8 Liters
- **Suction Power:** 15Kpa
- **Rated Power:** 500W
- **Hose Length:** 4.26 ft (1.3M)
- **Power Cord Length:** 16.4 ft (3M)
- **Color:** White

WARRANTY & SUPPORT

Your Ailltopd Portable Carpet & Upholstery Spot Cleaner is covered by a manufacturer's warranty. For detailed warranty information, product support, or service inquiries, please refer to the warranty card included in your product packaging or visit the official Ailltopd website. Keep your purchase receipt as proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question