

- Manuals.plus /
- > LocoLee /
 - > Instruction Manual for LocoLee Light Kit Compatible with Lego 21357 Pixar Luxo Jr. Lamp - Standard Version

LocoLee 21357

Instruction Manual for LocoLee Light Kit

Compatible with Lego 21357 Pixar Luxo Jr. Lamp - Standard Version
Model: 21357 | Brand: LocoLee

1. PRODUCT OVERVIEW

This light kit is designed to enhance your LEGO 21357 Pixar Luxo Jr. Lamp model, bringing it to life with integrated lighting. It features a touch dimmer switch for intuitive control over brightness and power.



Image: The LocoLee Light Kit illuminates the Lego Luxo Jr. Lamp and a Pixar ball, showcasing the enhanced display.

2. PACKAGE CONTENTS

Please verify that all components are present before beginning installation. The package includes the following:

- LED Light Kit components
- Instruction Manual (online access)

Note: The LEGO 21357 Pixar Luxo Jr. Lamp model set is **NOT** included with this light kit and must be purchased separately or already owned.

Touch to Switch On/Off & Adjust Brightness



Image: Contents of the light kit package, showing the LED components and the instruction manual.

3. SETUP AND INSTALLATION

Follow these steps for proper installation of your LocoLee Light Kit. Detailed video and PDF instructions are available online to guide you through the process.

1. **Pre-Installation Test:** Before assembling, connect all light components to a power source (USB, less than 5V) to ensure they are working correctly.
2. **Access Instructions:** Refer to the detailed video or PDF installation instructions provided online. These step-by-step guides will show you how to integrate the lights with your LEGO model.
3. **Disassembly (if required):** You may need to carefully disassemble a few bricks of your LEGO model to properly install the light fixtures.
4. **Gentle Handling:** The light parts are small and delicate. Avoid pulling wires too hard during installation to prevent damage.
5. **Power Connection:** Once installed, connect the light kit to a USB power source (voltage less than 5V). Using a USB power source will result in brighter illumination.

Your browser does not support the video tag.

Video: An overview of the light kit installation process for the Lego 21357 Pixar Luxo Jr. Lamp.

4. OPERATING INSTRUCTIONS

The LocoLee Light Kit features an intuitive touch dimmer switch for easy control.

- **Power On/Off:** A single, quick tap on the touch switch will turn the lights on or off, mimicking the iconic blink of the Luxo Jr. lamp.
- **Adjust Brightness:** To adjust the brightness, press and hold the touch switch. The brightness will smoothly increase or decrease. Release the switch when the desired brightness level is reached.
- **Power Source:** The light kit is powered via USB. Ensure the voltage is less than 5V for optimal performance and safety.



Image: Demonstrating the touch dimmer switch for turning the light on/off and adjusting brightness.

Your browser does not support the video tag.

Video: Demonstrating the operational features of the LocoLee Light Kit, including the touch dimmer.

5. MAINTENANCE

To ensure the longevity and optimal performance of your light kit, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to gently wipe the light components and wires. Avoid using liquid cleaners or abrasive materials.
- **Handling:** The wires and small parts are delicate. Avoid excessive pulling or bending of the wires during handling or repositioning of your LEGO model.
- **Storage:** If storing the light kit separately from the LEGO model, ensure it is kept in a dry, dust-free environment away from direct sunlight and extreme temperatures.

6. TROUBLESHOOTING

If you encounter any issues with your LocoLee Light Kit, please refer to the following common troubleshooting steps:

- **Lights Not Turning On:**
 - Ensure the USB power source is properly connected and functioning.
 - Verify that the voltage of the power source is less than 5V.
 - Check all wire connections to ensure they are secure and not damaged.
 - Perform the pre-installation test again on individual light components if possible.
- **Lights Not Dimming Properly:**
 - Ensure you are performing a long press on the touch dimmer switch to adjust brightness, not just a quick tap.
 - Confirm the power source is stable.
- **Flickering Lights:**
 - Check for loose connections.
 - Ensure the power supply is consistent and adequate.

If the issue persists after attempting these steps, please contact customer support for further assistance.

7. SPECIFICATIONS

Feature	Detail
Brand	LocoLee
Model Number	21357
Style	Standard Version
Material	High-quality copper lines and ABS plastic
Light Source Type	Light Emitting Diode (LED)
Voltage	Less than 5 Volts (USB powered)
Item Weight	3.2 ounces
Product Dimensions	6.06 x 1.24 x 3.98 inches
Country of Origin	China
Included Components	Light kit, Instruction Manual (online)

8. WARRANTY AND SUPPORT

Quality Guarantee

The LocoLee Light Kit is manufactured with high-quality copper lines and ABS plastic, undergoing thorough quality checks to ensure compatibility and durability with LEGO blocks. We are committed to providing the best lighting kit and improving our service.

Safety Information

This product contains small parts. To prevent accidental ingestion, keep out of reach of small children. Ensure proper installation and use only recommended power sources (USB, less than 5V).

Customer Support

If you have any questions or encounter issues with the product that are not resolved by the troubleshooting guide, please do not hesitate to contact our customer support team. We are available to assist you.

Contact information (e.g., email, website) can typically be found on the product packaging or the retailer's website.

© 2025 LocoLee. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B0F9WYY9J4>

More documents and user manuals: <https://manuals.plus/>