Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

EMKE 120x140cm

EMKE Bathtub Shower Screen 120x140cm Foldable 2-Part Instruction Manual

Model: 120x140cm

1. Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your EMKE 120x140cm Foldable 2-Part Bathtub Shower Screen. Designed for bathtubs, this screen offers reliable splash protection and defines shower areas. It features a frameless design with robust aluminum profiles and 6mm tempered safety glass with a nano-coating for easy cleaning. The integrated 4mm lift-and-lower mechanism ensures quiet operation and a watertight seal.

Please read these instructions carefully before installation and use to ensure safe and correct operation of the product. Keep this manual for future reference.



Figure 1: EMKE Bathtub Shower Screen in a bathroom setting.

2. Safety Instructions

- **Handle Glass with Care:** Tempered glass, while strong, can shatter if struck at the edges. Always handle glass panels carefully.
- **Two-Person Installation:** Due to the size and weight of the glass panels, installation requires at least two people to prevent injury and damage.
- **Wear Protective Gear:** Always wear safety gloves and eye protection during installation.
- **Proper Sealing:** Ensure all seals are correctly installed and watertight to prevent water leakage. Improper sealing can lead to water damage.
- **Secure Mounting:** The wall profile must be securely mounted to a solid wall structure. Use appropriate fasteners for your wall type.
- **Avoid Abrasive Cleaners:** Do not use abrasive cleaning agents or tools on glass or metal components, as this can damage surfaces and coatings.

3. Package Contents

Before beginning installation, verify that all components listed below are present and undamaged.

- Glass Panels (2 pieces, 6mm tempered safety glass)
- Wall Profile (Aluminum)
- Hinges and Fasteners
- Seals (for glass and bathtub edge)
- Mounting Screws and Wall Plugs
- Installation Manual (this document)



Figure 2: Key components and features: 6mm safety glass, 4mm lift-lower mechanism, high-quality hinges, and PVC seal.

4. Specifications

Model	120x140cm
Dimensions (Width x Height)	120 cm x 140 cm
Glass Thickness	6 mm Tempered Safety Glass
Material	Tempered Glass, Aluminum Profile
Finish	Glossy (Chrome fittings)
Lift-and-Lower Mechanism	4 mm
Wall Adjustment	Up to 10 mm
Weight	Approximately 26.64 kg
Number of Panels	2




Figure 3: Dimensional drawing of the shower screen. Please verify measurements before installation.

5. Setup and Installation

Tools Required (Not Included): Drill, spirit level, measuring tape, pencil, screwdriver, silicone sealant, utility knife.

1. **Preparation:**
   - Ensure the bathtub and surrounding wall area are clean, dry, and level.
   - Unpack all components and check against the package contents list.
2. **Marking Drill Holes:**
   - Position the wall profile against the wall at the desired height, ensuring it is perfectly vertical using a spirit level.
   - Mark the drill holes through the profile onto the wall.
3. **Drilling and Mounting Wall Profile:**

- Drill holes at the marked positions. Insert wall plugs.
- Attach the wall profile to the wall using the provided screws.

4. **Attaching the First Glass Panel:**
   - Carefully insert the first glass panel into the wall profile.
   - Secure the glass panel within the profile according to the specific fastening mechanism (e.g., set screws).
5. **Attaching the Second Glass Panel:**
   - Attach the hinges to the first glass panel.
   - Connect the second glass panel to the hinges. Ensure smooth movement.
6. **Applying Seals:**
   - Install the bottom seal along the edge of the glass panels where they meet the bathtub.
   - Apply silicone sealant along the exterior joint between the wall profile and the wall, and along the bottom edge where the screen meets the bathtub. Allow to cure completely before use.



Figure 4: Installation step: Securing the glass panel.

6. Operation

The EMKE Bathtub Shower Screen is designed for flexible use, allowing you to fold it away when not in use to maximize space.

- **Folding the Screen:** Gently push the outer glass panel inwards or outwards. The hinges allow the panels to swivel, enabling the screen to fold compactly against the wall or inwards over the bathtub.
- **Unfolding the Screen:** Pull the panels back into their extended position to create a full splash guard for showering.
- **Lift-and-Lower Mechanism:** The integrated 4mm lift-and-lower mechanism slightly raises the glass panels when opened and lowers them when closed. This protects the bottom seal from wear and ensures a quiet, smooth operation while maintaining a tight seal against the bathtub.



Figure 5: The swivel function allows the screen to open inwards or outwards.



Figure 6: The shower screen in its folded position.

7. Maintenance and Cleaning

- **Glass Cleaning:** The 6mm tempered safety glass features a nano-coating, making it water-repellent and reducing dirt buildup. Clean regularly with a soft cloth and mild, non-abrasive glass cleaner. Wipe dry to prevent water spots.
- **Profile and Hinge Cleaning:** Clean aluminum profiles and chrome hinges with a soft, damp cloth. Avoid harsh chemicals or abrasive sponges that can scratch the finish.
- **Seal Maintenance:** Regularly check the seals for wear or damage. Clean them gently to remove soap scum or mildew. Replace seals if they become brittle or damaged to maintain watertightness.
- **General Care:** After each use, rinse the screen with clean water to remove soap residue.

8. Troubleshooting

Problem	Possible Cause	Solution
Water leakage from the bottom or sides.	• Improperly installed or damaged seals. • Insufficient silicone sealant application. • Wall profile not perfectly vertical or securely mounted.	• Check and adjust all seals. Replace if damaged. • Reapply silicone sealant where necessary, ensuring a continuous, watertight bead. • Verify the wall profile's vertical alignment and secure mounting.
Screen panels do not fold smoothly or are stiff.	• Hinges are dirty or stiff. • Misalignment of panels.	• Clean hinges thoroughly. Apply a silicone-based lubricant if necessary (avoid oil-based lubricants). • Check that panels are correctly aligned and secured in their hinges.
Screen feels wobbly or unstable.	• Wall profile not securely fastened. • Loose connections at hinges or glass clamps.	• Tighten all screws on the wall profile. Ensure appropriate wall plugs were used. • Check and tighten all hinge and glass clamp screws.

9. Warranty and Support

The EMKE Bathtub Shower Screen is designed for long-term use, offering reliable performance for up to 2 years under normal conditions.

For any questions regarding installation, operation, maintenance, or if you encounter any issues not covered in this manual, please contact EMKE customer support. Our team is available to provide competent assistance.

Please refer to your purchase documentation for specific warranty terms and contact information.

© 2025 EMKE. All rights reserved.
This manual is subject to change without prior notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F9Y2JCNQ

More documents and user manuals: **https://manuals.plus/**