

EMKE 130x140cm 3-Panel

EMKE 130x140cm 3-Panel Foldable Bathtub Shower Screen Instruction Manual

Model: 130x140cm 3-Panel | Brand: EMKE

			Safety Instructions	Package		
Contents	Specifications	Setup	Operating	Maintenance	Troubleshooting	Warranty & Support

1. SAFETY INSTRUCTIONS

Please read all instructions carefully before installation and use. Failure to follow these instructions may result in injury or damage to the product.

- Always handle glass panels with care. Tempered safety glass, while strong, can shatter if struck forcefully at the edges.
- Ensure all mounting surfaces are structurally sound and capable of supporting the weight of the shower screen.
- Use appropriate personal protective equipment (PPE) during installation, including safety glasses and gloves.
- Installation should ideally be performed by two people due to the weight and size of the glass panels.
- Do not use abrasive cleaners or tools that could scratch the glass or metal components.
- Ensure all seals are properly installed to prevent water leakage.
- Keep children away from the installation area.

2. PACKAGE CONTENTS

Verify that all components are present before beginning installation.

- Glass panels (3 pieces)
- Seals
- Screws
- Wall profile

- Hinges



Image: Detailed view of the 6mm tempered safety glass, hinges, and PVC seals, highlighting key components.

3. SPECIFICATIONS

Feature	Detail
Brand	EMKE
Model Number	130x140cm 3-Panel (NFTSS13E-AVC)
Product Dimensions (L x W x H)	6 x 130 x 140 cm
Weight	29 kg

Feature	Detail
Material	6mm Tempered Safety Glass
Finish Type	Glossy
Door Style	Folding Doors
Number of Panels	3
Installation Type	Freestanding (Bathtub Mounted)
Color	Chrome

Abmessungen

Vor dem Kauf bitte die Größe überprüfen.

A	1190-1200	1290-1300
B	373	406
C	373	406
D	373	406
E	439-449	472-482
H	1400	1400

Einheit : mm

Image: Dimensional diagram of the shower screen, indicating overall width (A), panel widths (B, C, D), profile width (E), and height (H) in millimeters. Please verify dimensions before purchase.

4. SETUP (INSTALLATION)

Installation requires careful attention to detail. It is recommended that two people perform the installation.

1. Preparation:

- Unpack all components and check against the package contents list.
- Ensure the bathtub edge and adjacent wall are clean, dry, and level.
- Gather necessary tools (drill, level, measuring tape, screwdriver, silicone sealant, pencil).

2. Positioning the Wall Profile:

- Place the wall profile against the wall at the desired height, ensuring it is perfectly vertical using a spirit level.
- Mark the drilling points through the pre-drilled holes in the profile.
- Drill holes and insert wall plugs.
- Secure the wall profile to the wall with screws.

3. Attaching the First Glass Panel:

- Attach the first glass panel (the one connecting to the wall profile) to the wall profile according to the manufacturer's instructions, ensuring it is securely fastened.
- Apply silicone sealant along the bottom edge of the wall profile and where it meets the wall to ensure a watertight seal.

4. Assembling Folding Panels:

- Connect the remaining two glass panels using the provided hinges. Ensure the hinges allow for smooth folding action.
- Attach the assembled folding panels to the first fixed panel.
- Verify that the panels align correctly and fold smoothly.

5. Sealing:

- Install the PVC seals along the bottom edge of the glass panels where they meet the bathtub and between the glass panels to prevent water leakage.
- Apply a bead of silicone sealant along all external joints where the shower screen meets the wall and bathtub. Allow the sealant to cure completely before use (typically 24-48 hours).



Image: Visual guide illustrating the installation process, from attaching the wall profile to securing the glass panels and applying sealant.

5. OPERATING INSTRUCTIONS

The EMKE 3-panel foldable bathtub shower screen is designed for ease of use and efficient space management.

- **Folding Mechanism:** The shower screen features a 3-panel design that allows it to fold inwards or outwards, providing flexible access to your bathtub.
- **Swivel Function:** The panels can swivel to create a wider opening when entering or exiting the bathtub, or to fold neatly against the wall when not in use.
- **Lift-and-Lower Mechanism:** The integrated 4mm lift-and-lower mechanism protects the bottom seal, ensuring a quiet operation and a tight seal against the bathtub when closed.
- **Water Protection:** When showering, ensure all panels are extended to fully cover the bathtub opening to prevent water splashes.



Image: The shower screen panels shown in various folded positions, illustrating the swivel function and how they can open inwards or outwards.



Image: The EMKE shower screen in a fully folded position, demonstrating its compact storage against the wall when not in use.

6. MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and appearance of your shower screen.

- **Glass Cleaning:** The 6mm tempered safety glass features a nano-coating, making it water-repellent and reducing dirt buildup. Clean the glass regularly with a soft cloth and mild, non-abrasive glass cleaner. Avoid harsh chemicals or abrasive sponges that can damage the coating.
- **Profile and Hinge Cleaning:** Wipe down the aluminum profiles and chrome hinges with a soft, damp cloth. For stubborn spots, use a mild soap solution. Dry thoroughly to prevent water spots.
- **Seal Maintenance:** Periodically check the PVC seals for wear and tear. Clean them gently to remove any soap scum or mildew. Replace seals if they become damaged or lose their effectiveness to maintain a watertight enclosure.

- **Hinge Lubrication:** If hinges become stiff over time, apply a small amount of silicone-based lubricant to ensure smooth operation.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Water leakage from bottom or sides	Damaged or improperly installed seals; insufficient silicone sealant.	Check all seals for proper placement and condition. Reapply silicone sealant where necessary, ensuring a continuous bead along all contact points with the wall and bathtub. Replace worn seals.
Panels are difficult to fold or swivel	Hinges are dirty or require lubrication; misalignment of panels.	Clean hinges and apply a silicone-based lubricant. Check if panels are properly aligned and adjust if needed. Ensure no debris is obstructing the folding mechanism.
Glass appears cloudy or stained	Soap scum or hard water deposits.	Clean with a soft cloth and a mild glass cleaner. For hard water stains, use a vinegar-water solution, then rinse thoroughly. Avoid abrasive cleaners.
Screen feels unstable after installation	Wall profile not securely fastened; wall not structurally sound.	Re-check all screws securing the wall profile. Ensure they are tight. If the wall is not strong enough, consider reinforcing the mounting area or consulting a professional.

8. WARRANTY AND SUPPORT

EMKE offers a 2-year warranty for this product, ensuring long-term, worry-free use. For any questions, technical assistance, or warranty claims, please contact EMKE customer support. Our team is available to provide competent assistance. Please retain your proof of purchase for warranty purposes.

© 2023 EMKE. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F9Y2YTRJ>

More documents and user manuals: <https://manuals.plus/>