

UCOCARE M7

UCOCARE 4MP Mini 4G SIM Camera User Manual

Model: M7

INTRODUCTION

The UCO CARE M7 4MP Mini 4G SIM Camera is a portable and versatile security solution designed for both indoor and outdoor use. It operates on a 4G LTE network, eliminating the need for Wi-Fi, making it ideal for remote locations, RVs, camping, and other areas without traditional internet access. Featuring a high-capacity 5200mAh battery, 4MP video clarity, AI motion detection, and seamless remote access via a smartphone app, this camera provides reliable surveillance wherever you need it.

KEY FEATURES

- **Portable 4G Security:** Operates on 4G LTE network, no Wi-Fi required, offering flexible monitoring in remote areas.
- **Extended Battery Life:** Equipped with a powerful 5200mAh rechargeable battery for long-lasting protection and fewer recharges.
- **Superior 4MP Clarity:** Delivers 4MP video quality, twice as sharp as 1080P, with a 160° viewing angle and 10x digital zoom for detailed coverage.
- **Plug & Play with Included SIM:** Comes with a 4G SIM card and 7 days of free unlimited data for immediate remote monitoring. Compatible with major 4G operators.
- **Smart AI Motion Detection:** Advanced AI accurately detects relevant movements, reducing false alarms, and sends instant notifications to your smartphone.
- **Flexible Storage & Sharing:** Supports local storage via an SD card (up to 128GB, not included) and optional cloud storage with a 30-day free trial. Device access can be shared with family members.
- **Enhanced Night Vision:** Provides clear night vision up to 10 meters without red glare, ensuring visibility in low-light conditions.
- **Compact and Easy to Install:** Small, portable design allows for quick installation and easy transport for security anywhere.

PACKAGE CONTENTS

Verify that all items are present and in good condition upon opening the package.

- UCO CARE Mini 4G Camera (Model M7)
- 4G SIM Card (with 7 days free unlimited data)
- Mounting Bracket
- Charging Cable
- Screw Pack for Installation

PRODUCT OVERVIEW



Figure 1: The UCO CARE M7 4G SIM Camera, shown with its adjustable stand and an included 4G SIM card, ready for setup.

Piccolo e Portatile, Facile da Trasportare e Installare Ovunque



Figure 2: The compact size of the UCOCARE M7 camera allows for easy portability and versatile installation in various environments, including outdoor camping, RVs, and indoor spaces.

Nessuna Configurazione Necessaria SIM 4G Inclusa per un Utilizzo Immediato Ovunque



INCLUSO

Scheda SIM 4G

(7 Giorni di Dati Illimitati Gratuiti)

Altri Operatori Compatibili:

 **TIM**


vodafone


WINDTRE

iliad



 SFR

 O₂

 e-plus⁺

 T Mobile

 orange[™]

Figure 3: Close-up view of the UCOCARE M7 camera demonstrating the SIM card insertion process. The camera comes with a 4G SIM card and is compatible with various network operators.

Batteria Potenziata Progettata per Durare più a Lungo



A Batteria
senza Fili



Sempre Attivo
con Cavo

Ucocare



5200mAh
Capacità Maggiore

Altri



VS

500mAh
Capacità Inferiore

Figure 4: A visual comparison highlighting the UCO CARE M7's 5200mAh battery capacity against typical mini cameras with 500mAh, emphasizing its extended operational duration.

SETUP GUIDE

- 1. Charge the Camera:** Before first use, fully charge the camera using the provided charging cable. The charging indicator light will change once fully charged.
- 2. Insert SIM Card:** Locate the SIM card slot on the camera. Insert the provided 4G SIM card into the slot. Ensure it is inserted correctly according to the diagram on the camera or in the quick start guide.

3. **Power On:** Press and hold the power button until the indicator light turns on. The camera will initiate its startup sequence.
4. **Download the App:** Scan the QR code in the quick start guide or search for "UBoxPro" in your smartphone's app store (available for Android and iOS). Download and install the application.
5. **Pair the Camera:**
 - Open the UBoxPro app and create an account or log in.
 - Enable Bluetooth on your smartphone.
 - In the app, select "Add Device" or the "+" icon.
 - Follow the on-screen instructions to connect to the camera via Bluetooth. The app will guide you through the pairing process.
 - Once connected, the blue indicator light on the camera should remain solid.
6. **Mount the Camera:** Use the included mounting bracket and screw pack to install the camera in your desired location. The adjustable bracket allows for wall, ceiling, or tabletop mounting. Ensure the camera has a clear line of sight to the area you wish to monitor.

Configurazione Semplice, Accesso Immediato, Massima Tranquillità

Bastano pochi passaggi per gestire la videocamera ovunque ti trovi.



Passaggio 1
Scarica l'app "UBoxPro" e attiva il Bluetooth.



Passaggio 2
Inserisci la scheda SIM fornita.



Passaggio 3
Dopo l'accensione e il reset, attendi che la spia blu rimanga fissa.



Passaggio 4
Scansiona con l'app il codice di configurazione sul retro del dispositivo.

Figure 5: Visual guide illustrating the simple four-step setup process: 1. Download the UBoxPro app and enable Bluetooth. 2. Insert the provided SIM card. 3. Power on and wait for the blue light to stabilize. 4. Scan the configuration QR code in the app to complete pairing.

OPERATING INSTRUCTIONS

Real-time Monitoring

Once the camera is paired and connected to the 4G network, you can view live footage from anywhere using the UBoxPro app.

- Open the UBoxPro app on your smartphone.
- Select your camera from the device list to access the live view.
- You can use on-screen controls for digital zoom (up to 10x) and to capture screenshots or record video manually.

Monitoraggio Video in Tempo Reale Sempre e Ovunque dal tuo Smartphone



Figure 6: The UBoxPro app interface displaying real-time video monitoring, motion detection alerts, event video playback, remote viewing capabilities, and multi-user access options.

Motion Detection and Alerts

The camera features advanced AI motion detection to alert you to significant activity.

- **Enable Alerts:** In the UBoxPro app settings for your camera, ensure motion detection alerts are enabled.
- **Sensitivity Adjustment:** Adjust the motion detection sensitivity to minimize false alarms. You can set it to low, medium, or high based on your environment.
- **Scheduled Detection:** Configure specific time periods for motion detection to be active, optimizing battery life and reducing

unnecessary alerts.

- When motion is detected, you will receive an instant push notification on your smartphone.
- Tapping the notification will take you directly to the live view or the recorded event clip.

Notifiche Istantanee al Rilevamento di Movimento
Controllo da Remoto Ovunque tu Sia

Rilevamento del Movimento **Avviso Tramite App** **Visualizzazione Remota** **Clip Video di Movimento**

Box **Telecamera 4G**
Attività Rilevata

The advertisement features a background image of a blue and black kite flying in a clear sky over a lush green field. In the foreground, a man in a plaid shirt and a young girl in a green outfit are running together, holding a string. A wooden picnic table with lemons is visible on the left. The text is overlaid in white and blue, with icons for motion detection, app notification, remote viewing, and video clips. A logo for 'Box Telecamera 4G' is in the bottom left corner.

Figure 7: An example of an instant motion detection notification received on a smartphone, indicating activity detected by the UCO CARE 4G camera, allowing for immediate remote control and viewing of video clips.

Video Storage and Playback

The camera supports two methods for video storage:

- **Local Storage (SD Card):** Insert a microSD card (up to 128GB, not included) into the camera's SD card slot for local recording of motion-triggered events.
- **Cloud Storage:** The camera offers an optional cloud storage service with a 30-day free trial. After the trial, you can subscribe to a plan via the app for continuous cloud backup.
- To view recorded footage, navigate to the "Playback" or "Events" section within the UBoxPro app. You can filter by date and time to find specific events.

Riproduzione Istantanea dei Momenti Importanti

Registra gli eventi all'istante e rivedili in qualsiasi momento per restare sempre informato e in controllo.

The screenshot displays a horizontal timeline of four video thumbnails with timestamps: 21:29, 19:10, 09:15, and 06:57. Below the timeline are two blue callout boxes: 'Fino a 128 GB Memoria su scheda (Non inclusa)' and 'Prova di 30 giorni Archiviazione cloud (Opzionale)'. On the right, a smartphone screen shows the app's playback interface with a video player, a date selector set to '2025-05-28', and a 'Attività rilevata' section.

Figure 8: The app's interface for instant playback of recorded events, showing a timeline of activities and options for storage, including local SD card storage (up to 128GB) and optional cloud storage with a 30-day free trial.

Multi-User Access

You can share access to your camera with family members or trusted individuals.

- In the UBoxPro app, go to the camera settings and look for "Share Device" or "Multi-User Access."
- Follow the instructions to invite others to view the camera feed. They will need to download the UBoxPro app and create an account.

Accesso Multiutente per il Controllo dell'Intera Famiglia

Condividi l'accesso con la tua famiglia per mantenere tutti connessi e protetti ovunque si trovino.

The illustration features a smartphone displaying a family of four and a dog in a field. To the right, a world map is overlaid with five circular avatars representing users in different geographical locations. Above the map are two blue callout boxes: 'Condivisione Utente Illimitata' and '5 Utenti Online'.

Figure 9: Illustration of the multi-user access feature, allowing unlimited user sharing and up to 5 simultaneous online users to monitor the camera from various locations globally.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the camera lens and body. Do not use liquid cleaners or aerosols.
- **Battery Care:** To prolong battery life, avoid extreme temperatures. Recharge the camera when the battery level is low. The camera can operate while charging.
- **Firmware Updates:** Periodically check the UBoxPro app for available firmware updates. Keeping the firmware updated ensures optimal performance and security.
- **Storage Management:** If using an SD card, regularly back up important footage and format the card to maintain performance. For cloud storage, ensure your subscription is active.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Camera not powering on.	Low battery; Power button not pressed correctly.	Charge the camera fully. Press and hold the power button for a few seconds until the indicator light appears.
No 4G signal or offline.	SIM card not inserted correctly; No network coverage; SIM card data plan expired.	Reinsert the SIM card. Move the camera to an area with better 4G coverage. Check your SIM card data plan status and recharge if necessary.
Cannot pair with app.	Bluetooth not enabled; Incorrect pairing steps; App version outdated.	Ensure Bluetooth is enabled on your phone. Follow the setup guide steps carefully. Update the UBoxPro app to the latest version.
Frequent false motion alerts.	Motion sensitivity too high; Environmental factors (e.g., moving branches, shadows).	Adjust the motion detection sensitivity in the app settings to a lower level. Utilize the scheduled detection feature to activate alerts only when needed.
Poor video quality.	Dirty lens; Low light conditions; Network bandwidth issues.	Clean the camera lens with a soft cloth. Ensure adequate lighting for optimal day vision. Check 4G signal strength; a weak signal can affect streaming quality.

SPECIFICATIONS

Feature	Detail
Brand	UCOCARE
Model Name	M7
Indoor/Outdoor Use	Outdoor, Indoor
Compatible Devices	Smartphone (Android, iOS)
Power Source	Battery Powered
Connection Protocol	Cellular (4G LTE)
Mounting Type	Wall, Ceiling, Tabletop (Self-adhesive, Freestanding, Screw-in)
Video Capture Resolution	4MP (2560 x 1440)

Feature	Detail
Included Components	Mini 4G Camera, 4G SIM Card, Mounting Bracket, Charging Cable, Screw Pack, User Manual
Wireless Communication Technology	Cellular
Viewing Angle	160 Degrees
Night Vision Range	10 Meters (33 feet)
Material	Plastic
Voltage	5 Volts
Battery Capacity	5200 mAh
Item Dimensions (LxWxH)	5.8 x 3.8 x 3.8 cm (2.28 x 1.5 x 1.5 inches)
Item Weight	284 grams (0.63 lbs)
Battery Type	Lithium Ion (1 included)
Special Features	4MP HD Resolution, 40 Meter Visual Range, 160° Wide Angle, 10x Digital Zoom, Motion Detection, 10 Meter Night Vision, Portable Wireless
Recommended Uses	Pet Monitoring, Baby Monitoring, Outdoor Security, Indoor Security

WARRANTY AND SUPPORT

UCOCARE is committed to providing high-quality security products and excellent customer service.

- **Quality Assurance:** All UCOCARE products undergo rigorous testing and inspection before shipment to ensure they meet high factory standards and certifications (CE, FCC, ROHS).
- **Customer Satisfaction:** Our professional technical support team is dedicated to resolving any issues you may encounter, ensuring 100% satisfaction.
- **Privacy Protection:** Your video data is protected with financial-grade encryption, ensuring it is secure from theft and damage. Your data remains private and accessible only with your permission.
- **Returns:** This product is eligible for a refund/replacement within 14 days of purchase, as per Amazon's return policy.

For technical assistance or warranty claims, please contact UCOCARE customer support through the contact information provided in your product packaging or via the UCOCARE store on Amazon.

Soddisfazione Garantita al 100%

Il nostro team tecnico professionale è sempre pronto a risolvere eventuali problemi per garantire la tua soddisfazione al 100%.



Figure 10: UCOCARE's dedicated customer support team is available to assist with any product-related inquiries or issues, ensuring complete customer satisfaction.

© 2025 UCOCARE. All rights reserved.

Related Documents

<p>SECURITY CAMERA <i>Indoor</i></p>  <p>B1-EN-V1</p> <p>Quick Installation Guide</p> <p><small>Thank you for choosing our security camera. Please read the quick installation guide carefully before using and install it in your environment.</small></p>	<p>UCOCARE Baby Camera B1: Installation and Troubleshooting Guide</p> <p>Comprehensive guide for installing and troubleshooting the UCOCARE Baby Camera Model B1, covering setup, connectivity, motion detection, and common issues.</p>
<p>Wireless Battery Powered Camera Quick Start Guide</p>  <p>W</p>	<p>UCOCARE Wireless Battery Powered Camera: Quick Start Guide</p> <p>A quick start guide for the UCOCARE Wireless Battery Powered Camera. Learn how to set up the camera, install the bracket and solar panel, configure network settings, manage motion detection, store and playback recordings, share camera access, and troubleshoot common issues.</p>