



[Manuals.plus](#) /

> [VEVOR](#) /

> VEVOR JWM-331 1/2 HP Continuous Feed Garbage Disposer Instruction Manual

VEVOR JWM-331

VEVOR JWM-331 1/2 HP Continuous Feed Garbage Disposer Instruction Manual

Model: JWM-331 | Brand: VEVOR

1. INTRODUCTION

This manual provides essential information for the safe and efficient installation, operation, and maintenance of your VEVOR JWM-331 1/2 HP Continuous Feed Garbage Disposer. Please read all instructions carefully before use and retain this manual for future reference.



Image 1.1: The VEVOR JWM-331 Garbage Disposer shown with its main unit and various installation components.

2. SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury. This disposer is designed for household use only.

- **Electrical Safety:** Ensure the power supply matches the disposer's requirements. Do not operate with a damaged cord or plug. Disconnect power before attempting to clear a jam or service the unit.
- **Water Safety:** Do not immerse the disposer in water. Ensure all plumbing connections are secure to prevent leaks.
- **Personal Safety:** Never put hands or fingers into the disposer opening. Use the stopper or a long utensil to push food into the disposer. Always wear appropriate personal protective equipment during installation.
- **Child Safety:** Keep children away from the disposer and its controls.
- **Prohibited Items:** Do not dispose of glass, metal, plastic, large bones, fibrous materials (e.g., corn husks, artichokes), harsh chemicals, or hot grease into the disposer.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- 1 x VEVOR JWM-331 Garbage Disposer Unit
- 1 x User Manual
- 1 x Drain Stopper
- 1 x Drain Elbow
- 1 x Gasket
- 1 x Sealing Ring
- 1 x Connector
- 1 x Connector Sealing Ring
- 2 x Screws
- 1 x Hex Key

VEVOR
TOUGH TOOLS, HALF PRICE



1 x User Manual



1 x Drain Elbow



1 x Gasket



1 x Drain Stopper



1 x Sealing Ring



1 x Connector



2 x Screws



1 x Hex Key



1 x Connector Sealing Ring



Item Model Number: **JWM-331**

Horsepower: **1/2 HP**

Motor Type: **DC Motor**

Noise Level: **≤65dB**

Main Materials: **ABS + Stainless Steel**

Product Weight: **9.96lbs / 4.52kg**

Product Dimensions:

7.28" x 7.28" x 14.57" / 185 x 185 x 370 mm

Image 3.1: A visual representation of all components included with the VEVOR JWM-331 Garbage Disposer, including the main unit, user manual, drain stopper, drain elbow, various rings, screws, and a hex key.

4. SETUP AND INSTALLATION

The VEVOR JWM-331 features a 3-bolt mounting system for secure installation. Professional installation is recommended if you are unfamiliar with plumbing or electrical work. Ensure power to the sink area is turned off at the circuit breaker before starting.

4.1 Preparing the Sink Drain

1. Remove any existing sink drain assembly. Note that some existing assemblies may have a retaining ring that needs to be removed to separate the sink drain from the mount flange.
2. Clean the sink flange opening thoroughly.
3. Install the new sink flange and rubber gasket into the sink opening, securing it from below with the provided mounting hardware.

4.2 Mounting the Disposer Unit

1. Align the disposer unit with the mounting assembly under the sink.
2. Twist the disposer unit to lock it into the 3-bolt mounting system. Ensure it is securely seated and tightened.

3-BOLT MOUNTING SYSTEM

Tight connection, no leaks



Image 4.1: A person demonstrating the installation of the disposer unit by twisting it into the 3-bolt mounting system under a kitchen sink.

4.3 Plumbing Connections

1. Connect the drain elbow to the disposer's discharge outlet using the provided gasket and screws.
2. Connect the other end of the drain elbow to your household drain pipe. Ensure all connections are watertight.
3. If connecting to a dishwasher, remove the knockout plug from the disposer's dishwasher inlet port.



Image 4.2: The VEVOR JWM-331 Garbage Disposer fully installed under a sink, showing the connection to the drain pipe and the compact footprint.

4.4 Electrical Connection

The disposer comes with a power cord. Plug the cord into a grounded 120V AC outlet. If a dedicated outlet is not available, consult a qualified electrician for proper wiring.

5. OPERATING INSTRUCTIONS

The VEVOR JWM-331 is a continuous feed disposer, designed for efficient and quiet operation.

5.1 Grinding Food Waste

1. Turn on the cold water faucet to a moderate flow.
2. Turn on the disposer using its power switch.
3. Slowly feed food waste into the sink opening. The 1/2 HP DC motor with 3450 RPM ensures quick and efficient grinding of various food scraps, including vegetables, chicken bones, fish bones, fruit pits, and nuts.

4. Allow the disposer to run until all food waste is ground and only the sound of the motor and running water is heard.
5. Turn off the disposer, then turn off the cold water after a few seconds to flush the drain line.



Image 5.1: An illustration showing the continuous feeding of food waste, such as vegetables, chicken bones, and fruit pits, into the disposer for efficient grinding.

5.2 Quiet Operation

This disposer incorporates multiple noise reduction features, including a splash guard, soundproof cotton, and a thickened ABS shell, to ensure quiet operation even during use.

TRIPLE NOISE REDUCTION

Enjoy a peaceful time in kitchen



Image 5.2: A cutaway diagram highlighting the splash guard, soundproof cotton, and thickened ABS shell that contribute to the disposer's quiet performance.

6. MAINTENANCE

Regular maintenance helps ensure the longevity and optimal performance of your VEVOR JWM-331 Garbage Disposer.

- **Cleaning:** To clean the disposer, grind small bones or ice cubes to scour the grinding chamber. Follow with a citrus peel (lemon, orange) to freshen the scent.
- **Splash Guard:** Periodically remove and clean the splash guard to prevent buildup and ensure proper drainage.
- **Durable Construction:** The disposer is built with a rust-proof ABS housing and stainless steel grinding components for durability and corrosion resistance.

PREMIUM ABS & STAINLESS STEEL MATERIAL

Waterproof, corrosion-resistant, longer lifespan



Image 6.1: A detailed cutaway view of the disposer, illustrating the robust ABS shell and the durable stainless steel grinding disc designed for long-term use.

7. TROUBLESHOOTING

Before calling for service, review the following common issues and solutions:

Problem	Possible Cause	Solution
Disposer does not start	No power; Overload protector tripped	Check circuit breaker. Press the red reset button on the bottom of the disposer.
Disposer hums but does not grind	Jam in grinding chamber	Turn off power. Use the hex key (provided) to insert into the center hole on the bottom of the disposer and turn back and forth to free the jam. Remove object with tongs.
Leaking under sink	Loose plumbing connections; Improperly seated gaskets	Check and tighten all plumbing connections. Ensure gaskets are correctly installed and not damaged.

Problem	Possible Cause	Solution
Slow grinding or poor performance	Excessive food waste; Dull grinding components	Feed waste slowly. Grind ice cubes or small bones to help clean and sharpen grinding elements.

8. SPECIFICATIONS

Key technical specifications for the VEVOR JWM-331 Garbage Disposer:

Feature	Detail
Item Model Number	JWM-331
Horsepower	1/2 HP
Motor Type	DC Motor
Motor Speed	3450 RPM
Noise Level	≤65 dB
Main Materials	ABS + Stainless Steel
Product Weight	11.02 lbs / 4.52 kg
Product Dimensions (L x W x H)	7.28 x 7.28 x 14.57 inches (185 x 185 x 370 mm)



1 x User Manual



1 x Drain Elbow



1 x Gasket



1 x Drain Stopper



1 x Sealing Ring



1 x Connector



2 x Screws



1 x Hex Key



1 x Connector Sealing Ring



Item Model Number: **JWM-331**

Horsepower: **1/2 HP**

Motor Type: **DC Motor**

Noise Level: **≤65dB**

Main Materials: **ABS + Stainless Steel**

Product Weight: **9.96lbs / 4.52kg**

Product Dimensions:

7.28" x 7.28" x 14.57" / 185 x 185 x 370 mm

Image 8.1: A graphic detailing the physical dimensions and key specifications of the VEVOR JWM-331 Garbage Disposer.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official VEVOR website. Keep your purchase receipt as proof of purchase.