

Vicco 27390

Vicco Viktor Washing Machine Cabinet Instruction Manual

Model: 27390 | Brand: Vicco

1. INTRODUCTION

The Vicco Viktor washing machine cabinet is designed to provide a stylish and practical solution for your laundry area or bathroom. This cabinet offers optimal design and universal utility, enhancing the functionality and aesthetics of your space. Please read this manual carefully before assembly and use to ensure safe and correct installation and operation.

2. SAFETY INFORMATION

Important! Retain these instructions for future reference. Read carefully!

Tipping Hazard Warning:

Unanchored furniture can tip over. To prevent this furniture from tipping, it **must be anchored to the wall**. Appropriate wall mounting hardware suitable for your home's walls should be used. If you have questions regarding suitable hardware or installation, consult your local specialized dealer.

- Always follow each step of the assembly instructions carefully.
- Keep all small parts and packaging materials away from children.
- Ensure the cabinet is placed on a level and stable surface.
- Do not overload the cabinet or place excessively heavy items on top, exceeding the maximum weight capacity.

3. PACKAGE CONTENTS

Before beginning assembly, please check that all parts are present and undamaged. The package typically includes:

- Washing machine cabinet components (engineered wood panels)
- Assembly instructions
- Mounting hardware (screws, dowels, connectors)

Note: Decorative items shown in product images are not included.

4. SETUP AND ASSEMBLY

Assembly of the Vicco Viktor washing machine cabinet is designed to be straightforward. Please follow the detailed assembly instructions provided in your package step-by-step. Below are general guidelines:

1. **Unpack:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Match all components and hardware against the parts list in the assembly instructions.
3. **Assemble Frame:** Begin by assembling the main frame of the cabinet using the provided connectors and screws. The cabinet is constructed from 16mm thick particle board.
4. **Install Top Panel:** Secure the top panel (in golden oak finish) to the assembled frame.
5. **Positioning:** Once assembled, carefully position the cabinet over your washing machine. Ensure there is adequate clearance around the machine for ventilation and access.
6. **Wall Anchoring:** This is a critical safety step. Using the provided wall anchoring hardware, secure the cabinet to a sturdy wall. Choose appropriate wall plugs and screws for your specific wall type (e.g., concrete, drywall). If unsure, consult a professional.



Figure 4.1: Cabinet dimensions (68 cm width, 60 cm depth, 88.2 cm height).



Figure 4.2: The assembled cabinet structure, ready for placement.

5. OPERATING INSTRUCTIONS

The Vicco Viktor cabinet is designed to integrate seamlessly with your washing machine, providing a functional countertop and enhancing the aesthetic of your laundry space.

- **Placement:** Position the cabinet over your front-loading washing machine. Ensure the machine fits comfortably within the cabinet's internal dimensions.
- **Countertop Use:** The golden oak top surface can be used for placing laundry essentials, decorative items, or for folding clothes. The maximum weight capacity for the top surface is 15 kg.
- **Accessibility:** Ensure the washing machine door can open fully and that detergent dispensers are accessible without obstruction from the cabinet.



Figure 5.1: Cabinet in use with a washing machine, showcasing its functional design.



Figure 5.2: Detail of the cabinet's top surface, suitable for various items.

6. MAINTENANCE

To ensure the longevity and appearance of your Vicco Viktor washing machine cabinet, follow these simple maintenance guidelines:

- **Cleaning:** The engineered wood surfaces are easy to maintain. Wipe regularly with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Spills:** Immediately wipe up any liquid spills to prevent moisture absorption and potential damage to the particle board.
- **Wall Anchors:** Periodically check the wall anchoring hardware to ensure it remains secure. Tighten screws if necessary.
- **Avoid Direct Heat/Moisture:** While designed for a bathroom environment, avoid prolonged exposure to excessive moisture or direct heat sources.

7. TROUBLESHOOTING

If you encounter any issues with your Vicco Viktor washing machine cabinet, consider the following:

- **Cabinet Instability:** If the cabinet feels wobbly, ensure all assembly screws are tightened. Crucially, verify that the cabinet is properly anchored to the wall as per the safety instructions.
- **Missing or Damaged Parts:** If you find any parts missing or damaged upon unpacking, do not proceed with assembly. Contact your retailer or Vicco customer support for replacements.
- **Assembly Difficulties:** Re-read the assembly instructions carefully. Sometimes a small detail can be overlooked. Ensure all components are oriented correctly.

8. SPECIFICATIONS

Brand	Vicco
Model Number	27390
Color	Anthracite/Golden Oak
Material	Engineered Wood (16mm particle board)
Product Dimensions (L x W x H)	60 x 68 x 88.2 cm (Depth x Width x Height)
Item Weight	16.3 Kilograms
Maximum Weight Capacity (Top Surface)	15 Kilograms
Recommended Use	Washing Machine Cabinet

9. WARRANTY

Warranty information for the Vicco Viktor washing machine cabinet is not specified in the provided product details. Please refer to your purchase documentation, receipt, or contact the retailer from whom you purchased the product for specific warranty terms and conditions.

10. SUPPORT

For any questions, concerns, or assistance regarding the assembly, parts, or use of your Vicco Viktor washing machine cabinet, please contact:

- Your retailer or point of purchase.
- The Vicco customer service department (contact details may be available on the Vicco website or through your retailer).

Please have your model number (27390) and purchase information ready when contacting support.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question