

ZMISHIBO ZMF23YDBK01

ZMISHIBO 23-inch Low Profile Ceiling Fan with Light and Remote

Model: ZMF23YDBK01

INTRODUCTION

Thank you for choosing the ZMISHIBO 23-inch Low Profile Ceiling Fan with Light and Remote. This manual provides essential information for the safe installation, operation, and maintenance of your new ceiling fan. Please read it thoroughly before use and retain it for future reference.

This ceiling fan features an integrated LED light source with adjustable brightness and color temperature, a reversible DC motor with 6-speed settings, and dual control options via remote and Bluetooth-enabled app. Its low-profile design is suitable for various indoor spaces.

SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or personal injury, always follow these basic precautions:

- Read all instructions carefully before beginning installation.
- Ensure the power is turned off at the circuit breaker or fuse box before wiring.
- All wiring must be in accordance with national and local electrical codes. If you are unfamiliar with wiring, consult a qualified electrician.
- The mounting structure must be capable of supporting the weight of the fan (approximately 6.6 pounds).
- Do not operate the fan with damaged wiring or if it has been dropped or damaged in any way.
- Keep hands, clothing, and other objects clear of the fan blades when the fan is operating.
- Do not use a dimmer switch or a fan's gear switch for wall control, as this product is designed for a conventional ON/OFF switch.

PACKAGE CONTENTS

Verify that all components are present before installation:

- Ceiling Fan Unit with Integrated LED Light
- Remote Control

- Mounting Hardware (screws, wire nuts, etc.)
- Instruction Manual

SPECIFICATIONS

Brand	ZMISHIBO
Model Number	ZMF23YDBK01
Size	23 inches (Diameter)
Color	Black
Product Dimensions	17"D x 7.5"W x 13"H (Note: This may refer to packaging or a specific component. The fan's diameter is 23 inches.)
Item Weight	6.6 pounds
Power Source	DC
Wattage	65 watts
Noise Level	45 dB (Fan lamp operation: 30dB)
Number of Speeds	6
Light Color Temperature	3000K (Warm White) - 7000K (Cool White)
Light Brightness	14% to 100% Dimmable
Control Method	Remote Control, Bluetooth APP
Motor Type	Brushless DC Motor
Recommended Room Size	Height: 7FT-10FT, Length & Width: 9FT x 9FT

Note: The product dimensions (17"D x 7.5"W x 13"H) provided in the specifications may refer to packaging or a different measurement. The fan's diameter is 23 inches.



Image: A diagram illustrating the product dimensions (23" diameter, 16.5" height, 5.5" depth) and recommended room sizes for optimal

performance.

SETUP AND INSTALLATION

Installation should be performed by a qualified individual. Ensure power is disconnected at the circuit breaker before proceeding.

Installation Steps:

1. **Prepare Mounting Location:** Ensure the electrical box is securely mounted and capable of supporting the fan's weight.
2. **Assemble Fan Components:** Follow the instructions to attach any necessary parts to the main fan body.
3. **Wiring:** Connect the fan's electrical wires to the household wiring according to local electrical codes. This typically involves connecting live, neutral, and ground wires.
4. **Secure Fan to Ceiling:** Mount the fan unit to the electrical box using the provided hardware.
5. **Connect Terminal Connectors:** Insert the three terminal connectors for the light and fan components.
6. **Test Functionality:** Restore power and test the fan and light functions using the remote control.

Your browser does not support the video tag.

Video: ZMISHIBO Ceiling Fan Installation Guide. This video demonstrates the steps for installing the ceiling fan, including wiring and connecting terminal connectors.



Image: Diagram showing the remote control and smartphone app for controlling the fan and light. It also indicates that a conventional wall switch can be used for ON/OFF, but dimmer switches are not compatible.



Image: Illustration showing compatible (conventional ON/OFF) and incompatible (dimmer or fan gear) wall switches for the ceiling fan.

OPERATING INSTRUCTIONS

Your ZMISHIBO ceiling fan can be controlled via the included remote control or a Bluetooth-enabled smartphone application.

Remote Control Functions:

- **Light ON/OFF:** Toggles the LED light.
- **Fan ON/OFF:** Toggles the fan motor.
- **Fan Speed Adjustment:** Select from 6 fan speeds (1-6).
- **Color Temperature Adjustment:** Cycles through warm white (3000K), natural (4500K), and cool white (7000K).
- **Brightness Adjustment:** Dims or brightens the light from 14% to 100%.
- **Timer Setting:** Set the fan to turn off automatically after 2, 4, or 8 hours.
- **F/R Reverse Function:** Changes the direction of fan blade rotation for summer (downward airflow) or winter (upward airflow).
- **Code Pair:** Used to pair the remote with the fan.

APP Control Functions:

Download the "Fanlamp Pro" app from Google Play or the Apple App Store. Ensure Bluetooth is enabled on your device for pairing.

- Adjust light color temperature and brightness.
- Control fan speed and direction.
- Set timers.
- Independent operation of fan and light.

Light Memory Function:

The fan's light has a memory function that recalls the last brightness and color temperature setting. This setting will not be memorized if the wall switch is turned on within 10 seconds of being turned off.

Reversible Motor Operation:

- **Summer Mode (Forward Cool Airflow):** Blades rotate counter-clockwise to create a downward breeze, providing a

cooling effect.

- **Winter Mode (Reverse Warm Airflow):** Blades rotate clockwise to draw warm air up towards the ceiling and circulate it downwards, helping to distribute heat.

Your browser does not support the video tag.

Video: ZMISHIBO Product Overview. This video showcases the various features and operational aspects of the ceiling fan, including light and fan speed adjustments.



Image: Visual representation of the fan's control options, highlighting features like code pairing, bright setting, customizable light, 6 fan speeds, F/R reverse function, and timer setting.



Image: Demonstrates the three available color temperatures (3000K Warm, 4500K Nature, 7000K White) and the 14%-100% smooth dimming capability of the integrated LED light.

6 Fan Speeds Adjustable



Image: Illustrates the reversible motor function, showing how the fan provides cooler air in summer (downward airflow) and warmer air in winter (upward airflow).

Robust Iron Frame:

Built for Lasting Durability



Image: Depicts the 6 adjustable fan speeds, ranging from soft wind to cool wind, allowing for customized airflow.

Noiseless Fan Technology:

Silence Redefined for Peaceful Living



Image: Shows the timer setting feature, allowing users to set the fan to turn off automatically after a specified duration.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Dust the fan blades and light fixture periodically with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Tighten Fasteners:** Check all screws and fasteners annually to ensure they are secure.
- **No Lubrication Required:** The motor is permanently lubricated and does not require oiling.
- **Light Source:** The LED light source is integrated and not user-replaceable. Contact support if the light fails.

Always ensure power is disconnected before performing any cleaning or maintenance.

TROUBLESHOOTING

If you experience issues with your ceiling fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start.	No power, loose wiring, remote not paired.	Check circuit breaker. Ensure all wiring connections are secure. Re-pair the remote control with the fan.
Light does not turn on.	No power, loose wiring, LED failure.	Verify power supply. Check light wiring connections. If LED is faulty, contact customer support.
Fan makes excessive noise.	Loose screws, unbalanced blades, motor issue.	Ensure all mounting screws are tight. Check for any obstructions. If noise persists, contact support.
Remote control not working.	Dead batteries, remote not paired, signal interference.	Replace remote batteries. Re-pair the remote. Ensure no obstructions between remote and fan.
Fan airflow is weak.	Incorrect fan direction (winter mode in summer), low speed setting.	Ensure fan is set to summer mode for downward airflow. Increase fan speed.

WARRANTY AND SUPPORT

ZMISHIBO Ceiling Fans with Light come with a**2-year support period**. We are committed to providing high-quality products and customer satisfaction.

If you encounter any issues or have questions regarding your product, please contact ZMISHIBO customer service. Please have your model number (ZMF23YDBK01) and purchase information ready when contacting support.

For further assistance, you may visit the official ZMISHIBO store on Amazon:[ZMISHIBO Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question