Coucur Y66

Coucur Y66 Smart Watch User Manual

Model: Y66

Introduction

This manual provides detailed instructions for the Coucur Y66 Smart Watch. Please read it carefully to ensure proper use and to fully utilize all features of your device. Keep this manual for future reference.

Package Contents

- 1.96" HD Smart Watch
- Silicone Bracelet
- Magnetic Charging Cable
- English User Manual

Setup

1. Initial Charging

Before first use, charge the smart watch for at least 1 hour. If the battery is completely drained, charge for at least 30 minutes before powering on. Use the provided magnetic charging cable.



Image: The Coucur Y66 Smart Watch connected to its magnetic charging cable, illustrating the charging process.

2. App Download and Pairing

To connect your smart watch, download the "GloryFit" app from the Google Play Store or Apple App Store.

1. Turn on the Bluetooth function on your smartphone.
2. Open the "Google Play" or "App Store" on your phone.
3. Search for "GloryFit" app and download it.
4. Open the GloryFit app. In the app, click "Connect device", then "Select device", find "Y66" and bind it.
5. After selecting "Y66" to connect, respond to the mobile phone system pop-up pairing request by selecting "pair".




Image: A visual guide demonstrating the steps to connect the Coucur Y66 Smart Watch to a smartphone via the GloryFit app, including Bluetooth activation and device pairing.

3. Enabling Call Function

To use the call answering and making features:

1. After successful pairing, turn on the Bluetooth Call switch on the watch. This is necessary for making calls and playing media sound through the watch.
2. In your phone's Bluetooth settings, ensure that the Y66 device is connected and grant necessary permissions for calls.
3. Once connected, you can use the watch to answer or make calls.



Image: A series of screenshots illustrating the process of enabling the Bluetooth call function on the Coucur Y66 Smart Watch and granting phone permissions.

Operating Instructions

1. Display and Navigation

The Coucur Y66 features a 1.96-inch HD full touch color screen. Swipe across the screen to navigate menus and access various functions. The side button typically serves as a power/wake button and a return-to-home function.



Image: The Coucur Y66 Smart Watch displaying the time, date, and activity metrics on its 1.96-inch HD screen.

2. Call and Notification Features

Once connected via Bluetooth, the watch allows you to answer or make calls directly from your wrist. It also displays notifications from social media applications such as Facebook, WhatsApp, Instagram, and Twitter. These notifications are delivered via vibrating alerts.



Image: A user interacting with the Coucur Y66 Smart Watch to manage calls and view message notifications from various social media platforms.

3. Watch Face Customization

The GloryFit app offers over 200 free personalized watch faces. You can also upload your favorite photos to use as a custom watch face background.



Image: The Coucur Y66 Smart Watch displaying different customizable watch faces, including options to use personal photos.

4. Fitness Tracking

The watch tracks various fitness metrics throughout the day, including steps, distance, and calories burned. This data is synchronized with the GloryFit app for detailed analysis.



Image: A person running while wearing the Coucur Y66 Smart Watch, with an overlay showing fitness data such as steps, distance, and calories burned.

5. Health Monitoring

The Coucur Y66 is equipped with high-performance optical sensors for continuous health monitoring. It accurately tracks:

- **Heart Rate:** Real-time monitoring of your heart rate.
- **Blood Oxygen:** Measures blood oxygen levels.
- **Stress Levels:** Provides insights into your stress.
- **Sleep Status:** Monitors sleep patterns, including deep sleep, light sleep, and awake times.

You can view weekly health reports within the GloryFit app.



Image: Displays of the Coucur Y66 Smart Watch showing heart rate monitoring and sleep tracking data, alongside images of users engaged in activities and sleeping.

6. Sport Modes

The watch supports over 110 sport modes, including running, walking, hiking, basketball, boating, climbing, cycling, and football. During exercise, it records real-time data such as heart rate, steps, calories burned, and distance.



Image: A visual representation of the Coucur Y66 Smart Watch's extensive list of over 110 sport modes, with a user playing tennis.

7. Additional Functions

The Coucur Y66 Smart Watch includes various other useful features:

- Timer
- Stopwatch
- Alarm Clock
- Sedentary Reminder
- Music Control
- Weather Forecast
- Camera Control
- Calculator
- Voice Assistant
- Flashlight
- Find Phone

- Women's Health Tracking



Image: The Coucur Y66 Smart Watch showcasing its multifunctional capabilities, including voice assistant, music control, flashlight, camera control, alarm clock, calculator, weather forecast, and women's health tracking.

Maintenance

1. Water Resistance (IP68)

The Coucur Y66 Smart Watch is designed with IP68 waterproof rating, making it suitable for daily activities such as washing hands, sweating during exercise, and exposure to rain. **It is not recommended for swimming or submerging in water for extended periods.**



Image: The Coucur Y66 Smart Watch being splashed with water, illustrating its IP68 waterproof capability for daily use.

2. Cleaning

Wipe the watch and strap regularly with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials that could damage the device.

3. Battery Care

To prolong battery life, avoid extreme temperatures. Charge the watch fully when indicated and avoid letting the battery completely drain frequently. The watch has a built-in 300mAh battery, offering up to 7 days of average usage and 30 days of standby time on a 2-hour charge.

Troubleshooting

- **Connection Issues:** If the watch repeatedly disconnects from your phone, try restarting both the watch and your phone's Bluetooth. Ensure the GloryFit app is running in the background and Bluetooth is connected to both the phone and the app.
- **Notifications Not Received:** Verify that the GloryFit app has all necessary permissions enabled on your phone and is

allowed to run in the background. Check notification settings within the app.

- **Inaccurate Tracking:** Data monitored by the smartwatch is for reference only and should not be used as medical guidance. For best accuracy, ensure the watch is worn snugly on your wrist.
- **Watch Not Powering On:** Ensure the watch is sufficiently charged. If completely drained, charge for at least 30 minutes before attempting to power on.

For more detailed troubleshooting and frequently asked questions, refer to the "GloryFit" app's help section.




Image: An informational graphic highlighting important notes regarding charging, Bluetooth connection, and IP68 water resistance limitations for the Coucur Y66 Smart Watch.

Specifications

Feature	Detail
Model Number	Y66
Screen Size	1.96 Inches HD Touch Screen
Connectivity	Bluetooth 5.3
Water Resistance	IP68
Battery Capacity	300 mAh
Charging Time	Approximately 2 hours
Battery Life (Average Use)	Up to 7 days
Standby Time	Approximately 30 days
Operating System Compatibility	Android/iOS
Item Weight	3.17 ounces
Package Dimensions	6.77 x 3.31 x 0.59 inches

Warranty and Support

For warranty information, please refer to the documentation provided with your purchase or contact the seller directly. For

technical support and further assistance, please consult the "GloryFit" app or the manufacturer's official support channels.

Coucur Y66 Smart Watch User Manual. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question