Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ANCTOR B0F9YYQFFW

ANCTOR Kitchen Pantry Cabinet Instruction Manual

Model: B0F9YYQFFW

Introduction

Thank you for choosing the ANCTOR Kitchen Pantry Cabinet. This manual provides essential information for the safe assembly, operation, and maintenance of your new storage cabinet. Please read these instructions thoroughly before beginning assembly and retain them for future reference.



Image: The ANCTOR Kitchen Pantry Cabinet in Rustic Maple finish. This image displays the full cabinet with its six barn-style doors and overall aesthetic.

Safety Information

To ensure safe use of this product, please observe the following precautions:

- **Anti-Tip Device:** Always install the provided anti-tip device to secure the cabinet to a wall. Failure to do so can result in serious injury or death from tipping furniture.
- **Assembly:** Assembly should be performed by two adults. Ensure all parts are correctly installed and fasteners are tightened securely before use.
- **Weight Distribution:** Distribute weight evenly across shelves. Avoid placing excessively heavy items on upper shelves.
- **Placement:** Place the cabinet on a level, stable surface.
- **Children:** Do not allow children to climb on or play with the cabinet.



Image: Close-up view illustrating the thickened wooden structure, sturdy base support, and the wall anti-tipping device. This highlights key safety and stability features.

Package Contents

Before assembly, verify that all components listed in the instruction manual are present and undamaged. The package includes:

- All necessary wooden panels (pre-drilled and numbered)
- Hardware kit (screws, dowels, cam locks, hinges, handles)
- Motion-sensing LED light unit
- Anti-tip device
- Assembly tools (e.g., Allen wrench)
- Instruction manual

Setup and Assembly Instructions

Assembly requires two people and approximately 4-5 hours. Follow the detailed, numbered instructions provided in the included assembly guide. Ensure you have a clear, spacious area for assembly.

1. **Unpack and Identify Parts:** Carefully unpack all components. Refer to the parts list in your separate assembly guide to identify each numbered panel and hardware piece.
2. **Assemble Frame:** Begin by connecting the main side panels and base using the provided hardware. Ensure all connections are secure.
3. **Install Shelves:** Insert the fixed shelves into their designated slots. The cabinet features 12 shelves, with 2 adjustable dividers.
4. **Attach Door Storage Racks:** Secure the door storage racks to the interior of the specified doors.
5. **Mount Doors:** Attach the six barn-style doors using the high-quality metal hinges. Adjust hinges as needed for proper door alignment.
6. **Install Handles:** Secure the handles to the exterior of the doors.
7. **Install LED Light:** Mount the motion-sensing LED light unit inside the top cabinet section.
8. **Secure Anti-Tip Device:** Attach the anti-tip device to the top rear of the cabinet and secure it to a wall stud using appropriate wall anchors (not always included, check your specific hardware kit).




Image: Diagram showing the overall dimensions of the ANCTOR Kitchen Pantry Cabinet (71.3" H x 39.4" W x 15.8" D) and the internal layout with shelf measurements. This aids in understanding the cabinet's structure during assembly.




Image: Close-up view demonstrating the adjustable shelf mechanism. Yellow dashed lines indicate the range of adjustment for the shelves, allowing customization of storage space.

Operating Instructions

Using the Motion-Sensing LED Light

The ANCTOR Kitchen Pantry Cabinet is equipped with a built-in motion-sensing LED light located in the top section. This light is designed to illuminate automatically when the cabinet doors are opened, providing visibility to the contents. The light will turn off after a short period of inactivity or when the doors are closed.



Image: Close-up of the interior of the top cabinet section, showing the motion-sensing LED light illuminating the contents. This illustrates the automatic lighting feature.

Adjusting Shelves

Two of the twelve shelves are adjustable, allowing you to customize the storage space to accommodate items of various heights. To adjust a shelf:

1. Remove all items from the shelf.
2. Carefully lift the shelf and remove the shelf pins from their current holes.
3. Reinsert the shelf pins into the desired new holes, ensuring they are level.
4. Place the shelf back onto the pins.

Utilizing Door Storage Racks

The cabinet features two doors with integrated storage racks. These racks are ideal for smaller items such as spices, condiments, or small jars, maximizing the cabinet's storage capacity.



Image: Interior view of a cabinet door showing the integrated storage racks. The racks are depicted holding various small items like spice jars, demonstrating their utility.

Maintenance

Proper care will extend the life and appearance of your ANCTOR Kitchen Pantry Cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals, abrasive cleaners, or excessive moisture, which can damage the finish.
- **Spills:** Clean spills immediately to prevent staining or damage to the wood.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- **LED Light:** If the LED light stops functioning, check the battery (if applicable, or power connection). Consult the manufacturer if issues persist.

Troubleshooting

Problem	Possible Cause	Solution
Doors do not align properly.	Hinges are not adjusted correctly or cabinet is not level.	Adjust the screws on the hinges to align the doors. Ensure the cabinet is on a level surface.
LED light does not turn on.	Battery depleted (if battery-operated) or sensor obstructed.	Replace batteries if applicable. Ensure the sensor is clear of obstructions.
Cabinet feels unstable.	Anti-tip device not installed or fasteners loose.	Ensure the anti-tip device is securely fastened to both the cabinet and a wall stud. Check and tighten all assembly fasteners.

Specifications

Feature	Detail
Brand	ANCTOR
Model	B0F9YYQFFW
Dimensions (H x W x D)	71.3" x 39.4" x 15.8"
Color	Rustic Maple
Number of Doors	6 (Barn Doors)
Number of Shelves	12 (2 adjustable)
Special Features	Motion-sensing LED light, Door storage racks, Anti-tip device
Material	Engineered Wood (MDF)
Item Weight	143 Pounds
Assembly Required	Yes

Warranty and Support

For warranty information, replacement parts, or technical support, please contact ANCTOR customer service. Refer to your purchase documentation for specific contact details or visit the official ANCTOR website.
Online Support: Visit the ANCTOR Store on Amazon

© 2025 ANCTOR. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F9YYQFFW

More documents and user manuals: **https://manuals.plus/**