

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Sauder](#) /

› [Sauder Merton Hall Storage Cabinet, Harmony Ash Finish Instruction Manual](#)

Sauder 443670

Sauder Merton Hall Storage Cabinet, Harmony Ash Finish Instruction Manual

PRODUCT OVERVIEW

The Sauder Merton Hall Storage Cabinet in Harmony Ash finish offers a versatile and sturdy storage solution. Constructed with strong and lightweight engineered wood panels, this double-door cabinet features soft-close hinges and a combination of adjustable and fixed shelves to accommodate various items.



Image: Sauder Merton Hall Storage Cabinet with doors closed, showcasing the Harmony Ash finish.

Key Features:

- **Material:** Engineered Wood for durability and lightweight construction.
- **Versatile Storage:** Suitable for living rooms, kitchens, offices, or laundry/utility areas.
- **Adjustable Shelving:** Three adjustable shelves and one fixed shelf provide flexible storage options. Each adjustable shelf supports up to 25 lbs.
- **Soft-Closing Doors:** Doors are equipped with soft-closing hinges to prevent slamming.
- **Dimensions:** 23-1/2" W x 16-7/8" D x 71" H.
- **Safety:** Includes a wall anchor kit to prevent tip-over accidents.



Image: The storage cabinet with both doors open, revealing the interior shelves and storage capacity.

SETUP AND ASSEMBLY

This Sauder product requires assembly. Please follow the illustrated instructions provided in your assembly booklet carefully. Ensure all parts are present before beginning. A power drill on a low torque setting is recommended for efficiency, but exercise caution to avoid damaging the wood or stripping hardware.

It is highly recommended to have a second person assist with assembly due to the weight and size of the components.

Attaching the Back Panel:

Proper attachment of the back panel is crucial for the unit's squareness, stability, and strength. Do not stand the unit upright without the back attached, as it may collapse.

Your browser does not support the video tag.

Video: Instructions on how to properly attach the back panel to your Sauder unit, ensuring stability and squareness.

Cam and Dowel Assembly:

Many Sauder products utilize cam and dowel fasteners for secure assembly. Ensure proper alignment and tightening for a strong connection.

Your browser does not support the video tag.

Video: Detailed guide on assembling components using cam and dowel fasteners, a common method in Sauder furniture.

OPERATING INSTRUCTIONS

Adjusting Shelves:

The cabinet features three adjustable shelves. To adjust a shelf, carefully lift it from its current position and reposition the shelf pins into the desired holes. Ensure all four pins are securely seated before placing items on the shelf.



Image: Close-up view of the adjustable shelves and the soft-close hinges within the cabinet.

Soft-Close Hinges:

The doors are equipped with soft-close hinges for quiet and gentle closing. These hinges are designed to prevent the doors from slamming shut.

MAINTENANCE

General Care:

- Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- Periodically check all fasteners and tighten if necessary to maintain structural integrity.
- Keep the cabinet away from direct sunlight and extreme temperature changes to prevent warping or fading.
- Ensure the wall anchor kit remains securely fastened to prevent tip-over hazards.

Hinge Adjustment:

If the cabinet doors become misaligned, the adjustable hinges can be fine-tuned. This video demonstrates how to adjust the door horizontally, vertically, and for depth.

Your browser does not support the video tag.

Video: Guide on how to install and adjust the adjustable hinges for proper door alignment on your cabinet.

TROUBLESHOOTING

- **Wobbly Unit:** Ensure all cam locks and screws are fully tightened. Verify the back panel is securely attached and squared.

- **Misaligned Doors:** Refer to the 'Hinge Adjustment' video in the Maintenance section to correct door alignment.
- **Doors Not Closing Softly:** Check the soft-close mechanism on the hinges for any obstructions or damage. Adjust hinges if necessary.
- **Missing Parts:** If any parts are missing or damaged, contact Sauder customer service immediately.

SPECIFICATIONS




Image: Dimensional diagram of the Sauder Merton Hall Storage Cabinet, showing height, width, and depth.

Feature	Detail
Brand	Sauder
Model Name	Merton Hall
Model Number	443670
Color	Harmony Ash
Material	Engineered Wood
Product Dimensions	16.85"D x 23.47"W x 70.95"H
Item Weight	130.7 Pounds
Weight Limit	155 Pounds (total)
Number of Shelves	4 (3 adjustable, 1 fixed)
Door Style	Flat Panel, Double Door
Special Features	Strong and lightweight panel construction, soft-close hinges
Assembly Required	Yes
GTIN/UPC	042666244961

WARRANTY AND SUPPORT

This product comes with a 5-year limited warranty. For specific details regarding the warranty, please refer to the product description or the store page where it was purchased.

Sauder is a family-owned American company committed to quality and customer satisfaction. If you have any questions about the product, assembly, or require assistance, please contact Sauder customer service.



DOMESTIC CALL CENTER READY TO ASSIST.

sauder.com/service

800-523-3987

Image: Sauder Domestic Call Center information, indicating readiness to assist customers.

Contact Information:

- **Website:** sauder.com/service
- **Phone:** 800-523-3987

California Proposition 65 Warning: This product contains Formaldehyde. For more information, visit www.p65warnings.ca.gov.