

[Manuals.plus](#) /

> [Citizen](#) /

> Citizen Eco-Drive Blue Angels Promaster Navihawk Watch (Model: CA4667-53L) - Instruction Manual

Citizen CA4667-53L

Citizen Eco-Drive Blue Angels Promaster Navihawk Watch

Model: CA4667-53L

Brand: Citizen

1. OVERVIEW

The Citizen Eco-Drive Blue Angels Promaster Navihawk Watch (Model: CA4667-53L) is a special-edition timepiece designed for precision and durability. It features a robust silver-tone stainless steel case, a blue ion-plated bidirectional bezel with a slide-rule scale, and a triple-link stainless steel bracelet. The watch is powered by Citizen's proprietary Eco-Drive technology, which converts light into energy, eliminating the need for battery replacement. Key functions include a 1/5 second chronograph, 12/24 hour time displays, and a date indicator, all protected by a sapphire crystal and 200 meters of water resistance.

2. KEY FEATURES

- **Eco-Drive Technology:** Powered by any light source, eliminating the need for battery changes.
- **Chronograph:** 1/5 second chronograph measuring up to 60 minutes.
- **Time Display:** Features both 12/24 hour time displays.
- **Date Indicator:** Convenient date display.
- **Slide-Rule Bezel:** Blue ion-plated bidirectional bezel with a slide-rule scale for flight utility.
- **Durable Construction:** Silver-tone stainless steel case and triple-link bracelet.
- **Sapphire Crystal:** Highly scratch-resistant crystal for enhanced durability.
- **Water Resistance:** 200 meters (660 feet) suitable for professional marine activity and serious surface water sports.
- **Blue Angels Special Edition:** Features a distinctive Blue Angels colorway and insignia-signed case back.

3. SETUP

3.1 Initial Charging

Your Citizen Eco-Drive watch is powered by light. Before initial use, ensure the watch is fully charged by exposing it to a bright light source (natural or artificial) for several hours. A full charge can last for several months, even in darkness.

Video: Learn how Citizen's Eco-Drive technology converts any light source into energy to power your watch, eliminating the need for battery changes.

3.2 Setting Time and Date

Refer to the detailed instructions in the full user manual for precise time and date setting procedures. Generally, the crown is used to adjust the time and date. Pull the crown out to the appropriate position and rotate to set. Push the crown back in to secure the settings.

3.3 Adjusting 12/24 Hour Display

This model supports both 12-hour and 24-hour time displays. Consult the comprehensive manual for specific steps on how to switch between these display modes, typically involving a combination of crown and pusher operations.

4. OPERATING YOUR WATCH

4.1 Chronograph Function

The watch features a 1/5 second chronograph capable of measuring up to 60 minutes. Use the pushers on the side of the case to start, stop, and reset the chronograph. The sub-dials will display the elapsed time.

4.2 Using the Slide-Rule Bezel

The bidirectional rotating bezel features a slide-rule scale, a tool commonly used by pilots for various calculations such as multiplication, division, fuel consumption, and speed. Rotate the bezel to align the inner and outer scales for desired calculations. Detailed instructions for specific calculations are available in the full user manual.



Image: Front view of the Citizen Eco-Drive Blue Angels Promaster Navihawk Watch, showcasing the dial, chronograph sub-dials, and slide-rule bezel.

5. MAINTENANCE

5.1 Eco-Drive Charging Best Practices

To maintain optimal performance of your Eco-Drive watch, ensure it receives regular exposure to light. Avoid prolonged storage in dark places. If the watch stops or indicates a low charge, expose it to bright light until fully charged. The watch features a power reserve indicator to help monitor its charge level.

5.2 Cleaning and Care

Wipe the watch regularly with a soft, dry cloth to remove dirt and moisture. For the stainless steel bracelet, a soft brush

with mild soapy water can be used, followed by thorough rinsing and drying. The sapphire crystal is highly scratch-resistant but not entirely scratch-proof; avoid unnecessary impacts.

5.3 Water Resistance

The watch is water resistant to 200 meters. Ensure the crown is fully pushed in before any contact with water. Avoid operating the pushers or crown while the watch is wet or submerged to prevent water intrusion.



Image: Back view of the Citizen Eco-Drive Blue Angels Promaster Navihawk Watch, highlighting the stainless steel case back with the

6. TROUBLESHOOTING

6.1 Watch Stops or Runs Intermittently

This usually indicates insufficient charge. Expose the watch to bright light for several hours to fully recharge the Eco-Drive power cell. If the issue persists after adequate charging, contact Citizen customer support.

6.2 Time or Date is Incorrect

Manually adjust the time and date using the crown as described in the full user manual. Ensure the crown is fully pushed in after adjustment. If the watch has an atomic timekeeping feature (not explicitly stated for this model but common in Navihawk series), ensure it is receiving signals correctly.

7. SPECIFICATIONS

- **Model Number:** CA4667-53L
- **Case Dimensions:** 40mm diameter
- **Material:** Stainless Steel
- **Movement:** Eco-Drive (Caliber B620)
- **Water Resistance:** 200 meters (660 feet)
- **Crystal:** Sapphire Crystal
- **Functions:** 1/5 second chronograph (up to 60 minutes), 12/24 hour time, date indicator, slide-rule bezel.
- **Weight:** Approximately 1.1 Pounds (packaged)
- **Manufacturer:** Citizen
- **Department:** Men's





Image: The Citizen Eco-Drive Blue Angels Promaster Navihawk Watch presented in its distinctive protective packaging.

8. WARRANTY AND SUPPORT

Citizen offers a comprehensive warranty for its timepieces. For specific warranty details, including coverage and duration, please refer to the warranty card included with your watch or visit the official Citizen website. Extended protection plans are also available for purchase, offering additional coverage beyond the standard manufacturer's warranty.

- **2-Year Protection Plan:** Available for purchase.

- **3-Year Protection Plan:** Available for purchase.
- **Complete Protect:** Monthly plan covering eligible past and future purchases.

For technical assistance, service, or any inquiries regarding your Citizen watch, please contact Citizen customer support through their official website or the contact information provided in your product documentation.

© 2026 Citizen Watch Group. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F9Z5TRR9>

More documents and user manuals: <https://manuals.plus/>