



Manuals.plus /

› Casio /

› Casio G-Shock GD-010BBR-1 User Manual

## Casio GD010BBR-1

# Casio G-Shock GD-010BBR-1 User Manual

Model: GD-010BBR-1

## INTRODUCTION

---

This manual provides detailed instructions for the operation and maintenance of your Casio G-Shock GD-010BBR-1 watch. This timepiece is designed for durability and functionality, featuring a robust black resin case and band with a striking red digital display. It is built to withstand challenging conditions, offering water resistance and various timekeeping features.



Image: Front view of the Casio G-Shock GD-010BBR-1 watch, highlighting its black resin construction and the vibrant red digital display. The display shows the day and date as 'SUN 6-30' and the time as '10:58'. Various function indicators like MUTE, ALM, SIG, and ILLUMINATOR are also visible.

# SETUP

---

## Initial Time Setting

1. Press and hold the **ADJUST** button (top left) until the city code starts to flash. This indicates the setting mode.
2. Use the **FORWARD** (bottom right) and **REVERSE** (top right) buttons to select your desired city code.
3. Press the **MODE** button (bottom left) to cycle through the settings: DST (Daylight Saving Time), 12/24-hour format, Seconds, Hour, Minute, Year, Month, Day.
4. For each setting, use the **FORWARD** and **REVERSE** buttons to change the value.
5. Once all settings are configured, press the **ADJUST** button to exit the setting mode.

## OPERATING MODES

---

The watch features several operating modes accessible via the **MODE** button.

### Timekeeping Mode

Displays the current time, day, and date. This is the default mode.

### Stopwatch Mode

- Press **MODE** to navigate to the Stopwatch mode.
- Press **START** (bottom right) to begin timing.
- Press **START** again to pause/resume.
- Press **RESET** (top right) to reset the stopwatch to zero.

### Alarm Mode

- Press **MODE** to navigate to the Alarm mode.
- Use **FORWARD** and **REVERSE** to select an alarm number (if multiple are available).
- Press **ADJUST** to enter alarm setting mode.
- Use **FORWARD** and **REVERSE** to set the alarm time.
- Press **ADJUST** to confirm and exit.
- Press **SELECT** (middle left) to toggle the alarm on/off. An "ALM" indicator will appear when active.

### Illuminator (Backlight)

Press the **ILLUMINATOR** button (usually the large button at the bottom center, or indicated by "LT" on the display) to illuminate the display for easy viewing in low light conditions. The "LT" indicator on the display signifies the auto-light feature is active if configured.

## MAINTENANCE

---

### Water Resistance

The GD-010BBR-1 is water resistant to 20 BAR (200 meters). This means it is suitable for showering, swimming, and diving. Do not operate buttons while the watch is wet or submerged to prevent water ingress.

### Cleaning

Wipe the watch with a soft, dry cloth. For stubborn dirt, use a mild soap solution and a soft brush, then rinse thoroughly with fresh water and dry completely. Avoid using chemical cleaners or solvents.

## Battery Replacement

The watch uses 1 LR44 battery. When the display dims or functions become erratic, it may be time for a battery replacement. It is recommended to have the battery replaced by an authorized Casio service center to ensure proper sealing and water resistance.

## TROUBLESHOOTING

---

- **Display is blank or dim:** Check battery level. Replace battery if necessary. Ensure watch is not exposed to extreme temperatures.
- **Buttons are unresponsive:** Ensure the watch is not in a locked mode (if applicable). If wet, dry thoroughly. If issue persists, a service check may be required.
- **Time is incorrect:** Re-adjust time settings as per the "Initial Time Setting" section. Check for DST settings.
- **Water inside display:** Immediately cease use and take the watch to an authorized service center. This indicates a breach in water resistance.

## SPECIFICATIONS

---

Feature	Detail
Model Number	GD010BBR-1
Case Size (L x W x H)	54.9 x 51.9 x 16.1 mm
Package Dimensions	5 x 3 x 3 inches
Item Weight	8 ounces
Water Resistance	20 BAR (200 meters)
Battery Type	1 LR44 (included)
Clasp Type	Buckle
Department	Mens
Manufacturer	Casio

## WARRANTY AND SUPPORT

---

For warranty information and customer support, please refer to the official Casio website or contact your local authorized Casio dealer. Keep your proof of purchase for warranty claims.

Official Casio Website: [www.casio.com](http://www.casio.com)