

EaseLife 0602_W2_305J3_2

EaseLife 10FT Double Door Sliding Barn Door Hardware Track Kit Instruction Manual

Model: 0602_W2_305J3_2

1. SAFETY INFORMATION

Please read all instructions carefully before installation and use. Failure to follow these instructions may result in injury or property damage. Keep this manual for future reference.

- Always wear appropriate safety gear, including safety glasses and gloves, during installation.
- Ensure the mounting surface (wall) is structurally sound and capable of supporting the weight of the doors and hardware. Consult a professional if unsure.
- Use a stud finder to locate wall studs for secure mounting. If studs are not at ideal locations, a header board may be required.
- Keep children and pets away from the installation area.
- Do not exceed the maximum door weight capacity of 360 lbs.
- Ensure all fasteners are tightened securely before operating the doors.

2. PACKAGE CONTENTS

Verify that all components listed below are present and undamaged before beginning installation. If any parts are missing or defective, please contact EaseLife customer support.

Package List



Door not included,
hardware only




Image: All components of the EaseLife 10FT Double Door Sliding Barn Door Hardware Track Kit.

- 3x 3.33ft Rails (total 10FT track length)
- 4x Pulleys (Hangers with Industrial Spoke Wheels)
- 8x Spacers
- 2x Door Stoppers
- 2x Floor Guides
- 2x 12-inch Pull Handles
- Mounting Hardware (bolts, screws, washers)
- Instruction Manual

Note: Doors are NOT included with this hardware kit.

3. PRODUCT SPECIFICATIONS

Specification	Detail
Brand	EaseLife
Model Number	0602_W2_305J3_2
Track Length	10FT (120 inches)
Door Fit (Double Door)	Up to two 30-inch wide doors (total 60-inch opening)
Door Thickness Compatibility	1-3/8" to 1-3/4" (35mm to 45mm)
Maximum Door Weight Capacity	360 lbs
Material	Aluminum (Track), Steel (Hardware)
Finish	Black Powder-Coated
Mounting Type	Wall Mount
Item Weight	16.98 pounds
Package Dimensions	50.39 x 10.24 x 4.33 inches

Product Dimension




Image: Product dimension diagram for the 10FT track.

4. SETUP AND INSTALLATION

This section provides a general overview of the installation process. Refer to the detailed step-by-step manual included in your package for precise instructions and diagrams.

Long Lasting °

Premium steel, fine black powder coated surface,
ensures years of beauty and longevity

Ours

Others



Image: Visual guide for DIY installation steps.

1. **Measure and Mark:** Determine the desired height for your track. Ensure a minimum clearance of 6 inches above the door opening. Mark the positions for the track mounting holes, aligning with wall studs for maximum stability.
2. **Install Track:** Securely attach the track sections to the wall using the provided spacers and lag bolts. Ensure the track is level.
3. **Assemble Hangers:** Attach the pulleys (hangers) to the top edge of your barn doors. Ensure they are evenly spaced and securely fastened.
4. **Mount Doors:** Carefully lift each door and hook the pulleys onto the installed track.
5. **Install Door Stoppers:** Place the door stoppers at the ends of the track to prevent the doors from sliding off. Adjust their positions to control the door's travel.
6. **Install Floor Guides:** Mount the floor guides to the floor directly below the doors to prevent them from swinging outwards. Adjust for smooth operation.
7. **Attach Handles:** Install the pull handles on your doors at a comfortable height.

For a soft copy of the installation guide or professional assistance, please contact our online service.

5. OPERATING INSTRUCTIONS

The EaseLife sliding barn door hardware is designed for smooth and quiet operation. Once installed correctly, your doors will glide effortlessly.

High-Precision Ball Bearings for quiet & smooth sliding performance



Test **100,000+**



Our:
Dual bearings
Larger wheels



Other:
Single bearing
Small wheels

Image: High-precision ball bearings for quiet and smooth sliding.

- To open or close the doors, gently push or pull the handle in the desired direction.
- The high-precision bearing rollers ensure minimal friction and noise during movement.
- Avoid forcing the doors if they encounter resistance. Inspect the track and rollers for any obstructions.

6. MAINTENANCE

Regular maintenance will ensure the longevity and optimal performance of your EaseLife barn door hardware.



DIY Easy Install



Image: Durability of the black powder-coated finish.

- **Cleaning:** Wipe the track and hardware components with a soft, damp cloth to remove dust and debris. Avoid abrasive cleaners that could damage the finish.
- **Lubrication:** Periodically apply a silicone-based lubricant to the wheel bearings and the top of the track to maintain smooth operation. Do not use oil-based lubricants as they can attract dust.
- **Fastener Check:** Annually inspect all mounting bolts and screws to ensure they remain tight. Re-tighten if necessary.
- **Floor Guide:** Keep the floor guide clean and free of obstructions.

7. TROUBLESHOOTING

If you encounter any issues with your barn door hardware, refer to the following common solutions:

- **Doors are difficult to slide:**
 - Check the track for any debris or obstructions.
 - Ensure the track is level. An unlevel track can cause resistance.

- Apply lubricant to the wheel bearings and track.
- Verify that the floor guides are not too tight against the door.

- **Doors make noise when sliding:**

- Lubricate the wheel bearings.
- Check for loose fasteners on the hangers or track.
- Ensure the door is not rubbing against the wall or door frame. Adjust spacers if needed.

- **Door swings out from the wall:**

- Adjust or re-position the floor guide to properly secure the bottom of the door.

- **Door stoppers are not effective:**

- Ensure the door stoppers are securely tightened to the track and positioned correctly.

If these steps do not resolve the issue, please contact EaseLife customer support for further assistance.

8. WARRANTY AND SUPPORT

EaseLife is committed to providing high-quality products and excellent customer service. Your hardware kit is backed by our commitment to quality and durability.

- **Quality Assurance:** Our barn door hardware is crafted from premium steel with a fine black powder-coated finish, designed for years of beauty and longevity. The high-precision bearing rollers are tested for over 100,000 cycles to ensure smooth and silent operation.
- **Customer Support:** For any missing or defective parts, or if you require assistance with installation or troubleshooting, please contact EaseLife customer support. We offer 24/7 assistance to provide prompt solutions.
- **Contact Information:** Refer to the contact details provided in your product packaging or visit the official EaseLife website for support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question