DEZLTID M518-EEA

DEZLTID 11-inch Android 15 Tablet M518-EEA User Manual

Model: M518-EEA

1. Introduction

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your DEZLTID 11-inch Android 15 Tablet, model M518-EEA. Please read this manual thoroughly before using your device to ensure proper functionality and to maximize your user experience.

2. Setup

2.1 Unboxing and Initial Inspection

Carefully remove all items from the packaging. Verify that all components are present and undamaged. The package should contain:

- DEZLTID 11-inch Android 15 Tablet
- Keyboard
- Stylus
- Mouse
- Wired headphones
- Tablet Case
- Type-C Cable
- Fast Charger
- Card eject pin
- Screen Protector (pre-applied or separate)
- OTG Cable
- User Manual (this document)



Image: The DEZLTID 11-inch Android 15 Tablet displayed with its full suite of accessories, including a detachable keyboard, stylus, mouse, and protective case.

2.2 Charging the Tablet

Before first use, fully charge the tablet using the provided Type-C cable and fast charger. Connect the Type-C cable to the tablet's charging port and the charger to a power outlet. The battery indicator on the screen will show charging status.

2.3 Powering On/Off

- **To Power On:** Press and hold the Power button until the DEZLTID logo appears on the screen.
- **To Power Off:** Press and hold the Power button until the power options menu appears. Select 'Power off'.
- **To Restart:** Press and hold the Power button. Select 'Restart' from the options menu.

2.4 Initial Device Setup

Upon first power-on, follow the on-screen prompts to complete the initial setup:

1. Select your preferred language.
2. Connect to a Wi-Fi network.
3. Sign in with your Google account or create a new one.
4. Review and accept the terms and conditions.
5. Set up screen lock (PIN, pattern, or password).

2.5 Connecting Accessories

The tablet comes with a keyboard, mouse, and stylus for enhanced productivity.

- **Keyboard:** Attach the keyboard to the tablet via its magnetic connector. Ensure it is securely aligned.
- **Mouse:** The mouse typically connects via Bluetooth. Go to Settings > Connected devices > Bluetooth, turn on Bluetooth, and pair with the mouse.
- **Stylus:** The stylus is ready for use upon removal from its holder or packaging. No pairing is usually required for basic functionality.

2.6 MicroSD Card Installation

To expand storage, insert a MicroSD card (up to 1TB, sold separately) into the designated slot using the provided card eject pin. Ensure the tablet is powered off before inserting or removing the card.

3. Operating Your Tablet

3.1 Basic Navigation

The tablet uses a touch-based interface. Common gestures include:

- **Tap:** Select an item or open an app.
- **Swipe:** Navigate through screens or scroll content.
- **Pinch-to-zoom:** Enlarge or reduce content size.
- **Long press:** Access contextual menus or move icons.

3.2 Android 15 Features

Your tablet runs on Android 15, offering enhanced features for productivity and accessibility:

- **Split Screen:** Run two apps simultaneously side-by-side.
- **Focus Mode:** Temporarily pause distracting apps.
- **Homework Correction:** Utilize AI-powered tools for educational assistance.
- **Real-time Subtitles:** Automatically generate captions for audio and video content.
- **200% Stepless Fonts:** Adjust font size for improved readability.



Image: The home screen of the DEZLTID tablet, showcasing the Android 15 operating system with its clean interface and a variety of pre-installed applications.

3.3 Connectivity

- **Wi-Fi:** Connect to 5G or 2.4G Wi-Fi networks via Settings > Network & internet > Wi-Fi.
- **Bluetooth 5.0:** Pair with wireless headphones, speakers, or other Bluetooth devices via Settings > Connected devices > Bluetooth.
- **GPS:** Utilize the Global Positioning System for navigation and location-based services.

3.4 Camera Usage

The tablet features an 8MP front camera and a 13MP rear camera.

- Open the Camera app from the home screen or app drawer.
- Switch between front and rear cameras using the icon on the screen.
- Tap to focus and press the shutter button to capture photos or videos.



Image: A detailed view of the tablet's dual rear camera setup and a user engaging with the tablet in an outdoor setting, highlighting its portability and camera capabilities.

3.5 Media Playback and Streaming

The 11-inch 2K IPS display (2000x1200 resolution) and Widevine L1 support ensure high-quality media consumption.

- Enjoy HD streaming from platforms like Netflix, Hulu, and Amazon Prime Video.
- The dual speakers provide clear audio output.
- Connect wired headphones to the 3.5mm audio jack for private listening.



Image: The DEZLTID tablet showcasing its compatibility with popular streaming services such as Netflix, Prime Video, and Hulu, emphasizing its Widevine L1 certification for high-definition content.

3.6 Productivity Features



Image: A composite image illustrating various productivity and utility features of the DEZLTID tablet, including its PC Mode with external accessories, split-screen multitasking, stylus interaction, charging status, and GPS navigation capabilities.

- **PC Mode:** Transform your tablet into a laptop-like experience by connecting the keyboard and mouse.
- **Split View:** Efficiently manage two applications side-by-side for enhanced multitasking.
- **Versatile Stylus:** Use the stylus for drawing, note-taking, or precise interaction with apps.
- **FM Radio Function:** Access FM radio broadcasts.

4. Maintenance

4.1 Cleaning the Device

Use a soft, lint-free cloth to clean the screen and body of the tablet. For stubborn smudges, slightly dampen the cloth with water or a screen-cleaning solution. Avoid harsh chemicals or abrasive materials.

4.2 Battery Care

The tablet is equipped with an 8000mAh battery. To prolong battery life:

- Avoid extreme temperatures.
- Do not leave the tablet fully charged or fully discharged for extended periods.
- Use the original charger and cable.

4.3 Software Updates

Regularly check for and install software updates to ensure optimal performance, security, and access to new features. Go to Settings > System > System update.

4.4 Storage Management

Your tablet has 256GB of internal storage, expandable up to 1TB with a MicroSD card. Regularly manage your storage by:

- Deleting unnecessary files and apps.
- Moving large files to the MicroSD card.
- Utilizing cloud storage services.

5. Troubleshooting

5.1 Common Issues and Solutions

Problem	Solution
Tablet does not power on	Ensure the tablet is charged. Press and hold the power button for 10-15 seconds.
Wi-Fi connection issues	Restart the tablet and your Wi-Fi router. Forget the network and reconnect.
Apps are crashing or freezing	Clear the app's cache (Settings > Apps > [App Name] > Storage > Clear cache). Update the app or reinstall it.
Slow performance	Close unused apps. Clear cache. Check for software updates. Free up storage space.
Accessories not connecting	Ensure Bluetooth is enabled for wireless accessories. Check physical connections for the keyboard. Restart the tablet.

5.2 Factory Reset

If persistent issues occur, a factory reset may be necessary. This will erase all data on your tablet. Back up important data before proceeding. Go to Settings > System > Reset options > Erase all data (factory reset).

6. Technical Specifications



Image: An overview of the DEZLTID tablet's key features and specifications, including its display size, camera resolutions, operating system, battery capacity, and connectivity options.

Feature	Specification
Model Number	M518-EEA
Operating System	Android 15
Display	11-inch 2K IPS (2000x1200), 178° wide viewing, 350-nit brightness
Processor	Octa-core 1.6GHz CPU
Graphics Coprocessor	Mali-G57
RAM	36GB (12GB + 24GB virtual) LPDDR4X
Internal Storage	256GB UFS 2.1

Feature	Specification
Expandable Storage	Up to 1TB via MicroSD card
Battery	8000mAh (up to 10 hours video playback)
Rear Camera	13MP
Front Camera	8MP
Wireless Connectivity	5G/2.4G Dual WiFi (802.11a/b/g/n/ac), Bluetooth 5.0
Navigation	GPS
Audio	Dual Speakers, 3.5mm Headset Interface
Ports	Type-C
Dimensions (LxWxH)	13.18 x 7.67 x 1.57 inches
Weight	1.29 pounds
Certifications	FCC/CE, Widevine L1




Image: A visual representation of the tablet's internal hardware, detailing its substantial RAM, storage capacity, and the specifications of its octa-core processor and GPU.

7. Warranty and Support

7.1 Warranty Information

Your DEZLTID tablet is covered by a 1-year warranty from the date of purchase. This warranty covers manufacturing defects and ensures product quality. Please retain your proof of purchase for warranty claims.

7.2 Technical Support

DEZLTID offers lifetime technical support for your product. If you encounter any issues or have questions not covered in this manual, please contact our dedicated support team. Refer to the product packaging or the official DEZLTID website for contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question